




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	103 33 307 001	Retainer	1	23	103 33 307 023	Throttle Valve	1
2	103 33 307 002	O-Ring	1	24	103 33 307 024	Spring	1
3	103 33 307 003	Reverse Valve	1	25	103 33 307 025	Air Inlet	1
4A	103 33 307 004	Screw	3	26	103 33 307 026	Trigger	1
4B	103 33 307 204	Screw	1	27	103 33 307 027	O-Ring	1
5	103 33 307 005	Spring Washer	3	28	103 33 307 028	Air Regulator	1
★ 6	103 33 307 006	Backhead Assembly (incl.45)	1	29	103 33 307 029	Spring	1
7	103 33 307 007	Gasket	1	30	103 33 307 030	Steel Ball	1
8	103 33 307 008	Motor Clamp Washer	1	31	103 33 307 031	Hammer Frame	1
9	103 33 307 009	Ball Bearing	2	32	103 33 307 032	Hammer	2
10	103 33 307 010	Gasket	1	33	103 33 307 033	Hammer Pin	2
11	103 33 307 011	End Plate	2	34A	103 33 307 034	Standard Anvil	1
12	103 33 307 012	Spring Pin	2	34B	103 33 307 234	6" Extended Anvil (Option)	1
13	103 33 307 013	Rotor Blade	5	35	103 33 307 035	O-Ring	1
14	103 33 307 014	Rotor	1	36	103 33 307 036	Socket Retainer	1
15	103 33 307 015	Cylinder	1	37	103 33 307 037	Bushing	1
16	103 33 307 016	Lock Nut	3	38	103 33 307 038	Hammer Case	1
★ 17	103 33 307 017	Housing Assembly { incl.17B(4). 17C.17D (2).46 (3) }	1	39	103 33 307 039	Exhaust Deflector	1
17A	103 33 307 217	Gasket	4	40	103 33 307 040	Screw	2
17B	103 33 307 317	Heli-Coil	1	41	103 33 307 041	Screw	3
17C	103 33 307 417	Reverse Valve Bushing	2	42	103 33 307 042	Oil Seal	1
17D	103 33 307 517	Steel Ball	1	43	103 33 307 043	Spring	1
18	103 33 307 018	Washer	1	44	103 33 307 044	Steel Ball	1
19	103 33 307 019	Trigger Pin	1	45	103 33 307 045	Grease Fitting	1
20B	103 33 307 020	Throttle Valve Plunger	1	46	103 33 307 046	Heli-Coil	3
21	103 33 307 021	Spring Pin	1				
22	103 33 307 022	O-Ring					

★ Must be Purchased in Assembly Set

A-BIP-H65-R65T1085 A