




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
01-104-01	104 32 302 001	ROTOR BLADE	7	13-701-06	104 32 302 013	SCREW	1	37-503-07	104 32 302 037	REAR PLATE	1
02-200-04	104 32 302 002	O-RING (P4)	3	13-701-10	104 32 302 213	SCREW	1	38-504-07	104 32 302 038	CYLINDER	1
02-200-07	104 32 302 202	O-RING (P8x1.5)	1	14-701-01	104 32 302 014	OIL SEAL	1	39-504-01	104 32 302 039	NUT (LH)	1
02-202-03	104 32 302 302	O-RING (AS-568-025)	1	15-701-04	104 32 302 015	BALL BEARING (696-2Z)	1	41-704-01	104 32 302 041	HAMMER CASE	1
03-700-04	104 32 302 003	STEEL BALL (φ 4mm)	1	15-702-04	104 32 302 215	BALL BEARING (R6)	1	42-703-01	104 32 302 042	RING	2
04-700-03	104 32 302 004	PIN (φ 2x6)	1	17-709-01	104 32 302 017	SWITCH LEVER	1	45-402-01	104 32 302 045	ADJUSTER	1
04-701-08	104 32 302 204	PIN (φ 2x18)	1	18-704-01	104 32 302 018	REVERSE VALVE	1	51-402-04	104 32 302 051	BUSHING	1
04-702-08	104 32 302 304	PIN (φ 4.75x29)	2	21-701-01	104 32 302 021	RING	1	51-404-01	104 32 302 251	BUSHING	1
05-702-04	104 32 302 005	PIN (φ 3x26)	1	24-703-01	104 32 302 024	VALVE ROD	1	51-503-05	104 32 302 351	BUSHING	1
06-701-04	104 32 302 006	SPRING	1	25-702-12	104 32 302 025	AIR INLET (PT)	1	51-701-03	104 32 302 451	BUSHING	1
08-701-02	104 32 302 008	SPRING	1	26-704-01	104 32 302 026	MUFFLER	1	52-701-07	104 32 302 052	WASHER	1
08-701-03	104 32 302 208	SPRING	1	31-707-02	104 32 302 031	HOOK	1	74-707-30	104 32 302 074	ANVIL	1
12-701-07	104 32 302 012	RETAINING RING	1	35-706-05	104 32 302 035	ROTOR	1	75-706-02	104 32 302 075	FRONT CAP (LH)	1
13-700-09	104 32 302 013	SCREW	1	36-503-11	104 32 302 036	FRONT PLATE	1	78-614-02	104 32 302 078	HANDLE	1