




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
01.	105 35 112 001	Air Inlet	1	25.	105 35 112 025	Planet Carrier	1
02.	105 35 112 002	O-Ring	1	26.	105 35 112 026	Needle Bearing	2
03.	105 35 112 003	Spring	1	27.	105 35 112 027	Ratchet Housing	1
04.	105 35 112 004	Throttle Valve	1	28.	105 35 112 028	Crank Shaft	1
05.	105 35 112 005	Throttle Seat	1	29.	105 35 112 029	Drive Bushing	1
06.	105 35 112 006	Housing	1	30.	105 35 112 030	Ratchet Yoke	1
07.	105 35 112 007	Throttle Pin	1	31.	105 35 112 031	Clamp Nut	1
08.	105 35 112 008	O-Ring	1	32.	105 35 112 032	Reverse Button	1
09.	105 35 112 009	Lever	1	33.	105 35 112 033	Pin	1
10.	105 35 112 010	Roll Pin	1	34.	105 35 112 034	Spring	1
11.	105 35 112 011	O-Ring	2	35.	105 35 112 035	Pin	1
12.	105 35 112 012	Plug	1	36.	105 35 112 036	Ratchet Pawl	1
13.	105 35 112 013	Ball Bearing	1	37.	105 35 112 037	1/2" Anvil	1
14.	105 35 112 014	Rear End Plate	1	38.	105 35 112 038	Spring	2
15.	105 35 112 015	Roll Pin	2	39.	105 35 112 039	Pin	2
16.	105 35 112 016	Cylinder	1	40.	105 35 112 040	Washer	1
17.	105 35 112 017	Rotor Blade	4	41.	105 35 112 041	Washer	1
18.	105 35 112 018	Rotor	1	42.	105 35 112 042	Wave Washer	2
19.	105 35 112 019	Front End Plate	1	43.	105 35 112 043	Thrust Washer	1
20.	105 35 112 020	Ball Bearing	1	44.	105 35 112 044	Retainer Ring	1
21.	105 35 112 021	Internal Gear	1	45.	105 35 112 045	Comfort Grip	1
22.	105 35 112 022	Ball Bearing	2	46.	105 35 112 046	Roll Pin	1
23.	105 35 112 023	Bevel Gear	3	47.	105 35 112 047	Muffler	1
24.	105 35 112 024	Pin	3				