





NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	140 10 502 001	Hydraulic Section	1	38	140 10 502 038	Spring	1	79	140 10 502 079	Washer	5
2	140 10 502 002	O-ring	2	39	140 10 502 039	Nut	1	80	140 10 502 080	O-ring	10
3	140 10 502 003	Set Screw	1	40	140 10 502 040	Nut	1	81A	140 10 502 081	Swivel	1
4	140 10 502 004	Hydraulic Plunger	1	41	140 10 502 041	O-ring	1	81B	140 10 502 281	Cap	4
5	140 10 502 005	O-ring	2	43	140 10 502 043	Hexagon Bit	1	81C	140 10 502 381	Socket	1
6	140 10 502 006	Back-up Ring	2	44	140 10 502 044	Bolt Bushing	1	81D	140 10 502 481	Socket	3
7	140 10 502 007	O-ring	2	45	140 10 502 045	Adjustable Bushing	1	82A	140 10 502 082	Socket	1
8	140 10 502 008	Washer	1	46	140 10 502 046	Spring	1	82B	140 10 502 282	Washer	1
9	140 10 502 009	Shaft	1	47	140 10 502 047	Front Cap Nut	1	82C	140 10 502 382	O-ring	4
10	140 10 502 010	Ball Bearing	1	48	140 10 502 048	Set Screw	2	82D	140 10 502 482	Swivel	2
11	140 10 502 011	Gear Spindel	1	49	140 10 502 049	Nut	1	82E	140 10 502 582	Snap Ring	1
11-A	140 10 502 211	Position Guide	1	50	140 10 502 050	Front Cap	1	82F	140 10 502 682	Socket	1
12	140 10 502 012	Gear	3	51	140 10 502 051	Protection Sleeve	1	84	140 10 502 084	Set Screw	3
13	140 10 502 013	Ring Gear	1	54A	140 10 502 054	Hydraulic Tube Connector-b	1	86	140 10 502 086	Base	1
14	140 10 502 014	Ball Bearing	1	54B	140 10 502 254	O-ring	1	86A	140 10 502 286	Rubber Boot	1
15	140 10 502 015	Front End Plate	1	54D	140 10 502 354	Hydraulic Tube Connector-a	1	87	140 10 502 087	Bleeding Valve	2
16	140 10 502 016	Rotor	1	55	140 10 502 055	Nut	1	88	140 10 502 088	Valve Body	2
17	140 10 502 017	Rotor Blade	6	56	140 10 502 056	O-ring	1	89A	140 10 502 089	4x6 Puhose(Reverse)-orange	1
18	140 10 502 018	Cylinder	1	57	140 10 502 057	Upper Cover	1	89B	140 10 502 289	4x6 Puhose(Forward)-black	1
19	140 10 502 019	Pin	1	58	140 10 502 058	Nut	4	89C	140 10 502 389	6mm Hose Loop	2
20	140 10 502 020	Rear End Plate	1	61	140 10 502 061	O-ring	2	90A	140 10 502 090	2.5x4 Puhose(Reverse)-orange	1
21	140 10 502 021	Ball Bearing	1	62	140 10 502 062	Back-up Ring	2	90B	140 10 502 290	2.5x4 Puhose(Pull)-black	1
22	140 10 502 022	Motor Cage	1	65	140 10 502 065	Plunger Rod	1	91	140 10 502 091	Trigger	1
23	140 10 502 023	Seal	1	66	140 10 502 066	Bumper Ring	1	92	140 10 502 092	Plastic Grip-right	1
24	140 10 502 024	O-ring	1	67	140 10 502 067	Front Head Disc	1	93	140 10 502 093	Battery Cap	1
25	140 10 502 025	Muffler Cap	1	68	140 10 502 068	Packing Ring	1	94	140 10 502 094	Plastic Grip-left	1
26	140 10 502 026	Motor Valve Body	1	69	140 10 502 069	Lower Plate	1	95	140 10 502 095	Muffler Cap Holder	1
27	140 10 502 027	Ball Valve Ass'y	1	70	140 10 502 070	Air Cylinder Body	1	96	140 10 502 096	Muffler Cap	1
29	140 10 502 029	Spring	2	71	140 10 502 071	Set Screw	4	97	140 10 502 097	Washer	7
30	140 10 502 030	Set Screw	1	72	140 10 502 072	Valve Case	1	98	140 10 502 098	Screw	7
31	140 10 502 031	Hose Connector (4x6)	4	73	140 10 502 073	Valve Stem	2	99A	140 10 502 099	Hanger	1
32A	140 10 502 032	4x6 Puhose(Reverse)-orange	1	74	140 10 502 074	O-ring	2	99B	140 10 502 299	Hose Bind	1
32B	140 10 502 232	4x6 Puhose(Forward)-black	1	74A	140 10 502 274	O-ring	1	103	140 10 502 103	Oiler	1
33	140 10 502 033	Air Inlet Hose	2	75	140 10 502 075	O-ring	4	108A	140 10 502 108	5mm Hex. Wrench	1
34	140 10 502 034	O-ring	2	76	140 10 502 076	O-ring	2	108B	140 10 502 208	2mm Hex. Wrench	1
35	140 10 502 035	O-ring	2	77	140 10 502 077	Inlet Plug	1	109A	140 10 502 109	10x11 Wrench	1
36	140 10 502 036	Back-up Ring	2	77A	140 10 502 277	Socket Screw	2	109B	140 10 502 209	27x30 Wrench	1
37	140 10 502 037	O-ring	1	78	140 10 502 078	Inlet Plug	1	110	140 10 502 110	Air Inlet Assembly	1