



-SELF VACUUM





NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	141 10 607 001	Hydraulic Section	1	28E	141 10 607 528	Washer	1	59	141 10 607 059	Vacuum Switch	1
2	141 10 607 002	O-RING	2	29	141 10 607 029	O-RING	1	60	141 10 607 060	Set Screw	2
3	141 10 607 003	Back-Up Ring	2	30	141 10 607 030	Upper Cover	1	61	141 10 607 061	Washer	7
4	141 10 607 004	Nut	1	31	141 10 607 031	Nut	4	62	141 10 607 062	Screw	1
5	141 10 607 005	Jaw Housing Coupler (for Blind Rivet)	1	32	141 10 607 032	Air Cylinder Body	1	62A	141 10 607 262	Set Screw	4
6	141 10 607 006	O-RING	1	33	141 10 607 033	Set Screw	4	63	141 10 607 063	Valve Body	1
7	141 10 607 007	Spring	1	36	141 10 607 036	O-RING	2	64	141 10 607 064	Bleeding Valve	1
8	141 10 607 008	Jaw Pusher	1	37	141 10 607 037	Back-Up Ring	2	65	141 10 607 065	Trigger	1
9	141 10 607 009	Jaw	3	40	141 10 607 040	Plunger Rod	1	66	141 10 607 066	Plastic Grip-Right	1
10	141 10 607 010	Jaw Housing	1	41	141 10 607 041	Bumper Ring	1	67	141 10 607 067	Battery Cap	1
11	141 10 607 011	Lock Nut	1	42A	141 10 607 042	Front Head Disc A	1	68	141 10 607 068	Plastic Grip-Left	1
12	141 10 607 012	Head(for Blind Rivet)	1	42B	141 10 607 242	Front Head Disc B	1	68A	141 10 607 268	Set Screw	2
13	141 10 607 013	Hydraulic Plunger (5.6mm ID)	1	43	141 10 607 043	Packing Ring	1	70	141 10 607 070	Silencer	1
14	141 10 607 014	O-RING	2	44	141 10 607 044	Lower Plate	1	71	141 10 607 071	Muffler Seat	1
15	141 10 607 015	Back-Up Ring	2	45	141 10 607 045	Valve Case	1	72	141 10 607 072	Silencer	1
16	141 10 607 016	Return Spring	1	46	141 10 607 046	O-RING	2	73	141 10 607 073	Mandrel Collector	1
17	141 10 607 017	O-RING	2	47	141 10 607 047	Valve Stem	1	74	141 10 607 074	Muffler Cap	1
18	141 10 607 018	O-RING	1	48	141 10 607 048	O-RING	1	75	141 10 607 075	Deflector	1
19	141 10 607 019	Rear Gland	1	48A	141 10 607 248	O-RING	1	77	141 10 607 077	Multi-Wrench (A)	1
20	141 10 607 020	O-RING	1	49	141 10 607 049	O-RING	2	78	141 10 607 078	Multi-Wrench (B)	1
21	141 10 607 021	Set Screw	1	50	141 10 607 050	Inlet Plug	1	79	141 10 607 079	5mm Hex. Wrench	1
22	141 10 607 022	Hanger	1	50A	141 10 607 250	Socket Screw	1	80	141 10 607 080	Oiler	1
23	141 10 607 023	O-RING	8	51	141 10 607 051	Set Screw	3	81A	141 10 607 081	17x19 Wrench	2
24	141 10 607 024	Washer	6	52	141 10 607 052	Base	1	81B	141 10 607 281	19X21 Wrench	1
25	141 10 607 025	Socket	5	52A	141 10 607 252	Rubber Boot	1	82A	141 10 607 082	2.5x4 PU Hose(Black)	1
26	141 10 607 026	Cap	6	53	141 10 607 053	Vacuum Valve	1	82B	141 10 607 282	2.5x4 PU Hose(Orange)	1
27	141 10 607 027	Nut	1	54	141 10 607 054	Sleeve	1	82C	141 10 607 382	2.5x4 PU Hose(Orange)	1
28A	141 10 607 028	Hydraulic Tube Connector-B	1	55	141 10 607 055	O-RING	2	87	141 10 607 087	Nose Piece 5/16" (8mm)	1
28B	141 10 607 228	O-RING	1	56	141 10 607 056	Washer	1	89	141 10 607 089	Air Inlet Assembly	1
28C	141 10 607 328	Hydraulic Tube Washer	1	57	141 10 607 057	Swivel	1	90	141 10 607 090	Service Kit (opt.)(No.02.03.09.14.15.36.37.46.48.48A.49)	1
28D	141 10 607 428	Hydraulic Tube Connector-A	1	58	141 10 607 058	Socket	1				