



NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	146 08 309 001	Cylinder	1	27	146 08 309 027	Sleeve	1
2	146 08 309 002	Buffer	1	28	146 08 309 028	O-ring (37.82 x 1.78)	2
3	146 08 309 003	Nozzie	1	29	146 08 309 029	Filter	1
4	146 08 309 004	Lock ring (RB 20)	1	30	146 08 309 030	Cylinder	1
5	146 08 309 005	Piston	1	31	146 08 309 031	O-ring (22.1 x 1.6)	1
6	146 08 309 006	Main Valve Housing	1	32	146 08 309 032	Handle	1
7	146 08 309 007	Bearing Needle (2 x 9.8)	2	33	146 08 309 033	O-ring (25.1 x 1.6)	2
8	146 08 309 008	Main Valve	1	34	146 08 309 034	Push Button	1
9	146 08 309 009	Cover	1	35	146 08 309 035	Spring	1
10	146 08 309 010	Cup Spring	2	36	146 08 309 036	Lock Ring	1
11	146 08 309 011	Support Ring	1	37	146 08 309 037	O-ring (16.1 x 1.6)	1
12	146 08 309 012	O-ring (26.1 x 1.2)	1	38	146 08 309 038	Valve Sleeve	1
13	146 08 309 013	Circlip	1	39	146 08 309 039	O-ring (5.1 x 1.6)	1
14	146 08 309 014	Hand Guard	1	40	146 08 309 040	O-ring (13.1 x 1.6)	1
15	146 08 309 015	Nut	1	41	146 08 309 041	Valve Spindle	1
16	146 08 309 016	Retainer	1	42	146 08 309 042	O-ring (6.1 x 1.6)	1
17	146 08 309 017	Bearing Strip	1	43	146 08 309 043	O-ring (8.1 x 1.6)	1
18	146 08 309 018	Casing	1	44	146 08 309 044	Valve Cap	1
19	146 08 309 019	O-ring (37.82 x 1.78)	1	45	146 08 309 045	O-ring (12.1 x 1.6)	1
20	146 08 309 020	Exhaust Cover	1	46	146 08 309 046	Silencer	1
21	146 08 309 021	O-ring (32 x 2.4)	1	47	146 08 309 047	O-ring (17.3 x 2.4)	1
22	146 08 309 022	Ring	1	48	146 08 309 048	Adapter (1/4" NPT)	1
23	146 08 309 023	O-ring (8.1 x 1.6)	1	49	146 08 309 049	Plug (BSPT 3/8")	1
24	146 08 309 024	Piston	1	50	146 08 309 050	Flush Set Ø10.2mm	1
25	146 08 309 025	Spring	1				
26	146 08 309 026	O-ring (32 x 2.4)	1				