



NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
01.	146 35 203 001	Handle	1	12.	146 35 203 012	Trigger Button	1
02.	146 35 203 002	Throttle Seat	1	13.	146 35 203 013	Valve Stem	1
03.	146 35 203 003	Throttle Valve	1	14.	146 35 203 014	Valve	1
04.	146 35 203 004	Spring	1	15.	146 35 203 015	Valve Box	1
05.	146 35 203 005	Air Inlet	1	16.	146 35 203 016	Valve Pin	1
06.	146 35 203 006	O-Ring	1	17.	146 35 203 017	Piston	1
07.	146 35 203 007	Pin	1	18.	146 35 203 018	Cylinder	1
08.	146 35 203 008	O-Ring	1	19.	146 35 203 019	Clamp Cover	1
09.	146 35 203 009	Valve Bushing	1	20.	146 35 203 020	Retainer Spring	1
10.	146 35 203 010	O-Ring	1	21.	146 35 203 021	Comfort Grip	1
11.	146 35 203 011	Retaining Ring	1				