




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	151 07 110 001	MOTOR HOUSING	1	23	151 07 110 023	SPACER	1
2	151 07 110 002	MUFFLER CAP	2	24	151 07 110 024	PIN	2
3	151 07 110 003	O-RING	2	25	151 07 110 025	CLAMP NUT	1
4	151 07 110 004	TIP VALVE	1	26	151 07 110 026	BEVEL GEAR	1
5	151 07 110 005	SAFETY LEVER ASSEMBLY	1	27	151 07 110 027	ANGLE HEAD HOUSING	1
6	151 07 110 006	SPEED REG.	1	28	151 07 110 028	PINION	1
7	151 07 110 007	SEAL	1	29	151 07 110 029	GREASE FITTING	1
8	151 07 110 008	SPRING	1	30	151 07 110 030	KEY	1
9	151 07 110 009	VALVE STEM	1	31	151 07 110 031	SPINDLE	1
10	151 07 110 010	FELT MUFFLER	2	32	151 07 110 032	BALANCE WEIGHT	1
11	151 07 110 011	RETAINING RING	1	33	151 07 110 033	BEARING 686	2
12	151 07 110 012	INLET	1	34	151 07 110 034	PAD SEAT	1
13	151 07 110 013	O-RING	1	35	151 07 110 035	SANDING PAD	1
14	151 07 110 014	HOUSING LOCK RING	1	36	151 07 110 036	RUBBER COVER	1
15	151 07 110 015	O-RING	1	37	151 07 110 037	CLAMP	1
16	151 07 110 016	CYLINDER	1	38	151 07 110 038	INVERTED RETAINING RING	1
17	151 07 110 017	ROTOR	1	39	151 07 110 039	O-RING	1
18	151 07 110 018	BLADE	4	40	151 07 110 040	SCREW	1
19	151 07 110 019	BALL BEARING (696)	2	41	151 07 110 041	SCREW (M4*0.7)	1
20	151 07 110 020	REAR END PLATE	1	42	151 07 110 042	O-RING 15.46*2.62	1
21	151 07 110 021	FRONT END PLATE	1	43	151 07 110 043	PIN	1
22	151 07 110 022	BALL BEARING (608)	2				