




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
01	152 07 220 001	HOUSING	1	21	152 07 220 021	SPACER	1
02	152 07 220 002	CYLINDER	1	22	152 07 220 022	PIN(2*3.6)	3
03	152 07 220 003	REAR END PLATE	1	23	152 07 220 023	FLET	1
04	152 07 220 004	LILET	1	24	152 07 220 024	O-RING(7.8*1.9)	1
05	152 07 220 005	FELT MUFFLER	2	25	152 07 220 025	PIN(3*22)	1
06	152 07 220 006	INSULATOR COLLAR	1	26	152 07 220 026	HOUSING	1
07	152 07 220 007	MUFFLER CAP	2	27	152 07 220 027	BEADE	4
08	152 07 220 008	O-RING(31.47*1.78)	2	28	152 07 220 028	ADAPTER	1
09	152 07 220 009	TIP VALVE	1	29	152 07 220 029	ROTOR(1/4"-20)	1
10	152 07 220 010	SAFETY LEVER ASSEMBLY	1	30	152 07 220 030	FRONT BEARING PLATE	1
11	152 07 220 011	SPEED REG.	1	31	152 07 220 031	CAP	1
12	152 07 220 012	SEAL	1	32	152 07 220 032	GASKET	1
13	152 07 220 013	SPRING	1	33	152 07 220 033	LOCK NUT	1
14	152 07 220 014	VALVE STEM	1	34	152 07 220 034	INSERT	1
15	152 07 220 015	RETAINING RING(STW11)	1	35	152 07 220 035	SPANNER WRENCH(12MM)	1
16	152 07 220 016	O-RING(8.9*1.6)	1				
17	152 07 220 017	O-RING(2.6*1)	1				
18	152 07 220 018	O-RING(10.28*1.78)	1				
19	152 07 220 019	BEARING(696)	1				
20	152 07 220 020	BEARING(608)	1				