




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	153 02 350 001	Housing	1	21	153 02 350 021	Housing	1
2	153 02 350 002	Ball Bearing	1	22A	153 02 350 022	O-Ring	1
3	153 02 350 003	Rear End Plate	1	23A	153 02 350 023	Valve Stem	1
4	153 02 350 004	Rotor Blade	5	24A	153 02 350 024	O-Ring	1
5B	153 02 350 005	Rotor	1	26A	153 02 350 026	Air Controller	1
6	153 02 350 006	Cylinder	1	31	153 02 350 031	O-Ring	1
7	153 02 350 007	Spring Pin	2	32	153 02 350 032	Muffle	1
8	153 02 350 008	Front End Plate	1	33	153 02 350 033	Air Deflector	1
9	153 02 350 009	O-Ring	1	34A	153 02 350 034	Air Inlet	1
10	153 02 350 010	Ball Bearing	1	37	153 02 350 037	Handle	1
11	153 02 350 011	Pad Shaft 5/8"-11	1	38	153 02 350 038	Throttle Lever	1
11	153 02 350 211	Pad Shaft M14X2.0P	1	39	153 02 350 039	Spring Pin	1
11	153 02 350 311	Pad Shaft 5/16"-24	1	40A	153 02 350 040	Spanner	1
12	153 02 350 012	Ball Bearing	2	42	153 02 350 042	Pad Holder	1
13B	153 02 350 013	Gear Cage	1	44	153 02 350 044	Seal	1
14B	153 02 350 014	Gear	2	45	153 02 350 045	Valve Stem	1
16	153 02 350 016	Pin	2	46	153 02 350 046	Spring	1
17	153 02 350 017	O-Ring	1	47	153 02 350 047	O-Ring	1
18B	153 02 350 018	Internal Gear	1	48	153 02 350 048	Snap Ring	1
19	153 02 350 019	Gear Housing	1				
20	153 02 350 020	Lock Nut	1				