




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	154 04 421 001	Idle Pulley	1	36	154 04 421 036	Ball Bearing(6000zz)	1
2	154 04 421 002	Washer	1	37	154 04 421 037	Front End Plate	1
3	154 04 421 003	Bearing	2	38	154 04 421 038	Spacer	1
4	154 04 421 004	Idle Pulley Screw(M6×16)	1	39	154 04 421 039	Rotor	1
5	154 04 421 005	Tension Bar	1	40	154 04 421 040	Parallel Key Both Ends Round 4×4×9.5	1
6	154 04 421 006	E-Ring (E3)	1	41	154 04 421 041	Rotor Blade	5
7	154 04 421 007	Screw (M6×14)	1	42	154 04 421 042	Cylinder	1
8	154 04 421 008	Connecting rod	1	43	154 04 421 043	Rear End Plate	1
9	154 04 421 009	Pulley	1	44	154 04 421 044	Ball Bearing (608zz)	1
10	154 04 421 010	Pulley Screw	1	45	154 04 421 045	O-Ring(S38)	1
11	154 04 421 011	Spring Pin(Ø 3×16)	1	46	154 04 421 046	Cap	1
12	154 04 421 012	Screw(M4x8L)	1	47	154 04 421 047	Throttle Lever	1
13	154 04 421 013	Spring Washer	1	48	154 04 421 048	Spring Pin (Ø 3×20)	1
14	154 04 421 014	Washer	1	49	154 04 421 049	Valve Body	1
15	154 04 421 015	Ball Bearing (683ZZ)	2	50	154 04 421 050	O-Ring (S11.2)	1
16	154 04 421 016	Stopper Pin	1	51	154 04 421 051	O-Ring(P9)	1
17	154 04 421 017	Guard Bushing	1	52	154 04 421 052	O-Ring (ID3x1)	1
18	154 04 421 018	Tension Spring	1	53	154 04 421 053	Valve Stem	1
19	154 04 421 019	Guard Body	1	54	154 04 421 054	O-Ring (P3)	1
20	154 04 421 020	Head Cap Screw (M5×30)	1	55	154 04 421 055	Valve Spring	1
21	154 04 421 021	Dust Cover	1	56	154 04 421 056	Air Regulator	1
22	154 04 421 022	Stopper Spring	1	57	154 04 421 057	O-Ring (P7)	2
23	154 04 421 023	Stopper	1	58	154 04 421 058	External Stop Ring(STW-8)	1
24	154 04 421 024	Spring Pin(Ø 3×12)	1	59	154 04 421 059	Ring	1
25	154 04 421 025	Pan Head Screw(M6×10)	1	60	154 04 421 060	Muffle	1
26	154 04 421 026	Finger Plate	1	61	154 04 421 061	Exhaust Diffuser	1
27	154 04 421 027	Cap Screw(M5x10L)	2	62	154 04 421 062	Inlet Bushing	1
28	154 04 421 028	anti-slip spacer	1	63	154 04 421 063	Housing Cover	1
29	154 04 421 029	Pan Head Screw(M4×6)	1	64	154 04 421 064	Grinding Belt (#100×20)	1
30	154 04 421 030	Washer(M4)	1	65	154 04 421 065	Grinding Belt (#80×20)	1
31	154 04 421 031	Belt Cover	1	66	154 04 421 066	Hex. Wrench	1
32	154 04 421 032	Decorative Screw (M4×8)	1	67	154 04 421 067	Hex. Wrench	1
33	154 04 421 033	Hex. Nut M10	1	69	154 04 421 069	Shoe	1
34	154 04 421 034	Drive Pulley	1	70	154 04 421 070	Washer(M5)	1
35	154 04 421 035	Housing	1				