




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	161 02 140 001	Housing	1	21	161 02 140 021	O-Ring	1
2	161 02 140 002	Seal	1	22	161 02 140 022	Front End Plate	1
3	161 02 140 003	Regulator	1	23	161 02 140 023	Pin	2
4	161 02 140 004	O-Ring	1	24	161 02 140 024	Bearing	1
5	161 02 140 005	Valve stem	1	25	161 02 140 025	Washer	1
6	161 02 140 006	O-Ring	1	26	161 02 140 026	Rotor	1
7	161 02 140 007	O-Ring	1	27	161 02 140 027	Cover	1
8	161 02 140 008	Spring Ring	1	28	161 02 140 028	Blade	4
9	161 02 140 009	Throttle	1	29	161 02 140 029	Cylinder	1
10	161 02 140 010	Spring	1	30	161 02 140 030	Rear End Plate	1
11	161 02 140 011	Safety Lever	1	31	161 02 140 031	Bearing	1
12	161 02 140 012	Lever Pin	1	32	161 02 140 032	Collet Nut	1
13	161 02 140 013	Air Control Ring	1	33	161 02 140 033	Collet Holder	1
14	161 02 140 014	O-Ring	1	34	161 02 140 034	Collet (6mm)	1
15	161 02 140 015	Felt	1	34	161 02 140 234	Collet (1/4")	1
16	161 02 140 016	Rear Cap	1	35	161 02 140 035	Spanner	1
17	161 02 140 017	O-Ring	1	36	161 02 140 036	Spanner	1
18	161 02 140 018	Air Inlet	1				
19	161 02 140 019	Ring	1				
20	161 02 140 020	Spacer	1				