




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	161 02 160 001	Housing	1	21	161 02 160 021	O-Ring	1
2	161 02 160 002	Seal	1	22	161 02 160 022	Bearing	1
3	161 02 160 003	Regulator	1	23	161 02 160 023	Pin	2
4	161 02 160 004	O-Ring	1	24	161 02 160 024	Rear End Plate	1
5	161 02 160 005	Valve stem	1	25	161 02 160 025	Cylinder	1
6	161 02 160 006	O-Ring	1	26	161 02 160 026	Blade	4
7	161 02 160 007	O-Ring	1	27	161 02 160 027	Rotor	1
8	161 02 160 008	Spring Ring	1	28	161 02 160 028	Washer	1
9	161 02 160 009	Throttle	1	29	161 02 160 029	Front End Plate	1
10	161 02 160 010	Spring	1	30	161 02 160 030	Bearing	1
11	161 02 160 011	Safety Lever	1	31	161 02 160 031	Block Plate	1
12	161 02 160 012	Lever Pin	1	32	161 02 160 032	Cover	1
13	161 02 160 013	Air Control Ring	1	33	161 02 160 033	Rotor Nut	1
14	161 02 160 014	O-Ring	1	34	161 02 160 034	Collet Holder	1
15	161 02 160 015	Felt	1	35	161 02 160 035	Collet (6mm)	1
16	161 02 160 016	Rear Cap	1	35	161 02 160 235	Collet (1/4")	1
17	161 02 160 017	O-Ring	1	36	161 02 160 036	Collet Nut	1
18	161 02 160 018	Air Inlet	1	37	161 02 160 037	Spanner	2
19	161 02 160 019	Ring	1				
20	161 02 160 020	Spacer	1				