




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	161 02 161 001	Housing	1	21	161 02 161 021	O-Ring	1
1A	161 02 161 201	Insert	1	22	161 02 161 022	Lock Nut	1
2	161 02 161 002	Seal	1	23	161 02 161 023	Motor Housing	1
3	161 02 161 003	Regulator	1	24	161 02 161 024	O-Ring	1
4	161 02 161 004	O-Ring	1	25	161 02 161 025	Bearing	1
5	161 02 161 005	Valve stem	1	26	161 02 161 026	Rear End Plate	1
6	161 02 161 006	O-Ring	1	27	161 02 161 027	Pin	2
7	161 02 161 007	O-Ring	1	28	161 02 161 028	Cylinder	1
8	161 02 161 008	Spring Ring	1	29	161 02 161 029	Blade	5
9	161 02 161 009	Throttle	1	30	161 02 161 030	Rotor	1
10	161 02 161 010	Spring	1	31	161 02 161 031	Washer	1
11	161 02 161 011	Safety Lever	1	32	161 02 161 032	Front End Plate	1
12	161 02 161 012	Lever Pin	1	33	161 02 161 033	Bearing	1
13	161 02 161 013	Air Control Ring	1	34	161 02 161 034	Felt	1
14	161 02 161 014	O-Ring	1	35	161 02 161 035	Cover	1
15	161 02 161 015	Felt	1	36	161 02 161 036	Washer	1
16	161 02 161 016	Rear Cap	1	37	161 02 161 037	Collet Holder	1
17	161 02 161 017	O-Ring	1	38	161 02 161 038	Collet (6mm)	1
18	161 02 161 018	Air Inlet	1	38	161 02 161 238	Collet (1/4")	1
19	161 02 161 019	Ring	1	39	161 02 161 039	Collet Nut	1
20	161 02 161 020	Spacer	1	40	161 02 161 040	Spanner	2