




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	162 35 130 001	Air Inlet	1	17	162 35 130 017	Spacer	1
2	162 35 130 002	Spring	1	18	162 35 130 018	Front End Plate	1
3	162 35 130 003	Throttle Valve Handle	1	19	162 35 130 019	Ball Bearing	1
4	162 35 130 004	O-ring	1	20	162 35 130 020	Spindle Connector	1
5	162 35 130 005	Air Regulator	1	21	162 35 130 021	Bushing	1
6	162 35 130 006	Spring	1	22	162 35 130 022	Housing	1
7	162 35 130 007	Pin	1	23	162 35 130 023	Spindle Connector	1
8	162 35 130 008	Pin	1	24	162 35 130 024	Ball Bearing	1
9	162 35 130 009	Housing Cover	1	25	162 35 130 025	Spindle	1
10	162 35 130 010	Governor	1	26	162 35 130 026	Ball Bearing	1
11	162 35 130 011	Ball Bearing	1	27	162 35 130 027	Needle Bearing	1
12	162 35 130 012	Rear End Plate	1	28	162 35 130 028	Lock Washer	1
13	162 35 130 013	Roll Pin	1	29	162 35 130 029	Washer	1
14	162 35 130 014	Cylinder	1	30	162 35 130 030	Hex. Nut	2
15	162 35 130 015	Rotor Blade	5	31	162 35 130 031	Lock Nut	1
16	162 35 130 016	Rotor	1	32	162 35 130 032	Guard	1