




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	162 60 140 001	Wheel Guard	1	31	162 60 140 031	Cylinder Upper Plate	1
2	162 60 140 002	Nut	1	32	162 60 140 032	Ball Bearing	1
3	162 60 140 003	Nut	1	33	162 60 140 033	Governor Cage	1
4	162 60 140 004	Wheel Flange (B)	1	34	162 60 140 034	Governor Weight	2
5	162 60 140 005	Hexagon Bolt	1	35	162 60 140 035	Governor Pin	2
6	162 60 140 006	Spring Washer	1	36	162 60 140 036	Governor Valve	1
7	162 60 140 007	Nut	1	37	162 60 140 037	Governor Valve Spring	1
8	162 60 140 008	Snap Ring	1	38	162 60 140 038	Adjusting Washer (T=0.2)	1
9	162 60 140 009	Wheel Flange (A)	1	38	162 60 140 238	Adjusting Washer (T=0.3)	1
10	162 60 140 010	Felt Ring	1	38	162 60 140 338	Adjusting Washer (T=0.5)	1
11	162 60 140 011	Spindle Bearing Cover	1	39	162 60 140 039	Governor Valve Spring Holder	1
12	162 60 140 012	Needle Bearing	1	40	162 60 140 040	Needle Roller	1
13	162 60 140 013	Inner Race	1	41	162 60 140 041	Bushing	1
14	162 60 140 014	Exhaust Cover	1	42	162 60 140 042	Housing Cover	1
15	162 60 140 015	Spring Washer	1	43	162 60 140 043	Needle Roller	1
16	162 60 140 016	Cap Screw	1	44	162 60 140 044	Throttle Valve Handle Spring	1
17	162 60 140 017	Housing	1	45	162 60 140 045	Throttle Valve	1
18	162 60 140 018	Key	1	46	162 60 140 046	O-Ring	1
19	162 60 140 019	Wheel Spindle	1	47	162 60 140 047	Throttle Valve Handle	1
20	162 60 140 020	Ball Bearing	1	48	162 60 140 048	Throttle Valve Spring	1
21	162 60 140 021	Snap Ring	1	49	162 60 140 049	Strainer	1
22	162 60 140 022	Spacer	1	50	162 60 140 050	Throttle Valve Cover (PT)	1
23	162 60 140 023	Coupling	1	51	162 60 140 051	Cup Nut	1
24	162 60 140 024	Ball Bearing	1	69	162 60 140 069	Exhaust Hose Joint (Opt. Part)	1
25	162 60 140 025	Cylinder Lower Plate	1				1
26	162 60 140 026	Cylinder	1				
27	162 60 140 027	Spring Pin	1				
28	162 60 140 028	Key	1				
29	162 60 140 029	Rotor Blade	4				
30	162 60 140 030	Rotor	1				