




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	162 60 220 001	Wheel Flange (B)	1	26	162 60 220 026	Bearing Cover	1
2	162 60 220 002	Wheel Flange (A)	1	27	162 60 220 027	Ball	1
3	162 60 220 003	Spindle Bearing Cover	1	28	162 60 220 028	Knock Spring	1
4	162 60 220 004	Ball Bearing(6001)	1	29	162 60 220 029	Housing Cover	1
5	162 60 220 005	Wheel Spindle Washer	1	30	162 60 220 030	Needle Roller	1
6	162 60 220 006	Bevel Gear	1	31	162 60 220 031	Throttle Valve	1
7	162 60 220 007	Wheel Spindle	1	32	162 60 220 032	Grip	1
8	162 60 220 008	Ball Bearing(605)	1	33	162 60 220 033	Throttle Valve Spring	1
9	162 60 220 009	Bearing Washer	1	34	162 60 220 034	Throttle Valve Cover (PT)	1
10	162 60 220 010	Housing	1	35	162 60 220 035	Spring Pin	1
11	162 60 220 011	Cap Screw	2	36	162 60 220 036	Throttle Valve Lever	1
12	162 60 220 012	Spring Washer	2	37	162 60 220 037	Safety Lock	1
13	162 60 220 013	Wheel Guard	1	38	162 60 220 038	Safety Lock Spring	1
14	162 60 220 014	O-Ring	1	39	162 60 220 039	Spring Pin	1
15	162 60 220 015	Bevel Pinion	1	40	162 60 220 040	Throttle Valve Bushing	1
16	162 60 220 016	Key	1	41	162 60 220 041	Housing Cover	1
17	162 60 220 017	Ball Bearing(608)	1	42	162 60 220 042	Cup Nut	1
18	162 60 220 018	Bearing Case	1	43	162 60 220 043	Housing Cover Gasket	1
19	162 60 220 019	Cylinder Lower Plate	1	44	162 60 220 044	Inlet Bushing	1
20	162 60 220 020	Rotor	1	45	162 60 220 045	Throttle Valve Body	1
21	162 60 220 021	Rotor Blade	4	46	162 60 220 046	Throttle Valve Rod	1
22	162 60 220 022	Cylinder	1	47	162 60 220 047	O-Ring	1
23	162 60 220 023	Spring Pin	1	48	162 60 220 048	Throttle Valve Spring	1
24	162 60 220 024	Cylinder Upper Plate	1	49	162 60 220 049	Throttle Valve Cover Gasket	1
25	162 60 220 025	Ball Bearing(606)	1	50	162 60 220 050	Throttle Valve Cover	1