




| NO. | PART NO.       | DESCRIPTION                  | Qty | NO. | PART NO.       | DESCRIPTION                  | Qty |
|-----|----------------|------------------------------|-----|-----|----------------|------------------------------|-----|
| 1   | 162 60 250 001 | Bolt                         | 1   | 40  | 162 60 250 040 | Bottom Head Cap Screw        | 2   |
| 2   | 162 60 250 002 | Wheel Guard                  | 1   | 41  | 162 60 250 041 | Spring Washer                | 2   |
| 3   | 162 60 250 003 | Spring Washer                | 1   | 42  | 162 60 250 042 | Exhaust Cover Holder         | 1   |
| 4   | 162 60 250 004 | Nut                          | 1   | 43  | 162 60 250 043 | O-Ring                       | 1   |
| 5   | 162 60 250 005 | Detent Bolt                  | 1   | 44  | 162 60 250 044 | Exhaust Cover                | 1   |
| 6   | 162 60 250 006 | Wheel Flange (B)             | 1   | 45  | 162 60 250 045 | Muffler Plate Holder         | 1   |
| 7   | 162 60 250 007 | Wheel Flange (A)             | 1   | 46  | 162 60 250 046 | Muffler Spring               | 1   |
| 8   | 162 60 250 008 | Felt Ring                    | 1   | 47  | 162 60 250 047 | Muffler Plate                | 1   |
| 9   | 162 60 250 009 | Spindle Bearing Cover        | 1   | 48  | 162 60 250 048 | Strainer                     | 1   |
| 10  | 162 60 250 010 | O-Ring                       | 1   | 49  | 162 60 250 049 | Muffler Pad                  | 1   |
| 11  | 162 60 250 011 | Ball Bearing                 | 1   | 50  | 162 60 250 050 | Spring Pin                   | 1   |
| 12  | 162 60 250 012 | Bearing Washer               | 1   | 51  | 162 60 250 051 | Housing                      | 1   |
| 13  | 162 60 250 013 | Wheel Spindle Washer         | 1   | 52  | 162 60 250 052 | Bushing                      | 1   |
| 14  | 162 60 250 014 | Bevel Gear                   | 1   | 53  | 162 60 250 053 | Housing Cover                | 1   |
| 15  | 162 60 250 015 | Wheel Spindle                | 1   | 54  | 162 60 250 054 | Needle Roller                | 1   |
| 16  | 162 60 250 016 | Ball Bearing                 | 1   | 55  | 162 60 250 055 | Throttle Valve Handle Spring | 1   |
| 17  | 162 60 250 017 | Bearing Washer               | 1   | 56  | 162 60 250 056 | Needle Roller                | 1   |
| 18  | 162 60 250 018 | Ring                         | 1   | 57  | 162 60 250 057 | O-Ring                       | 1   |
| 19  | 162 60 250 019 | Bevel Pinion                 | 1   | 58  | 162 60 250 058 | Throttle Valve               | 1   |
| 20  | 162 60 250 020 | Ball Bearing                 | 1   | 59  | 162 60 250 059 | Throttle Valve handle        | 1   |
| 21  | 162 60 250 021 | Cylinder Lower Plate         | 1   | 60  | 162 60 250 060 | Throttle Valve Spring        | 1   |
| 22  | 162 60 250 022 | Key                          | 1   | 61  | 162 60 250 061 | Strainer                     | 1   |
| 23  | 162 60 250 023 | Rotor                        | 1   | 62  | 162 60 250 062 | Throttle Valve Cover (PT)    | 1   |
| 24  | 162 60 250 024 | Rotor Blade                  | 4   | 63  | 162 60 250 063 | Cup Nut                      | 1   |
| 25  | 162 60 250 025 | Cylinder                     | 1   | 64  | 162 60 250 064 | Housing Cover                | 1   |
| 26  | 162 60 250 026 | Spring Pin                   | 1   | 65  | 162 60 250 065 | O-Ring                       | 1   |
| 27  | 162 60 250 027 | Cylinder Upper Plate         | 1   | 66  | 162 60 250 066 | Cup Nut                      | 1   |
| 28  | 162 60 250 028 | Ball Bearing                 | 1   | 67  | 162 60 250 067 | Throttle Valve Body          | 1   |
| 29  | 162 60 250 029 | Grooved Pin                  | 2   | 68  | 162 60 250 068 | Safety Lock Spring           | 1   |
| 30  | 162 60 250 030 | Governor Weight              | 2   | 69  | 162 60 250 069 | Safety Lock                  | 1   |
| 31  | 162 60 250 031 | Governor Cage                | 1   | 70  | 162 60 250 070 | Spring Pin                   | 1   |
| 32  | 162 60 250 032 | Governor Valve               | 1   | 71  | 162 60 250 071 | Throttle Valve Lever         | 1   |
| 33  | 162 60 250 033 | Governor Valve Spring        | 1   | 72  | 162 60 250 072 | Spring Pin                   | 1   |
| 34  | 162 60 250 034 | Adjusting Washer (T=0.2)     | 1   | 73  | 162 60 250 073 | Throttle Valve Cover         | 1   |
| 34  | 162 60 250 234 | Adjusting Washer (T=0.3)     | 1   | 74  | 162 60 250 074 | Throttle Valve Cover Gasket  | 1   |
| 34  | 162 60 250 334 | Adjusting Washer (T=0.5)     | 1   | 75  | 162 60 250 075 | Throttle Valve Spring        | 1   |
| 35  | 162 60 250 035 | Governor Valve Spring Holder | 1   | 76  | 162 60 250 076 | Throttle Valve               | 1   |
| 36  | 162 60 250 036 | Needle Roller                | 1   | 77  | 162 60 250 077 | Throttle Valve Rod           | 1   |
| 37  | 162 60 250 037 | Dead Handle                  | 1   | 78  | 162 60 250 078 | Throttle Valve Rod Bushing   | 1   |
| 38  | 162 60 250 038 | Dead Handle Joint            | 1   | 79  | 162 60 250 079 | Inlet Bushing (PT)           | 1   |
| 39  | 162 60 250 039 | Conical Spring Washer        | 1   |     |                |                              |     |