




| NO. | PART NO.       | DESCRIPTION                  | Qty | NO. | PART NO.       | DESCRIPTION                     | Qty |
|-----|----------------|------------------------------|-----|-----|----------------|---------------------------------|-----|
| 1   | 162 60 270 001 | Hexagon Bolt                 | 1   | 42  | 162 60 270 042 | Governor Weight                 | 2   |
| 2   | 162 60 270 002 | Wheel Guard                  | 1   | 43  | 162 60 270 043 | Governor Cage                   | 1   |
| 3   | 162 60 270 003 | Spring Washer                | 1   | 44  | 162 60 270 044 | Governor Shaft                  | 1   |
| 4   | 162 60 270 004 | Nut                          | 1   | 45  | 162 60 270 045 | Governor Valve                  | 1   |
| 5   | 162 60 270 005 | Cap Screw                    | 1   | 46  | 162 60 270 046 | Governor Valve Spring(16260270) | 1   |
| 6   | 162 60 270 006 | Wheel Flange (B)             | 1   | 46  | 162 60 270 246 | Governor Valve Spring(16260271) | 1   |
| 7   | 162 60 270 007 | Wheel Flange (A)             | 1   | 47  | 162 60 270 047 | Adjusting Washer (T=0.2)        | 1   |
| 8   | 162 60 270 008 | Spacer                       | 1   | 47  | 162 60 270 247 | Adjusting Washer (T=0.3)        | 1   |
| 9   | 162 60 270 009 | Spindle Bearing Cover        | 1   | 47  | 162 60 270 347 | Adjusting Washer (T=0.5)        | 1   |
| 10  | 162 60 270 010 | O-Ring                       | 1   | 48  | 162 60 270 048 | Governor Valve Spring Holder    | 1   |
| 11  | 162 60 270 011 | Ball Bearing                 | 1   | 49  | 162 60 270 049 | Needle Roller                   | 1   |
| 12  | 162 60 270 012 | Bearing Washer               | 1   | 50  | 162 60 270 050 | Bushing                         | 1   |
| 13  | 162 60 270 013 | Wheel Spindle Washer (T=0.2) | 1   | 51  | 162 60 270 051 | Housing Cover                   | 1   |
| 13  | 162 60 270 213 | Wheel Spindle Washer (T=0.3) | 1   | 52  | 162 60 270 052 | Needle Roller                   | 1   |
| 13  | 162 60 270 313 | Wheel Spindle Washer (T=0.5) | 1   | 53  | 162 60 270 053 | Throttle Valve Handle Spring    | 1   |
| 14  | 162 60 270 014 | Bevel Gear                   | 1   | 54  | 162 60 270 054 | Needle Roller                   | 1   |
| 15  | 162 60 270 015 | Wheel Spindle                | 1   | 55  | 162 60 270 055 | O-Ring                          | 1   |
| 16  | 162 60 270 016 | Ball Bearing                 | 1   | 56  | 162 60 270 056 | Throttle Valve                  | 1   |
| 17  | 162 60 270 017 | Bearing Holder               | 1   | 57  | 162 60 270 057 | Throttle Valve Handle           | 1   |
| 18  | 162 60 270 018 | Dead Handle                  | 1   | 58  | 162 60 270 058 | Throttle Valve Spring           | 1   |
| 19  | 162 60 270 019 | Dead Handle Joint            | 1   | 59  | 162 60 270 059 | Strainer                        | 1   |
| 20  | 162 60 270 020 | Conical Spring Washer        | 1   | 60  | 162 60 270 060 | Throttle Valve Cover (PT)       | 1   |
| 21  | 162 60 270 021 | Cap Screw                    | 2   | 61  | 162 60 270 061 | Cup Nut                         | 1   |
| 22  | 162 60 270 022 | Spring Washer                | 2   | 62  | 162 60 270 062 | Cap Screw                       | 2   |
| 23  | 162 60 270 023 | Exhaust Cover Holder         | 1   | 63  | 162 60 270 063 | Spring Washer                   | 2   |
| 24  | 162 60 270 024 | O-Ring                       | 1   | 64  | 162 60 270 064 | Washer                          | 1   |
| 25  | 162 60 270 025 | Exhaust Cover                | 1   | 65  | 162 60 270 065 | Housing Cover                   | 1   |
| 26  | 162 60 270 026 | Muffler Pad                  | 1   | 66  | 162 60 270 066 | Cup Nut                         | 1   |
| 27  | 162 60 270 027 | Housing                      | 1   | 67  | 162 60 270 067 | Set Screw                       | 1   |
| 28  | 162 60 270 028 | Ring                         | 1   | 68  | 162 60 270 068 | Lock Key                        | 1   |
| 29  | 162 60 270 029 | Bevel Pinion                 | 1   | 69  | 162 60 270 069 | O-Ring                          | 1   |
| 30  | 162 60 270 030 | Ball Bearing                 | 1   | 70  | 162 60 270 070 | Lock Spring                     | 1   |
| 31  | 162 60 270 031 | Cylinder Lower Plate         | 1   | 71  | 162 60 270 071 | Throttle Valve Lever            | 1   |
| 32  | 162 60 270 032 | Key                          | 1   | 72  | 162 60 270 072 | Grooved Pin                     | 1   |
| 33  | 162 60 270 033 | Rotor                        | 1   | 73  | 162 60 270 073 | Throttle Valve Body             | 1   |
| 34  | 162 60 270 034 | Rotor Blade                  | 4   | 74  | 162 60 270 074 | Throttle Valve Rod Bushing      | 1   |
| 35  | 162 60 270 035 | Cylinder                     | 1   | 75  | 162 60 270 075 | Throttle Valve Rod              | 1   |
| 36  | 162 60 270 036 | Spring Pin                   | 1   | 76  | 162 60 270 076 | Throttle Valve                  | 1   |
| 37  | 162 60 270 037 | Cylinder Upper Plate         | 1   | 77  | 162 60 270 077 | Throttle Valve Washer           | 1   |
| 38  | 162 60 270 038 | Ball Bearing                 | 1   | 78  | 162 60 270 078 | Sub Throttle Valve              | 1   |
| 39  | 162 60 270 039 | Bearing Cover                | 1   | 79  | 162 60 270 079 | Throttle Valve Spring           | 1   |
| 40  | 162 60 270 040 | Nut                          | 2   | 80  | 162 60 270 080 | Inlet Bushing (PT)              | 1   |
| 41  | 162 60 270 041 | Grooved Pin                  | 2   |     |                |                                 |     |