




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	170 04 322 001	Drill Chuck(1/4")	1	19	170 04 322 019	Ball Bearing	1
2	170 04 322 002	Washer	1	20	170 04 322 020	Housing	1
3	170 04 322 003	Gear Case Cap	1	21	170 04 322 021	Trigger	1
4	170 04 322 004	Ball Bearing(6002ZZ)	2	22	170 04 322 022	Trigger Sleeve	1
5	170 04 322 005	Gear Carrier	1	23	170 04 322 023	O-Ring (ID7.65x1.78)	1
6	170 04 322 006	Pin(Ø4x12.8)	3	24	170 04 322 024	Retaining Ring	1
7	170 04 322 007	Needle Bearing (INA)	3	25	170 04 322 025	Housing Cover	1
8	170 04 322 008	Planet Gear	3	26	170 04 322 026	Spring Pin (Ø2x20)	1
9	170 04 322 009	Gear Case	1	27	170 04 322 027	Washer	1
10	170 04 322 010	Grease Fitting	1	28	170 04 322 028	Pin Valve Rod	1
12	170 04 322 012	Ball Bearing	1	29	170 04 322 029	Trigger Spring	1
13	170 04 322 013	Front End Plate	1	30	170 04 322 030	O-Ring (ID15x2)	1
14	170 04 322 014	Cylinder	1	31	170 04 322 031	Exhaust Cap	1
15	170 04 322 015	Spring Pin (Ø2x6)	1	32	170 04 322 032	Air Inlet	1
16	170 04 322 016	Rotor	1	33	170 04 322 033	Silencer Pad	4
17	170 04 322 017	Rotor Blade	5	34	170 04 322 034	Key(KK-1/4")	1
18	170 04 322 018	Rear End Plate	1				