




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	170 35 740 001	Housing	1	27	170 35 740 027	Gear	2
2	170 35 740 002	Throttle Valve Bushing	1	28	170 35 740 028	Needle Bearing	2
3	170 35 740 003	O-Ring	2	29	170 35 740 029	Pin	2
4	170 35 740 004	O-Ring	1	30	170 35 740 030	Gear Carrier	1
5	170 35 740 005	O-Ring	1	31	170 35 740 031	Ball Bearing	1
6	170 35 740 006	Throttle Pin	1	32	170 35 740 032	Grease Fitting	1
7	170 35 740 007	Spring	1	33	170 35 740 033	Connector	1
8	170 35 740 008	Air Regulator	1	34	170 35 740 034	Lock Nut	1
9	170 35 740 009	O-Ring	2	35	170 35 740 035	Lock Ring	1
10	170 35 740 010	O-Ring	1	36	170 35 740 036	Ball Bearing	1
11	170 35 740 011	Valve Plug	1	37	170 35 740 037	Spindle	1
12	170 35 740 012	Safety Throttle Lever	1	38	170 35 740 038	Nose Housing	1
13	170 35 740 013	Pin	1	39	170 35 740 039	Ball Bearing	2
14	170 35 740 014	Air Inlet	1	40	170 35 740 040	Bevel Gear Shaft w/Ball Bearing	1
15	170 35 740 015	Ball Bearing	1	41	170 35 740 041	Grease Fitting	1
16	170 35 740 016	Rear End Plate	1	42	170 35 740 042	Angle Housing	1
17	170 35 740 017	Rotor	1	43	170 35 740 043	Felt Plate	1
18	170 35 740 018	Rotor Blade	5	44	170 35 740 044	Bevel Gear	1
19	170 35 740 019	Cylinder	1	45	170 35 740 045	Ball Bearing	1
20	170 35 740 020	Spindle Collar	1	46	170 35 740 046	Lock Ring	1
21	170 35 740 021	Steel Ball	3	47	170 35 740 047	Felt	1
22	170 35 740 022	Front End Plate	1	48	170 35 740 048	Silencer	1
23	170 35 740 023	Ball Bearing	1	49	170 35 740 049	Hub Rod	1
24	170 35 740 024	Bearing Cover	1	50	170 35 740 050	Comfort Grip	1
25	170 35 740 025	Ball Bearing	1	51	990 35 290 051	Collet set (Option)	1
26	170 35 740 026	Internal Gear	1				