




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	171 04 310 001	Wheel Cover	1	21	171 04 310 021	Spring Pin (Ø 3×20)	1
2	171 04 310 002	Cap Screw	1	22	171 04 310 022	Valve Body	1
3	171 04 310 003	Screw(M6×12)	1	23	171 04 310 023	O-Ring (S11.2)	1
4	171 04 310 004	Spacer	1	24	171 04 310 024	O-Ring(P9)	1
5	171 04 310 005	Wheel	1	25	171 04 310 025	O-Ring (ID3x1)	1
6	171 04 310 006	Power Shaft	1	26	171 04 310 026	Valve Stem	1
7	171 04 310 007	Clamp Nut	1	27	171 04 310 027	O-Ring (P3)	1
8	171 04 310 008	Set Screw(M5x5)	2	28	171 04 310 028	Valve Spring	1
9	171 04 310 009	Housing	1	29	171 04 310 029	Air Regulator	1
10	171 04 310 010	Ball Bearing(6000ZZ)	1	30	171 04 310 030	O-Ring (P7)	2
11	171 04 310 011	Front End Plate	1	31	171 04 310 031	External Stop Ring (STW-8)	1
12	171 04 310 012	Spacer	1	32	171 04 310 032	Ring	1
13	171 04 310 013	Rotor	1	33	171 04 310 033	Exhaust Diffuser	1
14	171 04 310 014	Rotor Blade	5	34	171 04 310 034	Inlet Bushing	1
15	171 04 310 015	Cylinder	1	35	171 04 310 035	Housing Cover	1
16	171 04 310 016	Rear End Plate	1	36	171 04 310 036	(#14)Spanner Wrench	1
17	171 04 310 017	Ball Bearing (608zz)	1	37	171 04 310 037	Hatted Wrench (M5)	1
18	171 04 310 018	O-Ring(S38)	1	38	171 04 310 038	Hatted Wrench (M4)	1
19	171 04 310 019	Cap	1	39	171 04 310 039	Muffle	1
20	171 04 310 020	Throttle Lever Ass'y	1				