




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
1	171 35 410 001	Housing	1	25	171 35 410 025	Ball Bearing	1
2	171 35 410 002	Throttle Valve Bushing	1	26	171 35 410 026	Gear Shaft	1
3	171 35 410 003	O-Ring	2	27	171 35 410 027	Ball Bearing	1
4	171 35 410 004	O-Ring	2	28	171 35 410 028	Bevel Gear Shaft (15T)	1
5	171 35 410 005	Throttle Pin	1	29	171 35 410 029	Bushing	1
6	171 35 410 006	Spring	1	30	171 35 410 030	Housing Cap	1
7	171 35 410 007	Air Regulator	1	31	171 35 410 031	Lock Nut	1
8	171 35 410 008	O-Ring	1	32	171 35 410 032	Grease Fitting	1
9	171 35 410 009	O-Ring	1	33	171 35 410 033	Angle Housing	1
10	171 35 410 010	Valve Plug	1	34	171 35 410 034	Ball Bearing	1
11	171 35 410 011	Safety Throttle Lever	1	35	171 35 410 035	Bevel Gear (19T)	1
12	171 35 410 012	Pin	1	36	171 35 410 036	Spindle Chuck	1
13	171 35 410 013	Air Inlet	1	37	171 35 410 037	Ball Bearing	1
14	171 35 410 014	Exhaust Swivel	1	38	171 35 410 038	Clamp Nut	1
15	171 35 410 015	Silencer	1	39	171 35 410 039	Clamp Spindle Nut	1
16	171 35 410 016	Ball Bearing	1	40	171 35 410 040	Hex Screw	1
17	171 35 410 017	Rear End Plate	1	41	171 35 410 041	Wheel Guard (4")	1
18	171 35 410 018	Roll Pin	2	42	171 35 410 042	Screw	1
19	171 35 410 019	Rotor	1	43	171 35 410 043	Motor lock	1
20	171 35 410 020	Rotor Blade	4	44	171 35 410 044	Retaining ring	1
21	171 35 410 021	Spacer	1	45	171 35 410 045	Comfort Grip	1
22	171 35 410 022	Cylinder	1	46	171 35 410 046	Spanner 19mm	1
23	171 35 410 023	Steel Ball	1	47	171 35 410 047	Screw	1
24	171 35 410 024	Front End Plate	1	48	171 35 410 048	Hex. Spanner 5mm	1