




E-Transit jacking points

(WSM 100-02 & Owners Manual)



Position the head of the vehicle jack on the bolted body brackets .



Position the head of the vehicle jack under the outer bush of the suspension arm.