


UPS Ford Battery Removal

Car shown Ford CNG Agility build

Job# 19-80 P120

Asset# 170646



1. Disconnect battery and brackets.



**2. Remove vinyl wrap by sliding up.
(it is not attached to tray or body).**



3. Slide battery forward, up and out.