



Circuit Diagrams Scrambler 1200 XC, Scrambler 1200 XE

This document is protected by copyright and may not, in whole or part be stored in a retrieval system, or transmitted in any form or by any means, copied, photocopied, translated or reduced to any machine-readable form without prior consent in writing from Triumph Motorcycles Limited.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Triumph Motorcycles Limited reserves the right to make changes and alter specifications without prior notice and without incurring an obligation to make such changes to products manufactured previously. See your authorised Triumph dealer for the latest information on product improvements incorporated after this publication.

All information contained in this publication is based on the latest product information available at the time of publication. Illustrations in this publication are intended for reference use only and may not depict actual model component parts.

© Triumph Motorcycles Ltd. 01.2019 Issue 1


This page intentionally left blank

TABLE OF CONTENTS


Circuit Diagrams	Page
1 - Power Distribution Circuit	4
2 - Keyless Control Circuit	5
3 - Ignition Circuit	6
4 - ABS Circuit	7
5 - Engine Management Circuit - Power Distribution, CAN	8
6 - Engine Management Circuit - Throttle Control Sensors	9
7 - Engine Management Circuit - Sensors Network	10
8 - Engine Management Circuit - Coils, Injectors, Heater, Purge	11
9 - Engine Management Circuit - Relay Management	12
10 - Brake Circuit	13
11 - Lighting Circuit - Front	14
12 - Lighting Circuit - Rear - Standard	15
13 - Lighting Circuit - Rear - Multifunctional	16
14 - Rider Information and Controls Circuit	17
15 - Heated Grips Circuit	18
16 - Horn Circuit	19
17 - CAN and LIN Circuit	20
18 - Auxiliary Connection Circuit	21
19 - Alarm Circuit	22
20 - Diagnostic Connector Circuit	23
21 - Earth Circuit - 01	24
22 - Earth Circuit - 02	25
23 - Earth Circuit - 03	26

ELECTRICAL CIRCUIT

01 - POWER DISTRIBUTION CIRCUIT




02 - KEYLESS CONTROL CIRCUIT




◀BACK

ELECTRICAL CIRCUIT

03 - IGNITION CIRCUIT




04 - ABS CIRCUIT




BACK

ELECTRICAL CIRCUIT

05 - ENGINE MANAGEMENT CIRCUIT - POWER DISTRIBUTION, CAN




06 - ENGINE MANAGEMENT CIRCUIT - THROTTLE CONTROL




ELECTRICAL CIRCUIT

07 - ENGINE MANAGEMENT CIRCUIT - SENSOR NETWORK




08 - ENGINE MANAGEMENT CIRCUIT - COILS, INJECTORS, HEATERS, PURGE




ELECTRICAL CIRCUIT

09 - ENGINE MANAGEMENT CIRCUIT - RELAY MANAGEMENT




10 - BRAKE CIRCUIT




ELECTRICAL CIRCUIT

11 - LIGHTING CIRCUIT - FRONT




12 - LIGHTING CIRCUIT - REAR - STANDARD



ELECTRICAL CIRCUIT

13 - LIGHTING CIRCUIT - REAR - MULTIFUNCTION






15 - HEATED GRIP CIRCUIT





ELECTRICAL CIRCUIT


17 - CAN AND LIN CIRCUIT






ELECTRICAL CIRCUIT

19 - ALARM CIRCUIT




20 - DIAGNOSTIC SOCKET CIRCUIT



◀BACK

ELECTRICAL CIRCUIT

21 - EARTH CIRCUIT



22 - EARTH CIRCUIT

