



Backup Battery Replacement Guide for Honeywell Vista 15 & 20 Control Panels

Remove the red wire first, then black from the battery leads. Replace battery with one (1) **12 volt**, 4Ah, 4.5Ah, 5Ah, or 7Ah Sealed Lead Acid rechargeable battery. TSG can provide a replacement for a small fee or you may purchase one at most hardware stores, Batteries + Bulbs and some sporting good stores (typically found in the hunting section).

WARNING! The polarity of the battery must be observed, by connecting the red wire to the red battery terminal and the black wire to the black terminal. Improper handling of batteries may result in heat generation, explosion or fire, which may lead to personal injuries. Replace only with the same or equivalent type of battery as recommended by the manufacturer.