



# SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS




SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

1- Remove the seat section & the solo seat or rear seat.

2- Disconnect the tail light wires





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

- 3- Slowly remove the tail section





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

In order to remove the tail section, please remove the attachments to the tail section.





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

- 4- Remove the lock rivets under the tail section and the 2 6mm bolts (10mm head).**
  
- 5- Cut the stock turn signal wires as close as possible to the signals**



## SUZUKI TL 1000R

### INSTALLATION INSTRUCTIONS

- **6- Fender trimming:** the stock fender is used to retain the trunk area also kept is the holder clips for the support bar but it must be trimmed enough to install the undertail section.

For cutting, it's recommended a dremmel tool with plastic cutting tip.  
You can also use a hack saw blade or something similar.


You basically have to cut fender at least as high as the finished edge and also leave room for signals. It's not critical to cut perfectly since the new tail covers all of this.

Drill 3 or 4 holes in each side of the trunk and use zip ties to attach it to sub frame for more support (see pictures)  
Wear safety glasses for all cutting procedures!!!

SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

### Fender trimming





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

### Fender trimming





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

- 7.- With cutting tool remove the 4 bungee hooks on sub-frame and file welds smooth also



SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

8- You may have to remove slip-on muffler to drill hole on right & left side.




9- Remove 2 welded bracket on same bar as the hooks.



# SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

- 10- Tail light assembly: It's easier for you to assemble the tail lights before installing the undertail.



With this undertail,  
you have to use your  
own stock sockets.

Just need to remove  
the area circled with  
the help of a Dremel,  
hand saw or sand  
paper.

# SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

It will look like this....





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS


Use the provided led bulbs, plug them in the sockets and then attach them to the base. Place the washers & nuts and adjust them.  
**DON'T TIGHT THEM TOO HARD!**



**SUZUKI TL 1000R**

## **INSTALLATION INSTRUCTIONS**

**Should look like this...**





# SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

Connect signal and tail light wires  
Check signal, tail and brake light operation.





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

- 11- Carefully reinstall the tail section on the bike but **do not install any of the bolts**. Proceed to install the undertail.





# SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

Slide the undertail up into the tail section and position rear holes to be drilled.



SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

Should look like this.





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

### 13- Secure the tail section





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

Secure the tail section






# SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

Position rear holes to be drilled,  
Proceed to drill. Use the hardware provided.





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS

Should look like this..





## SUZUKI TL 1000R

### INSTALLATION INSTRUCTIONS

The back of the undertail comes with 2 predrilled holes. You won't be able to notice them once the undertail is installed. Since the undertail is too long and in order to avoid vibrations in that area, we use 2 zip ties (provided) to secure it. Please see next step





SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS


Drill a hole in the area  
shown



**SUZUKI TL 1000R**

## **INSTALLATION INSTRUCTIONS**

**Use zip ties provided**





SUZUKI TL 1000R


## INSTALLATION INSTRUCTIONS

- 13- Install the license plate bracket in marking holes and drill the holes for fasteners supplied.  
You can also use nuts and bolts if you prefer.



# SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS






SUZUKI TL 1000R

## INSTALLATION INSTRUCTIONS




Use hardware provided  
for the bracket.



**SUZUKI TL 1000R**

**INSTALLATION INSTRUCTIONS**



**SUZUKI TL 1000R**



Should look like this...



SUZUKI TL 1000R



You are  
done!

