

QUICK START

Contact Terafloat or your distributor if you have questions



BATTERIES

Charge batteries until green charger light indicate full charge.

Insert into motor. Indicator lights on motor show the remaining charge



TRIGGER LOCK

Make yourself familiar with the 3 different positions of the trigger lock bolt.

The Switch paddle can be unrestricted, locked, blocked depending on the bolt position to suit your preference





TURNFLEX

Switch between straight shaft and flexed shaft.

Pull sleeve forward (1) and rotate 180 degrees (2).

The tongue of the sleeve will engage in the notch to secure this position



ROTATE HEAD

Pull head with sleeve forward.

Rotate head in 90 degrees increments and snap it back in place. Make sure you don't unscrew head by accident.



CARE

Clean disc and shaft with water and brush before debris dries.

Lubricate Turnflex once a month with grease or WD40 .

Store with batteries removed.

Make sure the head is screwed on tightly.

