







How to Operate a Low-Speed Floor Machine

Low-speed floor machine come in several sizes and can be used on floors in many different ways. Most common of uses is with a single 17" or 20" floor pad or brush under the unit in contact with the flooring surface.

Be sure that you are indeed using a floor machine by noting that the wheels on the unit are up off of the floor during operation and the motor is directly over the pad/brush.



Prior to Use

- Inspect the power cord, and be sure that it is in good repair.
- Inspect the pad driver and be sure the face is in good repair.
- Check the handle switch levers and be sure they do not stick and work properly under power.
- Check the 'dead man' switch for proper operation.

Setting up the Unit

- Lay the floor machine back on its handle. The bottom of the floor machine must be visible.
- Install the appropriate pad driver on the bottom of the floor machine.
- Place the unit and pad next to the wall outlet where the power cord is plug in.

Put the floor pad of choice on the floor and place the floor machine on top
of it. Be sure that it is centered on the pad.

Operating the Floor Machine

- Find the handle release and lower the handle to waist height.
- Prior to operating the unit, understand that the unit will move to the left immediently upon pulling the switch levers.
- Depress the 'dead man' switch and pull the switch levers. Do not move the handle up or down as will cause the machine to move.
- Lower the handle ½" from center and the machine will move to the right.
- Raise the handle ½" from center and the machine will move to the left.
- It is best if the operator lets the handle of the unit rest against their waist for stability. Do not try to operate the machine with your arms away from your body.

Scrubbing the Floor

- Operate the machine from side to side, working away from the plug where the machine is plugged in.
- Always work into the cleaning solution on the floor.
- Be sure to have the proper footware on for the cleaning task.

Storing the Machine

- At the end of the task, wrap the power cord on the machine, cleaning the cord with a rag as you wrap it up.
- Lay the machine back on its handle and remove the pad and driver.
- Clean the pad.
- Clean the driver and place on a wall hook or flat shelf, with the face up.
- Wipe down the machine.