
INSTRUCTION MANUAL





Please keep this manual and product code number for future reference and for ordering replacement parts if necessary.

GENERAL INSTRUCTIONS

- · Read this manual carefully and completely before proceeding.
- It is recommended that you wear safety glasses at all times during the installation.

INSTALLATION OVER CERAMIC TILES

- If your shower door is to be installed over ceramic tiles, the tiles should lay completely under the wall jamb.
- Silicone should be used to seal the gap where the ceramic tiles meet the fixed panel.


NOTICE

- Caulking: no sealant is required inside the shower, unless otherwise stated.
- Some models are equipped with clear sealing gaskets.

CARE FOR YOUR SHOWER DOOR


- Never use scouring powder pads or sharp instruments on metal pieces or glass panels.
 - An occasional wiping down with a mild soap diluted in water is all that is needed to keep the panels and metal parts looking new.
- We recommend wiping the glass panels with a squeegee after each use.


TOOLS REQUIRED




^{*} Use a 6mm(1/4") drill bit for ceramic when drilling into ceramic tiles

CHOOSE A CONFIGURATION





PARTS LISTING



ITEM	PARTS	DIAGRAM	QTY
1	Guide rail bracket		2
2	Track holder for fixed panel	3	2
3	Rail	0	1
4	Fixed panel		1
5	Wall mount bracket	9	1
6	Screw St4x20	8	1
7	Floor guide	Ø	1
8	Anti-splash threshold	F7	1

ITEM	PARTS	DIAGRAM	QTY
9	Ø55 Roller	9	4
10	Screw St4x30	8	2
11	Wall plugs Ø6	4	2
12	Door seal		2
13	Sliding door	0.	1
14	Handle	A A	1
15	Fixed panel seal	Ш	1

