
INSTRUCTION MANUAL



A A 2 PEOPLE REQUIRED

Please keep this manual and product code number for future reference and for ordering replacement parts if necessary.

GENERAL INSTRUCTIONS

- Read this manual carefully and completely before proceeding.
- It is recommended that you wear safety glasses at all times during the installation.

INSTALLATION OVER CERAMIC TILES

- If your shower door is to be installed over ceramic tiles, the tiles should lay completely under the wall jamb.
- Silicone should be used to seal the gap where the ceramic tiles meet the fixed panel.

NOTICE

- Caulking: no sealant is required inside the shower, unless otherwise stated.
- Some models are equipped with clear sealing gaskets.

CARE FOR YOUR SHOWER DOOR


- Never use scouring powder pads or sharp instruments on metal pieces or glass panels.
 An occasional wiping down with a mild soap diluted in water is all that is needed to keep the panels and metal parts looking new.
- We recommend wiping the glass panels with a squeegee after each use.

TOOLS REQUIRED


SPIRIT LEVEL	POWER DRILL	PENCIL	SILICONE	MALLET
TAPE MEASURE	SCREW DRIVER	6mm&3mm(1/4" & 1/8") DRILL BITS	HACKSAW	SAFETY GLASSES

 $[\]ensuremath{^{\star}}$ Use a 6mm(?") drill bit for ceramic when drilling into ceramic tiles

CHOOSE A CONFIGURATION



PARTS LISTING



ITEM	PARTS	DIAGRAM	QTY
01	Roller		4
02	Guide Rail & damper	IE	1
03	Anti jumping knob	®	4
04	Plastic seal	A	2
05	Sliding door		2
06	Towel bar	1	1
07	Anti-splash threshold	Ĺ	1

ITEM	PARTS	DIAGRAM	QTY
08	Floor guide cover cap	1	1
09	Floor guide		1
10	Screw St4x30		5
11	Guide rail bracket	(10.0)	2
12	Wall plugs ?6		5
13	Door seal	$\supset \chi$	4
14	Grab	4	1

