


a basic guide to measuring a room

In order to work out how much carpet or vinyl you will need you must first measure your room. To do this, simply measure the room across its longest and widest part.

Make sure you measure into any alcoves; it is better to have too much carpet or vinyl than too little! To run your carpet or vinyl into a doorway, measure to where the carpet or vinyl will finish underneath the door.

You should then add 10 centimetres (4 inches) on to each measurement. This will allow for cutting, trimming and will help ensure quality fitting. Therefore if your room is 5x3.9 mtr you will need to order carpet or vinyl measuring 5.1x4 mtr.

With 1000's of carpets in our Famous Collections, we've got the perfect carpet for you!



plot your own room and bring it to us

Plot out your room, including any alcoves, on the plan below and bring it with you to Carpets4Less. Once you've chosen your carpet or vinyl one of our specially trained Carpet Consultants will provide you with a written estimate.

