

Power Ionizer Basic Maintenance

Initial Start Up & Spring Opening Instructions

1. Balance the water:
 - a. Total Alkalinity = 80 - 120 ppm
 - b. pH = 7.2 – 7.8
 - c. Calcium Hardness = 230 – 350 ppm
 - d. Total Dissolved Solids = 1500 ppm
2. Turn on the Power Ionizer System and set the control to 8, (highest setting) for 48-72 hours.
3. Add pool salt.
4. Add Condition. *** DO NOT SWIM FOR AT LEAST 24 HOURS AFTER ADDING THIS PRODUCT!***
5. Test water daily until the copper level reaches .03 - .06 ppm.

Two Week Maintenance (Weekly for Pools larger than 24')

1. Test water for pH, Alkalinity and Copper. The amount of copper indicates the level of natural minerals in the water.
2. Adjust the Power Ionizer System using the control.
3. Add 1 bag of **Awaken** and 1 bag of **Energize**. Various conditions may require adding an additional bag of each, such as high bather load and consistent temperatures around 100 degrees.
4. Add 1 bottle of **Cleanse**.
5. Test the copper level and adjust the control dial to maintain residual within .03 - .06 ppm.
6. Follow steps 4 – 6 on ABC's of Pool Maintenance.