

MAINTENANCE GUIDELINES

- Regularly inspect the awning for any signs of wear or damage, such as frayed fabric or loose hardware.
- Clean the awning fabric periodically with mild soap and water to remove dirt and debris. Allow the fabric to air dry completely before retracting the awning.
- Inspect the motorized mechanism periodically for any signs of wear or damage, and lubricate as necessary according to the manufacturer's recommendations.
- Keep the area around the screen clear to prevent obstructions during operation.
- For detailed care and cleaning guidelines, please visit www.twitchellcorp.com or scan the QR code below.



- For detailed care and cleaning guidelines, please visit www.phifer.com or scan the QR code below.

