



Main Menu

Controller is in COMMISSIONING mode (more values are accessible and visible)


Scroll down to INPUTS and Press OK



Inputs

All inputs programmed are visible. Scroll down to view all INPUTS

Press ESC to go back to MAIN Menu



Aggregates

All aggregates (OUTPUTS) programmed are visible. Press OK to enter Aggregates Menu and view various aggregates



Aggregates

Press OK wheel to enter highlighted Block & view status.



Fan Start Block

Line 1 shows the State (ON/OFF)


Line 2 shows the Value of Input 1

Line 3 shows the value of Input 2

Number 1 indicates value is ON,

Number 0 indicates value is OFF

Press ESC to return to MAIN MENU



TEMP CONTROLLER

Using OK Wheel, Scroll down to TEMP CONTROLLER

Press OK wheel to Enter Temp Controller menu

Temp Controller

Line 1 shows Actual TEMP

Line 2 shows Current Setpoint

Line 3 shows Low (Heating)

Line 4 Shows High (Cooling)

Scroll down to Setpoint High, Press OK wheel



Setpoint High

Rotate Wheel to reduce setpoint.

Note; setpoint will not allow to go below Setpoint Low



Setpoint High

Rotate Wheel to reduce setpoint.

Press OK when desired Temp is reached.

Controller returns to Temp Controller Screen



Temp Controller

New Setpoint will now be displayed as Current Setpoint

Press ESC to return to Main Menu



Main menu

Press ESC to return to Welcome Page

