

**Mini XL**  
**SET FIBER OPTICS**

Step 1 – Highlight “**Channel 1**” with the “**up**” or “**down**” buttons and press the center button.

Step 2 – Make sure it is on “**Lon.**” It will be located in the top right hand corner.

Step 3 – Go up to “**Options**” and press the center button.

Step 4 – Go down to “**Manual Setting**” and press the center button.

Step 5 – Put the bottom number 15 higher than the top number, using the “**up**” or “**down**” buttons. Press “**Exit**” with the center button and down to “**Exit**” again with the center button.

Step 6 – Return to the main screen, and highlight “**Channel 2.**” Then press the center button.

Step 7 – Adjust the top two fiber optics, with the little wing nuts, until your top number is as high as it will go.

Step 8 – Go to “**Options**” and press center button.

Step 9 – Go to **Lon / Don** and press center button. Then put it on “**dark on**” and press center button.

Step 10 – Go to “**Manual Settings**” and press center button.

Step 11 – Put the bottom number to **10.00**. Then press “**Exit**” and return to the main screen.

Step 12 – The system should be ready to run.