



Satellite Dish Installation guidelines

Adopted 06/29/13

Dishes should be installed on fascia boards or trim boards on chimney chases, preferably higher up on the building above eyesight when walking or driving.

Dishes must not be attached to roofs.

Dishes must not be attached to siding.

All cables should enter the house as close to the dish as possible, otherwise they should be tucked and stapled against trim boards so they are not visible.