

How To Create Scenes on TouchMix-8/16

1. Power on mixer - Power button found top right corner
2. Press "Menu" Button
3. Touch "Scenes"
4. You should see two boxes, one for Mixer and one for USB
5. Select _EV_default_trio_ by touching it on the Mixer (left side)
6. Touch "Recall" at bottom of screen (it will take a few seconds for scene to come up)
7. Touch "Save/Save As" at top of screen
8. Change the name of the scene to fit your trio (must change name to create new scene)
9. Confirm name is correct and Touch "Ok"
10. Wait 10 seconds for action to complete
11. Find your new scene in the list on the left and touch it
12. Touch "Recall" at the bottom and confirm
13. When you see the scene name appear in the top right corner you are ready to begin building off of your new scene

Build your mix in the monitors but do not touch the House Feed or Mains. After your gig save your scene to protect your work. To save follow steps 2-7. Then confirm name is yours and touch "Ok" this will save what you did.

NOTE: Always make sure system is MUTED when you save to avoid feedback upon recall.