LEAD FREE BRASS COUPLING	PART #		DESCRIPTION
	103-A	1/8	BRASS COUPLING LEAD FREE
	103-B	1/4	BRASS COUPLING LEAD FREE
	103-C	3/8	BRASS COUPLING LEAD FREE
	103-D	1/2	BRASS COUPLING LEAD FREE
	103-E	3/4	BRASS COUPLING LEAD FREE
112	103-F	1	BRASS COUPLING LEAD FREE
THIN -	103-G	1 1/4	BRASS COUPLING LEAD FREE
	103-H	1 1/2	BRASS COUPLING LEAD FREE
	103-I	2	BRASS COUPLING LEAD FREE
	103-J	2 1/2	BRASS COUPLING LEAD FREE
	103-K	3	BRASS COUPLING LEAD FREE
	103-M	4"	BRASS COUPLING LEAD FREE

LEAD FREE BRASS REDUCING			
COUPLING			



Mills	1-5



PART #	DESCRIPTION
119-BA	1/4 X 1/8 BRASS COUPLING LEAD FREE
119-CB	3/8 X 1/4 BRASS COUPLING LEAD FREE
119-CA	3/8 X 1/8 BRASS COUPLING LEAD FREE
119-DC	1/2 X 3/8 BRASS COUPLING LEAD FREE
119-DB	1/2 X 1/4 BRASS COUPLING LEAD FREE
119-DA	1/2 X 1/8 BRASS COUPLING LEAD FREE
119-ED	3/4 X 1/2 BRASS COUPLING LEAD FREE
119-EC	3/4 X 3/8 BRASS COUPLING LEAD FREE
119-EB	3/4 X 1/4 BRASS COUPLING LEAD FREE
119-FE	1 X 3/4 BRASS COUPLING LEAD FREE
119-FD	1 X 1/2 BRASS COUPLING LEAD FREE
119-FC	1 X 3/8 BRASS COUPLING LEAD FREE
119-FB	1 X 1/4 BRASS COUPLING LEAD FREE
119-GF	1 1/4 X 1 BRASS COUPLING LEAD FREE
119-GE	1 1/4 X 3/4 BRASS COUPLING LEAD FREE
119-GD	1 1/4 X 1/2 BRASS COUPLING LEAD FREE
119-HG	1 1/2 X 1 1/4 BRASS COUPLING LEAD FREE
119-HF	1 1/2 X 1 BRASS COUPLING LEAD FREE
119-HE	1 1/2 X 3/4 BRASS COUPLING LEAD FREE
119-HD	1 1/2 X 1/2 BRASS COUPLING LEAD FREE
119-IH	2 X 1 1/2 BRASS COUPLING LEAD FREE
119-IG	2 X 1 1/4 BRASS COUPLING LEAD FREE
119-IF	2 X 1 BRASS COUPLING LEAD FREE
119-IE	2 X 3/4 BRASS COUPLING LEAD FREE
119-ID	2 X 1/2 BRASS COUPLING LEAD FREE
119-JI	2 1/2 X 2 BRASS COUPLING LEAD FREE
119-KJ	3 X 2 1/2 BRASS COUPLING LEAD FREE
119-KI	3 X 2 BRASS COUPLING LEAD FREE
119-MI	4 X 2 BRASS COUPLING LEAD FREE

LEAD FREE BRASS BUSHING







PART#	DESCRIPTION
110-BA	1/4 X 1/8 BRASS HEXO BUSH. LEAD FREE
110-CB	3/8 X 1/4 BRASS HEXO BUSH. LEAD FREE
110-CA	3/8 X 1/8 BRASS HEXO BUSH. LEAD FREE
110-DC	1/2 X 3/8 BRASS HEXO BUSH. LEAD FREE
110-DB	1/2 X 1/4 BRASS HEXO BUSH. LEAD FREE
110-DA	1/2 X 1/8 BRASS HEXO BUSH. LEAD FREE
110-ED	3/4 X 1/2 BRASS HEXO BUSH. LEAD FREE
110-EC	3/4 X 3/8 BRASS HEXO BUSH. LEAD FREE
110-EB	3/4 X 1/4 BRASS HEXO BUSH. LEAD FREE
110-EA	3/4 X 1/8 BRASS HEXO BUSH. LEAD FREE
110-FE	1 X 3/4 BRASS HEXO BUSH. LEAD FREE
110-FD	1 X 1/2 BRASS HEXO BUSH. LEAD FREE
110-FC	1 X 3/8 BRASS HEXI BUSH. LEAD FREE
110-FB	1 X 1/4 BRASS HEXI BUSH. LEAD FREE
110-GF	1 1/4 X 1 BRASS HEXO BUSH. LEAD FREE
110-GE	1 1/4 X 3/4 BRASS HEXO BUSH. LEAD FREE
110-GD	1 1/4 X 1/2 BRASS HEXI BUSH. LEAD FREE
110-GC	1 1/4 X 3/8 BRASS HEXI BUSH. LEAD FREE
110-HG	1 1/2 X 1 1/4 BRASS HEXO BUSH. LEAD FREE
110-HF	1 1/2 X 1 BRASS HEXO BUSH. LEAD FREE
110-HE	1 1/2 X 3/4 BRASS HEXI BUSH. LEAD FREE
110-HD	1 1/2 X 1/2 BRASS HEXI BUSH. LEAD FREE
110-HC	1 1/2 X 3/8 BRASS HEXI BUSH. LEAD FREE
110-IH	2 X 1 1/2 BRASS HEXO BUSH. LEAD FREE
110-IG	2 X 1 1/4 BRASS HEXO BUSH. LEAD FREE
110-IF	2 X 1 BRASS HEXI BUSH. LEAD FREE
110-IE	2 X 3/4 BRASS HEXI BUSH. LEAD FREE
110-ID	2 X 1/2 BRASS HEXI BUSH. LEAD FREE
110-JI	2 1/2 X 2 BRASS HEXO BUSH. LEAD FREE
110-JH	2 1/2 X 1 1/2 BR. HEXI BUSH. LEAD FREE
110-JG	2 1/2 X 1 1/4 BR. HEXI BUSH. LEAD FREE
110-JF	2 1/2 X 1 BRASS HEXI BUSH. LEAD FREE
110-JE	2 1/2 X 3/4 BRASS HEXI BUSH. LEAD FREE
110-KJ	3 X 2 1/2 BRASS HEXO BUSH. LEAD FREE
110-KI	3 X 2 BRASS HEXI BUSH. LEAD FREE
110-KH	3 X 1 1/2 BRASS HEXI BUSH. LEAD FREE
110-MK	4 X 3 BRASS HEXO BUSH. LEAD FREE
110-MJ	4 X 2 1/2 BRASS HEXI BUSH. LEAD FREE
110-MI	4 X 2 BRASS HEXI BUSH. LEAD FREE
110-GB	1 1/4 X 1/4 BRASS HEXI BUSH. LEAD FREE
110-HB	1 1/2 X 1/4 BRASS HEXI BUSH. LEAD FREE
110-IE	2 x 3/4 BRASS GIANT BUSHING LEAD FREE
110-IG	2 x 1 1/2 BRASS GIANT BUSHING LEAD FREE

LEAD FREE 45 FEMALE	PART #	DESCRIPTION
	105-A	1/8 BRASS 45 LEAD FREE
75-	105-B	1/4 BRASS 45 LEAD FREE
	105-C	3/8 BRASS 45 LEAD FREE
	105-D	1/2 BRASS 45 LEAD FREE
	105-E	3/4 BRASS 45 LEAD FREE
	105-F	1 BRASS 45 LEAD FREE
	105-G	1 1/4 BRASS 45 LEAD FREE
	105-H	1 1/2 BRASS 45 LEAD FREE
Taline	105-l	2 BRASS 45 LEAD FREE
	105-J	2 1/2 BRASS 45 LEAD FREE
	105-K	3 BRASS 45 LEAD FREE
LEAD FREE 45 STREET M/F	PART #	DESCRIPTION
	124-A	1/8 BRASS ST 45 LEAD FREE (MXF)
	124-B	1/4 BRASS ST 45 LEAD FREE (MXF)
	124-C	3/8 BRASS ST 45 LEAD FREE (MXF)
	124-D	1/2 BRASS ST 45 LEAD FREE (MXF)
12 6 0	124-E	3/4 BRASS ST 45 LEAD FREE (MXF)
	124-F	1 BRASS ST 45 LEAD FREE (MXF)
	124-G	1 1/4 BRASS ST 45 LEAD FREE (MXF)
	124-H	1 1/2 BRASS ST 45 LEAD FREE (MXF)
	124-l	2 BRASS ST 45 LEAD FREE (MXF)
LEAD FREE 90 FEMALE	PART #	DESCRIPTION
	100-A	1/8 BRASS 90 ELBOW LEAD FREE
	100-B	1/4 BRASS 90 ELBOW LEAD FREE
	100-CA	3/8 BRASS 90 ELBOW LEAD FREE
	100-D	1/2 BRASS 90 ELBOW LEAD FREE
	100-E	3/4 BRASS 90 ELBOW LEAD FREE
	100-F	1 BRASS 90 ELBOW LEAD FREE
	100-G	1 1/4 BRASS 90 ELBOW LEAD FREE
	100-H	1 1/2 BRASS 90 ELBOW LEAD FREE
	100-J	2 BRASS 90 ELBOW LEAD FREE
	100-K	2 1/2 BRASS 90 ELBOW LEAD FREE
	100-M	3 BRASS 90 ELBOW LEAD FREE
	100-N	4 BRASS 90 ELBOW LEAD FREE

LEAD FREE 90 STREET ELBOW	PART#	DESCRIPTION
	116-A	1/8 BRASS ST 90 (MF) LEAD FREE
	116-B	1/4 BRASS ST 90 (MF) LEAD FREE
	116-C	3/8 BRASS ST 90 (MF) LEAD FREE
	116-D	1/2 BRASS ST 90 (MF) LEAD FREE
	116-E	3/4 BRASS ST 90 (MF) LEAD FREE
	116-F	1 BRASS ST 90 (MF) LEAD FREE
	116-G	1 1/4 BRASS ST 90 (MF) LEAD FREE
	116-H	1 1/2 BRASS ST 90 (MF) LEAD FREE
	116-I	2 BRASS ST 90 (MF) LEAD FREE
	116-J	2 1/2 BRASS ST 90 (MF) LEAD FREE
	116-K	3 BRASS ST 90 (MF) LEAD FREE
LEAD FREE CAP	PART#	DESCRIPTION
	108-A	1/8 BRASS CAP LEAD FREE
	108-B	1/4 BRASS CAP LEAD FREE
	108-C	3/8 BRASS CAP LEAD FREE
	108-D	1/2 BRASS CAP LEAD FREE
	108-E	3/4 BRASS CAP LEAD FREE
	108-F	1 BRASS CAP LEAD FREE
	108-G	1 1/4 BRASS CAP LEAD FREE
	108-H	1 1/2 BRASS CAP LEAD FREE
	108-I	2 BRASS CAP LEAD FREE
	108-J	2 1/2 BRASS CAP LEAD FREE
	108-K	3 BRASS CAP LEAD FREE
	108-M	4 BRASS CAP LEAD FREE
LEAD FREE SQUARE HEAD PLUG	PART #	DESCRIPTION
	109-A	1/8 BRASS SOLID PLUG LEAD FREE
	109-B	1/4 BRASS SOLID PLUG LEAD FREE
	109-C	3/8 BRASS SOLID PLUG LEAD FREE
	109-D	1/2 BRASS PLUG LEAD FREE
	109-E	3/4 BRASS PLUG LEAD FREE
	109-F	1 BRASS PLUG LEAD FREE
	109-G	1 1/4 BRASS PLUG LEAD FREE
	109-H	1 1/2 BRASS PLUG LEAD FREE
	109-I	2 BRASS PLUG LEAD FREE
	109-J	2 1/2 BRASS PLUG LEAD FREE
	109-K	3 BRASS PLUG LEAD FREE

109-M

4

BRASS PLUG LEAD FREE

LEAD EDGE TEE	DADT #	DESCRIPTION
LEAD FREE TEE	PART #	DESCRIPTION
	101-A	1/8 BRASS TEE LEAD FREE
	101-B	1/4 BRASS TEE LEAD FREE
	101-C	3/8 BRASS TEE LEAD FREE
	101-D	1/2 BRASS TEE LEAD FREE
	101-E	3/4 BRASS TEE LEAD FREE
	101-F	1 BRASS TEE LEAD FREE
	101-G	1 1/4 BRASS TEE LEAD FREE
	101-H	1 1/2 BRASS TEE LEAD FREE
	101-1	2 BRASS TEE LEAD FREE
	101-J	2 1/2 BRASS TEE LEAD FREE
	101-K	3 BRASS TEE LEAD FREE
	101-M	4 BRASS TEE LEAD FREE
	101-BA	1/4 X 1/4 X 1/8 BRASS TEE LEAD FREE
	101-CB	3/8 X 3/8 X 1/4 BRASS TEE LEAD FREE
	101-CA	3/8 X 3/8 X 1/8 BRASS TEE LEAD FREE
	101-DE	1/2 X 1/2 X 3/4 BRASS TEE LEAD FREE
	101-DC	1/2 X 1/2 X 3/8 BRASS TEE LEAD FREE
	101-DB	1/2 X 1/2 X 1/4 BRASS TEE LEAD FREE
	101-DBD	1/2 X 1/4 X 1/2 BRASS TEE LEAD FREE
	101-EF	3/4 X 3/4 X 1 BRASS TEE LEAD FREE
	101-ED	3/4 X 3/4 X 1/2 BRASS TEE LEAD FREE
	101-EDE	3/4 X 1/2 X 3/4 BRASS TEE LEAD FREE
	101-EDD	3/4 X 1/2 X 1/2 BRASS TEE LEAD FREE
	101-FB	1 X 1 X 1/4 BRASS TEE LEAD FREE
	101-FE	1 X 1 X 3/4 BRASS TEE LEAD FREE
	101-FD	1 X 1 X 1/2 BRASS TEE LEAD FREE
	101-FEF	1 X 3/4 X 1 BRASS TEE LEAD FREE
	101-FEE	1 X 3/4 X 3/4 BRASS TEE LEAD FREE
	101-FED	1 X 3/4 X 1/2 BRASS TEE LEAD FREE
	101-FDF	1 X 1/2 X 1 BRASS TEE LEAD FREE
	101-FDE	1 X 1/2 X 3/4 BRASS TEE LEAD FREE
	101-FDD	1 X 1/2 X 1/2 BRASS TEE LEAD FREE
	101-GI	1 1/4 X 1 1/4 X 1 BR. TEE LEAD FREE
	101-GE	1 1/4 X 1 1/4 X 3/4 BR.TEE LEAD FREE
	101-GD	1 1/4 X 1 1/4 X 1/2 BR.TEE LEAD FREE
	101-GFG	1 1/4 X 1 X 1 1/4 BRASS TEE LEAD FREE
	101-GFF	1 1/4 X 1 X 1 BRASS TEE LEAD FREE
	101-GEG	1 1/4 X 3/4 X 1 1/4 BR. TEE LEAD FREE
	101-GDG	1 1/4 X 1/2 X 1 1/4 BR. TEE LEAD FREE
	101-HGG	1 1/2 X 1 1/2 X 1 1/4 BR.TEE LEAD FREE
	101-HHF	1 1/2 X 1 1/2 X 1 BRASS TEE LEAD FREE
	101-HHE	1 1/2 X 1 1/2 X 3/4 BR. TEE LEAD FREE
	101-HHD	1 1/2 X 1 1/2 X 1/2 BR. TEE LEAD FREE

LEAD FREE TEE	PART#	DESCRIPTION
	101-HFF	1 1/2 X 1 X 1 BRASS TEE LEAD FREE
	101-IH	2 X 2 X 1 1/2 BRASS TEE LEAD FREE
	101-IG	2 X 2 X 1 1/4 BRASS TEE LEAD FREE
	101-IF	2 X 2 X 1 BRASS TEE LEAD FREE
	101-IE	2 X 2 X 3/4 BRASS TEE LEAD FREE
	101-ID	2 X 2 X 1/2 BRASS TEE LEAD FREE
	101-E-GIANT	3/4 BRASS TEE LEAD FREE (GIANT)
	101-IEI	2 X 3/4 X 2 BRASS TEE LEAD FREE
	101-JJI	2 1/2 X 2 1/2 X 2 BRASS TEE LEAD FREE
	101-MMI	4 X 4 X 2 BRASS TEE LEAD FREE



PART #	DESCRIPTION
102-B	1/4 BRASS CROSS LEAD FREE
102-C	3/8 BRASS CROSS LEAD FREE
102-D	1/2 BRASS CROSS LEAD FREE
102-E	3/4 BRASS CROSS LEAD FREE
102-F	1 BRASS CROSS LEAD FREE
102-G	1 1/4 BRASS CROSS LEAD FREE
102-H	1 1/2 BRASS CROSS LEAD FREE
102-I	2 BRASS CROSS LEAD FREE



LEAD FREE UNION COUPLING

PART#		DESCRIPTION
LF104-A	1/8	BRASS UNION LEAD FREE
LF104-B	1/4	BRASS UNION LEAD FREE
LF104-C	3/8	BRASS UNION LEAD FREE
LF104-D	1/2	BRASS UNION LEAD FREE
LF104-E	3/4	BRASS UNION LEAD FREE
LF104-F	1	BRASS UNION LEAD FREE
LF104-G	1 1/4	BRASS UNION LEAD FREE
LF104-H	1 1/2	BRASS UNION LEAD FREE
LF104-I	2	BRASS UNION LEAD FREE
LF104-J	2 1/2	BRASS UNION LEAD FREE
LF104-K	3	BRASS UNION LEAD FREE
LF104-M	4	BRASS UNION LEAD FREE