

Grounding & Bonding Station



The Grounding and Bonding network connecting station is used with the engineered Ground/Bond Clamp. The ground clamp is connected to the well or tank farm. Ancillary equipment is safely and easily connected to the station that is placed outside the **Hot Zone**.

Tank and vessel cleaning equipment is safely connected outside the **hot zone**.

All equipment coming onto the location has generated a potential for static electricity. There will be a **SPARK** of some type when the Ground/Bond connection is made.