

## The Awl of Spades

Below are illustrations on how to remove or change the blade on the Awl of Spades.



(1)

(2)

(3)

(4)

(1) Tool-less blade change Awl of Spades. (2) Grip the bottom half of the haft and twist the top (with the “LW” logo) counter-clockwise to loosen the collet holding the blade. (3) Push the top half toward the bottom until it releases the collet, moving it slightly forward. (4)



(5)

(6)

(7)

(\*)

(5) The \*blade (or scribe awl) should now slide out easily. (6) Insert the scribe or align the \*blade tang parallel to one of the slots in the collet and pull the top half until the collet and \*blade are snug in the bolster. (7) Tighten the collet by rotating the top half clockwise, until it is nice and tight. (\*) **Handle the awl blade from the sides, not the edges. It is very sharp, and it will cut you!** Your Awl of Spades is now ready to use.

Please try it, and let us know what you think about the Awl of Spades. We welcome your honest feedback.

Happy stitching!

