



SHAKER STYLE ESSENTIAL COLLECTION



Shaker White




Shaker Gray



Shaker Espresso

SHAKER WHITE



SPECIFICATIONS

1. **Door & Drawer Front:** Full overlay, 5-pieces door & drawer, solid wood with MDF center panel
2. **Face Frame:** 3/4" solid wood frame
3. **Cabinet Box:** 1/2" cabinet grade plywood box
4. **Drawer Box:** Solid wood, dovetail construction, 2 1/2 depth
5. **Drawer Glides:** Concealed undermount full extension glides with soft-close feature
6. **Hinges:** 6-way adjustable with soft-close feature
7. **Exterior Finish:** Matching color exterior
8. **Interior Finish:** Clear UV coated natural plywood
9. **Shelves:** 3/4" thick plywood with front edge banding
10. **Accessories:** Door bumper, metal shelf pin, metal clips, L bracket for base cabinet
11. **Package:** One box per cabinet
12. **Certification:** TSCA VI, KCMA, CARB2, NGBS Green.

Tray Base Cabinet



Model	Description
SW-BT09	Shaker White - Base Tray - 9"W X 24"D X 34-1/2"H With 1 Door

1 Door 1 Drawer Base Cabinets




Model	Description
SW-B12	Shaker White - Base Cabinet Single Door-12"W X 24"D X 34-1/2"H With 1 Door, Drawer And Shelf
SW-B15	Shaker White - Base Cabinet Single Door-15"W X 24"D X 34-1/2"H With 1 Door, Drawer And Shelf
SW-B18	Shaker White - Base Cabinet Single Door -18"W X 24"D X 34-1/2"H With 1 Door, Drawer And Shelf
SW-B21	Shaker White - Base Cabinet Single Door - 21"W X 24"D X 34-1/2"H With 1 Door, Drawer And Shelf

2 Doors 1 Drawer Base Cabinets




Model	Description
SW-B24	Shaker White - Base Cabinet Double Door - 24\"W X 24\"D X 34-1/2\"H With 2 Door, 1 Drawer And Shelf
SW-B27	Shaker White - Base Cabinet Double Door - 27\"W X 24\"D X 34-1/2\"H With 2 Door, 1 Drawer And Shelf

2 Door 2 Drawers Base Cabinets




Model	Description
SW-B30	Shaker White - Base Cabinet Double Door - 30\"W X 24\"D X 34-1/2\"H With 2 Door, 2 Drawer And 1 Shelf
SW-B33	Shaker White - Base Cabinet Double Door - 33\"W X 24\"D X 34-1/2\"H With 2 Door, 2 Drawer And 1 Shelf
SW-B36	Shaker White - Base Cabinet Double Door - 36\"W X 24\"D X 34-1/2\"H With 2 Door, 2 Drawer And 1 Shelf
SW-B42	Shaker White - Base Cabinet Double Door - 42\"W X 24\"D X 34-1/2\"H With 2 Door, 2 Drawer And 1 Shelf

Full Height Single Door Base Cabinet




Model	Description
SW-BFH12	Shaker White - Base Cabinet - Full Height Door- 12"W x 34-1/2"H x 24"D - 1D, 1S
SW-BFH15	Shaker White - Base Cabinet - Full Height Door- 15"W x 34-1/2"H x 24"D - 1D, 1S
SW-BFH18	Shaker White - Base Cabinet - Full Height Door- 18"W x 34-1/2"H x 24"D - 1D, 1S
SW-BFH21	Shaker White - Base Cabinet - Full Height Door- 21"W x 34-1/2"H x 24"D - 1D, 1S

Full Height Double Door Base Cabinet




Model	Description
SW-BFH24	Shaker White - Base Cabinet - Full Height Door- 24"W x 34-1/2"H x 24"D - 2D, 1S
SW-BFH27	Shaker White - Base Cabinet - Full Height Door- 27"W x 34-1/2"H x 24"D - 2D, 1S
SW-BFH30	Shaker White - Base Cabinet - Full Height Door- 30"W x 34-1/2"H x 24"D - 2D, 1S
SW-BFH33	Shaker White - Base Cabinet - Full Height Door- 33"W x 34-1/2"H x 24"D - 2D, 1S
SW-BFH36	Shaker White - Base Cabinet - Full Height Door- 36"W x 34-1/2"H x 24"D - 2D, 1S

2 Drawer Bases




Model	Description
SW-2DB24	Shaker White - Drawer Base Cabinet - 24"W x 34-1/2"H x 24"D - 2DRW
SW-2DB30	Shaker White - Drawer Base Cabinet - 30"W x 34-1/2"H x 24"D - 2DRW
SW-2DB36	Shaker White - Drawer Base Cabinet - 36"W x 34-1/2"H x 24"D - 2DRW

Three Drawer Base Cabinets




Model	Description
SW-3DB12	Shaker White - Drawer Base Cabinet - 12"W X 24"D X 34-1/2"H With 3 Drawer
SW-3DB15	Shaker White - Drawer Base Cabinet - 15"W X 24"D X 34-1/2"H With 3 Drawer
SW-3DB18	Shaker White - Drawer Base Cabinet - 18"W X 24"D X 34-1/2"H With 3 Drawer
SW-3DB21	Shaker White - Drawer Base Cabinet - 21"W X 24"D X 34-1/2"H With 3 Drawer
SW-3DB24	Shaker White - Drawer Base Cabinet - 24"W X 24"D X 34-1/2"H With 3 Drawer
SW-3DB27	Shaker White - Three Drawer Base Cabinets - 27"W X 34.5"H X 24"D - Cabinet Has Three Drawers.
SW-3DB33	
SW-3DB30	Shaker White - Drawer Base Cabinet - 30"W X 24"D X 34-1/2"H With 3 Drawer
SW-3DB36	Shaker White - Drawer Base Cabinet - 36"W X 24"D X 34-1/2"H With 3 Drawer

Sink Base Cabinet With One Dummy Drawer



Model	Description
SW-SB27	Sink Base – 27"W X 34-1/2"H X 24"D – 1 False Drawer, Same Door Set With Vs27, Or Use Vs27 Instead Of Sb27

Sink Base Cabinets With Two Dummy Drawers



Model	Description
SW-SB30	Sink Base – 30"W X 34-1/2"H X 24"D – 1 False Drawer, Same Door Set With Vs30, Or Use Vs30 Instead Of Sb30
SW-SB33	Shaker White – Sink Base – 33"W X 24"D X 34-1/2"H With 2 Door And 2 Dummy Drawers
SW-SB36	Sink Base – 36"W X 34-1/2"H X 24"D – 2 False Drawers , Same Door Set With Vs36, Or Use Vs36 Instead Of Sb36

Farmhouse Sink Base Cabinet



Model	Description
-------	-------------

SW-FSB36	Shaker White - Farm Sink Base - 36"W X 24"D X 34-1/2"H With 2 Door
----------	--

Corner Sink Base Cabinet



Model	Description
-------	-------------

SW-CSB36	Shaker White - Corner Sink Base Cabinet - 36"W X 24"D X 34-1/2"H With 1 Door And 1 Dummy Drawers
----------	--

Corner Sink Base Front




Model	Description
SW-DCSF42	Shaker White - Corner Sink Base Front - 26 1/4"W X 30"H X 3/4"D - Goes With DCSF42

Base End Cabinet




Model	Description
SW-BEC24	Shaker White - Angle Base Cabinet - 24"W X 24"D X 34-1/2"H With 2 Door

Base Easy Reach Cabinets




Model	Description
SW-ERB33	Shaker White - Easy Reach Base Cabinet - 33"W X 24"D X 34-1/2"H With 1 Door And Shelf
SW-ERB36	Shaker White - Easy Reach Base Cabinet - 36"W X 24"D X 34-1/2"H With 1 Door And Shelf

Blind Corner Base Cabinets




Model	Description
SW-BBC36	Shaker White - Blind Base Corner Cabinet - 33"W X 24"D X 34-1/2"H With 1 Door, Drawer And Shelf - Install Range 36" - 39"
SW-BBC39	Shaker White - Blind Base Corner Cabinet - 36"W X 24"D X 34-1/2"H With 1 Door, Drawer And Shelf - Install Range 39" - 42"
SW-BBC42	Shaker White - Blind Base Corner Cabinet - 39"W X 24"D X 34-1/2"H With 1 Door, Drawer And Shelf - Install Range 42" - 45"

Base End Shelf




Model	Description
SW-BES12	Shaker White – Base End Shelf – 12"W X 24"D X 34-1/2"H

Spice Pull Base Cabinet



Model	Description
SW-SPB6	Shaker White – Spice Pull Base Cabinet – 6"W X 34-1/2"H X 24"D
SW-SPB9	Shaker White – Spice Pull Base Cabinet – 9"W X 34-1/2"H X 24"D

Base Spice Drawer




Model

Description

SW-BSDC6

Shaker White - Base Spice
Drawer: 6"W X 24"D X 34-
1/2"H- 5 Drawers

Microwave Base Cabinet



Model

Description


SW-MB30

Shaker White - Microwave
Base Cabinet - 30"W X 34-
1/2"H X 24"D

SW-MB33


Shaker White - Microwave
Base Cabinet - 33"W X 34-
1/2"H X 24"D

Base Waste Basket Cabinet




Model	Description
SW-BWB18	Shaker White - Base Waste Basket Cabinet - 18"W X 34-1/2"H X 24"D

Document File Base Cabinet




Model	Description
SW-DFB18	Shaker White - Document File Base Cabinet - 18"W X 21"D X 29-1/2"H - Top Drawer: 6-1/4"H Bottom Drawer: 17-1/2"H

30"H Single Door Wall Cabinets




Model	Description
SW-W0930	Shaker White – Wall Cabinet Single Door – 9"W X 30"H X 12"D With 1 Door And 2 Shelf
SW-W1230	Shaker White – Wall Cabinet Single Door – 12"W X 30"H X 12"D With 1 Door And 2 Shelf
SW-W1530	Shaker White – Wall Cabinet Single Door – 15"W X 30"H X 12"D With 1 Door And 2 Shelf
SW-W1830	Shaker White – Wall Cabinet Single Door – 18"W X 30"H X 12"D With 1 Door And 2 Shelf
SW-W2130	Shaker White – Wall Cabinet Single Door – 21"W X 30"H X 12"D With 1 Door And 2 Shelf

30"H Double Doors Wall Cabinets




Model	Description
SW-W2430	Shaker White – Wall Cabinet Double Door – 24"W X 30"H X 12"D With 2 Door And 2 Shelf
SW-W2730	Shaker White – Wall Cabinet Double Door – 27"W X 30"H X 12"D With 2 Door And 2 Shelf

36"H Single Doors Wall Cabinets



Model	Description
SW-W0936	Shaker White - Wall Cabinet Single Door - 9"W X 36"H X 12"D With 1 Door And 2 Shelf
SW-W1236	Shaker White - Wall Cabinet Single Door - 12"W X 36"H X 12"D With 1 Door And 2 Shelf
SW-W1536	Shaker White - Wall Cabinet Single Door - 15"W X 36"H X 12"D With 1 Door And 2 Shelf
SW-W1836	Shaker White - Wall Cabinet Single Door - 18"W X 36"H X 12"D With 1 Door And 2 Shelf
SW-W2136	Shaker White - Wall Cabinet Single Door - 21"W X 36"H X 12"D With 1 Door And 2 Shelf

36"H Double Doors Wall Cabinets




Model	Description
SW-W2436	Shaker White - Wall Cabinet Double Door - 24"W X 36"H X 12"D With 2 Door And 2 Shelf
SW-W2736	Shaker White - Wall Cabinet Double Door - 27"W X 36"H X 12"D With 2 Door And 2 Shelf
SW-W3036	Shaker White - Wall Cabinet Double Door - 30"W X 36"H X 12"D With 2 Door And 2 Shelf
SW-W3336	Shaker White - Wall Cabinet Double Door - 33"W X 36"H X 12"D With 2 Door And 2 Shelf
SW-W3636	Shaker White - Wall Cabinet Double Door - 36"W X 36"H X 12"D With 2 Door And 2 Shelf

42"H Single Door Wall Cabinets




Model	Description
SW-W0942	Shaker White - Wall Cabinet Single Door - 9"W X 42"H X 12"D With 1 Door And 3 Shelf
SW-W1242	Shaker White - Wall Cabinet Single Door - 12"W X 42"H X 12"D With 1 Door And 3 Shelf
SW-W1542	Shaker White - Wall Cabinet Single Door - 15"W X 42"H X 12"D With 1 Door And 3 Shelf
SW-W1842	Shaker White - Wall Cabinet Single Door - 18"W X 42"H X 12"D With 1 Door And 3 Shelf
SW-W2142	Shaker White - Wall Cabinet Single Door - 21"W X 42"H X 12"D With 1 Door And 3 Shelf

42"H Double Doors Wall Cabinets




Model	Description
SW-W2442	Shaker White - Wall Cabinet Double Door - 24"W X 42"H X 12"D With 2 Door And 3 Shelf
SW-W2742	Shaker White - Wall Cabinet Double Door - 27"W X 42"H X 12"D With 2 Door And 3 Shelf
SW-W3042	Shaker White - Wall Cabinet Double Door - 30"W X 42"H X 12"D With 2 Door And 3 Shelf
SW-W3342	Shaker White - Wall Cabinet Double Door - 33"W X 42"H X 12"D With 2 Door And 3 Shelf
SW-W3642	Shaker White - Wall Cabinet Double Door - 36"W X 42"H X 12"D With 2 Door And 3 Shelf

12"H Double Doors Wall Cabinets



Model	Description
SW-W3012	Shaker White - Wall Cabinet Double Door - 30"W X 12"H X 12"D With 2 Door
SW-W3312	Shaker White - Wall Cabinet Double Door - 33"W X 12"H X 12"D With 2 Door
SW-W3612	Shaker White - Wall Cabinet Double Door - 36"W X 12"H X 12"D With 2 Door

15"H Wall Cabinets With Double Doors




Model	Description
SW-W3015	Shaker White - Wall Cabinet Double Door - 30"W X 15"H X 12"D With 2 Door
SW-W3315	Shaker White - Wall Cabinet Double Door - 33"W X 15"H X 12"D With 2 Door
SW-W3615	Shaker White - Wall Cabinet Double Door - 36"W X 15"H X 12"D With 2 Door

18"H Wall Cabinets With Double Doors




Model	Description
SW-W2418	Shaker White - Wall Cabinet Double Door - 24"W X 18"H X 12"D With 2 Door
SW-W3018	Shaker White - Wall Cabinet Double Door - 30"W X 18"H X 12"D With 2 Door
SW-W3318	Shaker White - Wall Cabinet Double Door - 33"W X 18"H X 12"D With 2 Door
SW-W3618	Shaker White - Wall Cabinet Double Door - 36"W X 18"H X 12"D With 2 Door

24"H Wall Cabinets With Double Doors




Model	Description
SW-W3024	Shaker White - Wall Cabinet Double Door - 30"W X 24"H X 12"D With 2 Door
SW-W3324	Shaker White - Wall Cabinet Double Door - 33"W X 24"H X 12"D With 2 Door
SW-W3624	Shaker White - Wall Cabinet Double Door - 36"W X 24"H X 12"D With 2 Door

30"H Wall Cabinets With Single Glass Door



Model	Description
SW-W1530GD	Shaker White – Wall Glass Door Cabinet With Finished Interior – 15"W X 30"H X 12"D– 1D–2S *Clear Glass Included
SW-W1830GD	Shaker White – Wall Glass Door Cabinet With Finished Interior – 18"W X 30"H X 12"D– 1D–2S *Clear Glass Included

36"H Wall Cabinets With Single Glass Door




Model	Description
SW-W1536GD	Shaker White – Wall Glass Door Cabinet With Finished Interior – 15"W X 36"H X 12"D– 1D–2S *Clear Glass Included
SW-W1836GD	Shaker White – Wall Glass Door Cabinet With Finished Interior – 18"W X 36"H X 12"D– 1D–2S *Clear Glass Included



Model	Description
SW-W3018GD	Shaker White - Wall cabinet Double Glass door - 30"W X 18"H X 12"D *Clear Glass Included

42"H Wall Cabinets With Single Glass Door




Model	Description
SW-W1542GD	Shaker White - Wall Glass Door Cabinet With Finished Interior - 15"W X 42"H X 12"D-1D-3S *Clear Glass Included
SW-W1842GD	Shaker White - Wall Glass Door Cabinet With Finished Interior - 18"W X 42"H X 12"D-1D-3S *Clear Glass Included

30"H Wall Cabinets With Double Glass Doors



Model	Description
SW-W2430GD	Shaker White - Wall cabinet Double Glass door - 24"W X 30"H X 12"D-2D-2S *Clear Glass Included
SW-W3030GD	Shaker White - Wall cabinet Double Glass door - 30"W X 30"H X 12"D-2D-2S *Clear Glass Included

36"H Wall Cabinets With Double Glass Doors




Model	Description
SW-W2436GD	Shaker White - Wall cabinet Double Glass door - 24"W X 36"H X 12"D-2D-2S *Clear Glass Included
SW-W3036GD	Shaker White - Wall cabinet Double Glass door - 30"W X 36"H X 12"D-2D-2S *Clear Glass Included

42"H Wall Cabinets With Double Glass Doors




Model	Description
SW-W2442GD	Shaker White - Wall cabinet Double Glass door - 24"W X 42"H X 12"D-2D-3S *Clear Glass Included
SW-W3042GD	Shaker White - Wall cabinet Double Glass door - 30"W X 42"H X 12"D-2D-3S *Clear Glass Included

12"H Wall Cabinets With Single Glass Door




Model	Description
SW-W1212GD	Shaker White - Wall cabinet Single Glass door - 12"W X 12"H X 12"D *Clear Glass Included
SW-W1512GD	Shaker White - Wall cabinet Single Glass door - 15"W X 12"H X 12"D *Clear Glass Included
SW-W1812GD	Shaker White - Wall cabinet Single Glass door - 18"W X 12"H X 12"D *Clear Glass Included
SW-W2112GD	Shaker White - Wall cabinet Single Glass door - 21"W X 12"H X 12"D *Clear Glass Included

12"H Wall Cabinet With Double Glass Doors



Model	Description
SW-W2412GD	Shaker White – Wall cabinet Double Glass door – 24"W X 12"H X 12"D *Clear Glass Included
SW-W2712GD	Shaker White – Wall cabinet Double Glass door – 27"W X 12"H X 12"D *Clear Glass Included
SW-W3012GD	Shaker White – Wall cabinet Double Glass door – 30"W X 12"H X 12"D *Clear Glass Included
SW-W3312GD	Shaker White – Wall cabinet Double Glass door – 33"W X 12"H X 12"D *Clear Glass Included
SW-W3612GD	Shaker White – Wall cabinet Double Glass door – 36"W X 12"H X 12"D *Clear Glass Included


30"W Refrigerator Wall Cabinets With Double Doors



Model	Description
-------	-------------

SW-W301224	Shaker White – Refrigerator Wall Cabinet Double Doors – 30"W X 12"H X 24"D With 2 Door
------------	--

30"W Refrigerator Wall Cabinets With Double Doors




Model	Description
SW-W301524	Wall Refrigerator Cabinet – 30"W X 15"H X 24"D – 2D, Same Box With W3015 Door. Door Set Can Use W1530 For Every Colour.
SW-W301824	Shaker White – Refrigerator Wall Cabinet Double Doors – 30"W X 18"H X 24"D With 2 Door

33"W Refrigerator Wall Cabinets With Double Doors




Model	Description
SW-W331224	Shaker White – Refrigerator Wall Cabinet Double Doors – 33"W X 12"H X 24"D With 2 Door
SW-W331524	Shaker White – Refrigerator Wall Cabinet Double Doors – 33"W X 15"H X 24"D With 2 Door
SW-W331824	Shaker White – Refrigerator Wall Cabinet Double Doors – 33"W X 18"H X 24"D With 2 Door

30"W Refrigerator Wall Cabinets With Double Doors




Model	Description
SW-W301524	Wall Refrigerator Cabinet – 30"W X 15"H X 24"D – 2D, Same Box With W3015 Door. Door Set Can Use W1530 For Every Colour.
SW-W301824	Shaker White – Refrigerator Wall Cabinet Double Doors – 30"W X 18"H X 24"D With 2 Door

33"W Refrigerator Wall Cabinets With Double Doors



Model	Description
SW-W331224	Shaker White – Refrigerator Wall Cabinet Double Doors – 33"W X 12"H X 24"D With 2 Door
SW-W331524	Shaker White – Refrigerator Wall Cabinet Double Doors – 33"W X 15"H X 24"D With 2 Door
SW-W331824	Shaker White – Refrigerator Wall Cabinet Double Doors – 33"W X 18"H X 24"D With 2 Door

Wall Easy Reach Corner Cabinet




Model	Description
SW-WER2430	Shaker White - Wall Easy Reach Corner Cabinet - 24" W X 30" H X 12" D - 2D - 2S
SW-WER2436	Shaker White - Wall Easy Reach Corner Cabinet - 24" W X 36" H X 12" D - 2D - 2S
SW-WER2442	Shaker White - Wall Easy Reach Corner Cabinet - 24" W X 42" H X 12" D - 2D - 2S

30"H Wall Blind Corner Cabinets



Model	Description
SW-WBC2430	Shaker White - Wall Blind Corner Cabinet - 24"W X 30"H X 12"D With 1 Door And 2 Shelf
SW-WBC2730	Shaker White - Wall Blind Corner Cabinet - 27"W X 30"H X 12"D With 1 Door And 2 Shelf
SW-WBC3630	Shaker White - Wall Blind Corner Cabinet - 36"W x 30"H x 12"D - 1D - 2S Can be pulled to exact fit



Model

Description


SW-WBC2736

Shaker White - Wall Blind Corner Cabinet - 27"W X 36"H X 12"D With 1 Door And 2 Shelf

SW-WBC3036

Shaker White - Wall Blind Corner Cabinet - 30"W X 36"H X 12"D With 1 Door And 2 Shelf

42"H Wall Blind Corner Cabinets



Model

Description

SW-WBC2442

Shaker White - Wall Blind Corner Cabinet - 24"W X 42"H X 12"D With 1 Door And 3 Shelf


SW-WBC2742

Shaker White - Wall Blind Corner Cabinet - 27"W X 42"H X 12"D With 1 Door And 3 Shelf

SW-WBC3642


Shaker White - Wall Blind Corner Cabinet - 36"W X 42"H X 12"D With 1 Door And 3 Shelf

Wall Cabinet With Drawers



Model	Description
SW-WD1848	Shaker White - Wall With Drawer Cabinet- 18"W x 48"H x 12"D- 1D, 2 DRW -2S
SW-WD1854	Shaker White - Wall With Drawer Cabinet- 18"W x 54"H x 12"D- 1D, 2 DRW -2S
SW-WD1860	Shaker White - Wall With Drawer Cabinet- 18"W x 60"H x 12"D- 1D, 2 DRW -3S

Angle Wall Cabinets




Model	Description
SW-AW1230	Shaker White - Angle Wall Cabinet - 12"W X 30"H X 12"D With 1 Door And 2 Shelf
SW-AW1236	Shaker White - Angle Wall Cabinet - 12"W X 36"H X 12"D With 1 Door And 2 Shelf
SW-AW1242	Shaker White - Angle Wall Cabinet - 12"W X 42"H X 12"D With 1 Door And 3 Shelf

Diagonal Corner Wall Cabinet With Single Door



Model	Description
SW-DCW2430	Shaker White - Wall Diagonal Corner Cabinet - 24"W X 30"H X 12"D With 1 Door And 2 Shelf
SW-DCW2436	Shaker White - Wall Diagonal Corner Cabinet - 24"W X 36"H X 12"D With 1 Door And 2 Shelf
SW-DCW2442	Shaker White - Wall Diagonal Corner Cabinet - 24"W X 42"H X 12"D With 1 Door And 2 Shelf

Diagonal Corner Wall Cabinet



Model	Description
SW-DCW2736	Shaker White - Wall Diagonal Corner Cabinet - 27"W X 36"H X 15"D With 1 Door And 2 Shelf
SW-DCW2742	Shaker White - Wall Diagonal Corner Cabinet - 27"W X 42"H X 15"D With 1 Door And 2 Shelf

Diagonal Corner Wall Cabinet With Single Glass Door



Model	Description
SW-DCW2412GD	Shaker White - Diagonal Corner Wall Glass Door - 24"W X 12"H X 12"D *Clear Glass Included

Diagonal Corner Wall Cabinet With Single Door




Model	Description
SW-DCW2712GD	Shaker White - Diagonal Corner Wall Glass Door - 27"W X 12"H X 15"D *Clear Glass Included

Diagonal Corner Wall Cabinet With Single Glass Door




Model	Description
SW-DCW2430GD	Shaker White - Diagonal Corner Wall Glass Door - 24"W X 30"H X 12"D With 1 Door And 2 Shelf *Clear Glass Included
SW-DCW2436GD	Shaker White - Diagonal Corner Wall Glass Door - 24"W X 36"H X 12"D With 1 Door And 2 Shelf *Clear Glass Included
SW-DCW2442GD	Shaker White - Diagonal Corner Wall Glass Door - 24"W X 42"H X 12"D With 1 Door And 2 Shelf *Clear Glass Included

Microwave Wall Cabinets




Model	Description
SW-MO3030	Shaker White - Microwave Wall Cabinet - 30"W X 30"H X 12"D
SW-MO3036	Shaker White - Microwave Wall Cabinet - 30"W X 36"H X 12"D
SW-MO3042	Shaker White - Microwave Wall Cabinet - 30"W X 42"H X 12"D

30" Wall Open End Shelf




Model	Description
SW-OE630	Shaker White - Open End Shelf - 6"W X 30"H X 12"D With 3 Shelf

Wall Open End Shelf



Model	Description
SW-OE636	Shaker White - Open End Shelf - 6"W X 36"H X 12"D With 3 Shelf
SW-OE642	Shaker White - Open End Shelf - 6"W X 42"H X 12"D With 4 Shelf


Plate Rack



Model	Description
-------	-------------

SW-PR3015	Shaker White – Wall Plate Rack Cabinet 30"W X 15"H X 12"D
-----------	--

30"W Wine Rack




Model	Description
-------	-------------

SW-WRC3015	Shaker White – Wall Wine Rack Cabinet 30"W X 15"H X 12"D
------------	---


SW-WRC3018	Shaker White – Wall Wine Rack Cabinet 30"W X 18"H X 12"D
------------	---

30"H Wine Rack




Model	Description
SW-WRC2430	Shaker White - Wall Wine Rack Cabinet - 24"W X 30"H X 12"D

Wall Spice Drawer




Model	Description
SW-WSD630	Shaker White - Wall Spice Drawer - 30"W X 6"H X 12"D

30" Wide Utility Pantry




Model	Description
SW-U308424	Shaker White - Utility Pantry - 30"W X 24"D X 84"H. Two Adjustable Top Shelves, Three Bottom Shelves. Note: Roll Out Shelf Kits Available.

18"W Utility Pantry Cabinets




Model	Description
SW-U188424	Shaker White - Utility Pantry - 18"W X 24"D X 84"H. Two Adjustable Top Shelves, Three Bottom Shelves. Note: Roll Out Shelf Kits Available.

30" Wide Utility Pantry




Model	Description
SW-U309024	Shaker White - Utility Pantry - 30"W X 24"D X 90"H. Two Adjustable Top Shelves, Three Bottom Shelves. Note: Roll Out Shelf Kits Available.

18"W Utility Pantry Cabinets




Model	Description
SW-U189024	Shaker White - Utility Pantry - 18"W X 24"D X 90"H. Two Adjustable Top Shelves, Three Bottom Shelves. Note: Roll Out Shelf Kits Available.

30" Wide Utility Pantry




Model	Description
SW-U309624	Shaker White - Utility Pantry - 30"W X 24"D X 96"H. Two Adjustable Top Shelves, Three Bottom Shelves. Note: Roll Out Shelf Kits Available.

18"W Utility Pantry Cabinets




Model	Description
SW-U189624	Shaker White - Utility Pantry - 18"W X 24"D X 96"H. Two Adjustable Top Shelves, Three Bottom Shelves. Note: Roll Out Shelf Kits Available.

24"W Utility Pantry Cabinets




Model	Description
SW-U248424	Wall Pantry – 24"W X 84"H X 24"D – 4D, 5S, Shaker 4D, Slab 2D, Box Bb-U248424 Regular For Shaker Door Set ,Box Bb-U248424F For Slab Door Set.
SW-U249024	Wall Pantry – 24"W X 90"H X 24"D – 4D, 5S, Shaker 4D, Slab 2D, Box Bb-U249024 Regular For Shaker Door Set ,Box Bb-U249024F For Slab Door Set.
SW-U249624	Wall Pantry – 24"W X 96"H X 24"D – 4D, 5S, Shaker 4D, Slab 2D, Box Bb-U249624 Regular For Shaker Door Set ,Box Bb-U249624F For Slab Door Set.

30"W Oven Pantry Cabinets




Model	Description
SW-O308424	Shaker White – Oven Pantry – 30"W X 84"H X 24"D – Opening 24"W X 24-3/8"H. Two Door, One Large Open Shelf, Three Bottom Drawers. Note: Drawers May Be Removed To Accommodate Double Ovens.
SW-O309024	Shaker White – Oven Pantry – 30"W X 90"H X 24"D – Opening 24"W X 24-3/8"H. Two Door, One Large Open Shelf, Three Bottom Drawers. Note: Drawers May Be Removed To Accommodate Double Ovens.

Rollout Tray




Model	Description
RS18	RS18 – Rollout Tray – 17"W X 21"D X 3-1/4"H

30"W Oven Pantry Cabinets




Model	Description
SW-O309624	Shaker White – Oven Pantry – 30"W X 96"H X 24"D – Opening 24"W X 24-3/8"H. Two Door, One Large Open Shelf, Three Bottom Drawers. Note: Drawers May Be Removed To Accommodate Double Ovens.

Rollout Tray




Model	Description
RS21	RS21 – Rollout Tray – 20"W X 21"D X 3-1/4"H

33"W Oven Pantry Cabinets




Model	Description
SW-O338424	Shaker White – Oven Pantry – 33"W X 84"H X 24"D – Opening 24"W X 24-3/8"H. Two Door, One Large Open Shelf, Three Bottom Drawers. Note: Drawers May Be Removed To Accommodate Double Ovens.

Rollout Tray




Model	Description
RS24	RS24 – Rollout Tray – 23"W X 21"D X 3-1/4"H

33"W Oven Pantry Cabinets




Model	Description
SW-O339024	Shaker White – Oven Pantry – 33"W X 90"H X 24"D – Opening 24"W X 24-3/8"H. Two Door, One Large Open Shelf, Three Bottom Drawers. Note: Drawers May Be Removed To Accommodate Double Ovens.

Rollout Tray




Model	Description
RS27	RS27 – Rollout Tray – 26"W X 21"D X 3-1/4"H

33"W Oven Pantry Cabinets



Model	Description
SW-O339624	Shaker White – Oven Pantry – 33"W X 96"H X 24"D - Opening 24"W X 24-3/8"H. Two Door, One Large Open Shelf, Three Bottom Drawers. Note: Drawers May Be Removed To Accommodate Double Ovens.

Fluted Tall Filler




Model	Description
SW-FF396	Shaker White - Fluted Tall Filler - 3"W X 96"H

Chrome Tray



Model	Description
Chrome Tray 33	Chrome Tray 33. Add To ERB For Lazy Susan

Fluted Tall Filler




Model	Description
SW-FF396	Shaker White - Fluted Tall Filler - 3"W X 96"H

Chrome Tray



Model	Description
Chrome Tray 33	Chrome Tray 33. Add To ERB For Lazy Susan

Filler




Model	Description
SW-F342	Shaker White - Wall Filler - 3"W X 42"H

Chrome Tray




Model	Description
Chrome Tray 36	Chrome Tray 36. Add To ERB For Lazy Susan

Filler



Model	Description
SW-F642	Shaker White - Wall Filler - 6"W X 42"H

Tall Filler




Model	Description
SW-F396	Shaker White - Tall Filler - 3"W X 96"H
SW-F696	Shaker White - Tall Filler - 6"W X 96"H

Toe Kick




Model	Description
SW-TKC	Shaker White - Toe Kick 8' Plywood - 1/4"D X 4 1/2"H X 96"W

Base Decorative Door Panel




Model	Description
SW-BDEP	Shaker White - Base Decorative Door Panel - 23-1/2"W X 29"H X 3/4"D

Wall Decorative Door Panel




Model	Description
SW-WDEP30	Shaker White - Wall Decorative Door Panel - 12-3/4"W X 29"H X 3/4"D
SW-WDEP36	Shaker White - Wall Decorative Door Panel - 12-3/4"W X 35"H X 3/4"D
SW-WDEP42	Shaker White - Wall Decorative Door Panel - 12-3/4"W X 41"H X 3/4"D

Tall Decorative Door Panel




Model	Description
SW-TDEP2484	Shaker White - Tall Decorative Door Panel - 23-1/2"W X 78-1/2"H X 3/4"D
SW-TDEP2490	Shaker White - Tall Decorative Door Panel - 23-1/2"W X 84-1/2"H X 3/4"D
SW-TDEP2496	Shaker White - Tall Decorative Door Panel - 23-1/2"W X 90-1/2"H X 3/4"D

Refrigerator End Panel




Model	Description
SW-REPV2496	Shaker White - Refrigerator End Panel - 1-1/2"W X 96"H X 24"D Plywood With 1-1/2"W Filler
SW-REPV2796	Shaker White - Refrigerator End Panel - 1-1/2"W X 96"H X 27"D Plywood With 1-1/2"W Filler

Dishwasher Return Panel




Model	Description
SW-DWR3	Shaker White - Dishwasher Return Panel - 3"W X 34-1/2"H X 24"D Plywood With 3"W Filler

Base Skin Veneer Panel




Model	Description
SW-BSV	Shaker White - Base Skin Panel - 1/4"D X 34 1/2"H X 23 1/4"W

Wall Skin Panel




Model	Description
SW-WSV42	Shaker White - Wall Skin Panel - 1/4"D X 42"H X 15"W

Tall Skin Veneer Panel




Model	Description
SW-USV2496	Shaker White - Tall Skin Panel - 1/4"D X 96" X 23 1/4" W

Finish Plywood Panel




Model	Description
SW-FPV4296	Shaker White - Finished Plywood Panel - 42"W X 96"H X 1/4"D

Shelf Board




Model	Description
SW-S2496	Shaker White - Shelf Board - 3/4"D X 96"H X 24"W

Cove Crown Moulding




Model	Description
SW-COV	Shaker White - Cove Crown Moulding - 3 1/2"D X 3 5/8"H X 96"W

Crown Moulding




Model	Description
SW-CM8	Shaker White - Crown Moulding - 2-1/8"D X 1 7/8"H X 96"W

Angle Crown Moulding




Model	Description
SW-ACM8	Shaker White - Angle Crown Moulding - 2 1/2"D X 2 1/2"H X 96"W

Angle Light Rail Moulding




Model	Description
SW-ALRM8	Shaker White - Angle Light Rail Moulding - 2"D X 96"W

Light Rail Moulding




Model	Description
SW-LRM8	Shaker White - Light Rail Moulding - 2 1/4"H X 3/4"D X 96"W

Outside Corner Moulding




Model	Description
SW-OCM8	Shaker White - Outside Corner Moulding - 96"W X 3/4"H X 1/8"D

Rope Moulding




Model	Description
SW-ROPE	Shaker White - Rope moulding - 3/8"D X 3/4"H X 96"W

Dentil Moulding




Model	Description
SW-DMTIS	Shaker White - Dentil moulding - $\frac{3}{8}"$ D X $1\frac{1}{16}"$ H X 96"W

Furniture Base




Model	Description
SW-FBM	Shaker White - Furniture Base Moulding - $\frac{3}{4}"$ D X $4\frac{1}{2}"$ H X 96"W

Decorative Moulding




Model	Description
SW-BCM8(DCM)	Shaker White - Decorative Crown Moulding - 2 3/8"D X 3 17/32"H X 96"W

Inset Crown Moulding




Model	Description
SW-RCM4S(LCM)	Shaker White - Inset Crown Moulding - 2 1/2"D X 3-5/16"H X 96"W

Shoe Moulding




Model	Description
SW-SHM	Shaker White – Shoe Moulding – 1 1/16"D X 1 1/16"H X 96"W

Scribe Moulding




Model	Description
SW-SM8(SCR)	Shaker White – Scribe Moulding – 1/4"D X 3/4"H X 96"W

Batten Moulding




Model	Description
SW-BAM	Shaker White - Batten Moulding - 1/4"D X 3/4"H X 96"W

Corbel - Cb9




Model	Description
SW-CB9	Shaker White - Corbel - 3"W X 9"H X 9"D

Corbel - Cbt




Model	Description
SW-CBT	Shaker White - Corbel - 3-1/8"W X 13-1/16"H X 5-7/8"D

Bead Board Panel




Model	Description
SW-BBFPV4296	Shaker White - Finished Bead Board Plywood Panel-96"W x 42"H x 1/4"D

Classic Decorative Leg




Model	Description
SW-CLDL	Shaker White - Classic Decorative Leg - 3"W X 3"D X 34 1/2"H

Fluted Decorative Leg



Model	Description
SW-FLDL	Shaker White - Fluted Decorative Leg - 3"W X 3"D X 34 1/2"H

Arched Valance




Model	Description
SW-VA30	Shaker White - Arched Valance - 3/4"D X 6"H X 30"W
SW-VA36	Shaker White - Arched Valance - 3/4"D X 6"H X 36"W
SW-VA42	Shaker White - Arched Valance - 3/4"D X 6"H X 42"W
SW-VA48	Shaker White - Arched Valance - 3/4"D X 6"H X 48"W

Corner Sink Base Floor



Model	Description
SW-SBF4242	Shaker White - Corner Sink Front Floor - 42"W - Goes With DCSF42


Glass Holder



Model	Description
-------	-------------

SW-SGH30	Shaker White - Stem Wine Glass Holder - 30"W X 1-1/2"H X 12"D - Mounts under any 30"W Wall Cabinet.
----------	---

Knee Drawer



Model	Description
-------	-------------


SW-VKD36	Shaker White - Knee Drawer - 36"W X 7"H X 21"D
----------	--

Vanity Base Decorative Door Panel



Model	Description
SW-VDEP	Shaker White – Vanity Base Decorative Door Panel – 20 1/2"W x 29"H

Floating Shelf




Model	Description
SW-FS24	Shaker White – Floating Shelf–24"W x 2-1/16"H x 12"D
SW-FS30	Shaker White – Floating Shelf–30"W x 2-1/16"H x 12"D
SW-FS36	Shaker White – Floating Shelf–36"W x 2-1/16"H x 12"D

Touch Up Kit



Model	Description
SW-TUK	Shaker White - Touch Up Kit

Wall Skin Panel




Model	Description
SW-WSV30	Shaker White - Wall Skin Panel - 15"W x 30"H x 1/4"D
SW-WSV36	Shaker White - Wall Skin Panel - 15"W x 36"H x 1/4"D

Vanity Sink Base




Model	Description
SW-VS24	Shaker White - Vanity Sink Base Cabinet - 24"W X 21"D X 34-1/2"H With 2 Door And 1 Dummy Drawer
SW-VS27	Shaker White - Vanity Sink Base Cabinet - 27"W X 21"D X 34-1/2"H With 2 Door And 1 Dummy Drawer
SW-VS30	Shaker White - Vanity Sink Base Cabinet - 30"W X 21"D X 34-1/2"H With 2 Door And 2 Dummy Drawer
SW-VS33	Shaker White - Vanity Sink Base Cabinet - 33"W x 34 1/2"H x 21"D
SW-VS36	Shaker White - Vanity Sink Base Cabinet - 36"W X 21"D X 34-1/2"H With 2 Door And 2 Dummy Drawer

2 Doors Vanity Combo Cabinets




Model	Description
SW-VSD36	Shaker White - Vanity Combo - 36"W X 21"D X 34-1/2"H With 2 Door, Drawer And 1 Dummy Drawer
SW-VSD42	Shaker White - Vanity Combo - 42"W X 21"D X 34-1/2"H With 2 Door, Drawer And 1 Dummy Drawer
SW-VSD48	Shaker White - Vanity Combo - 48"W X 21"D X 34-1/2"H With 2 Door, Drawer And 1 Dummy Drawer

1 Door Vanity Combo Cabinets – 3 Left/Right Side Drawers




Model	Description
SW-V302IDL	Shaker White – Vanity Combo – 30"Wx21"Dx34-1/2"H 1 door, 3 Drawers on Left
SW-V302IDR	Shaker White – Vanity Combo – 30"Wx21"Dx34-1/2"H 1 door, 3 Drawers on Right

Vanity Combo Cabinets – Left Side Drawers




Model	Description
SW-V332IDL	Shaker White – Vanity Sink Base – 33"W x 34 1/2" x 21"D – 1D, 3 Left DRW

Vanity Combo Cabinets – Right Side Drawers




Model	Description
SW-V3321DR	Shaker White – Vanity Sink Base – 33"W x 34 1/2" x 21"D – 1D, 3 Right DRW

Vanity Sink Drawer Base Drawer Combo – Three Left/Right Drawer



Model	Description
SW-V3621DL	Shaker White – Vanity Combo – 36"Wx21"Dx34-1/2"H 2 door, 3 Drawers on Left
SW-V3621DR	Shaker White – Vanity Combo – 36"Wx21"Dx34-1/2"H 2 door, 3 Drawers on Right

Vanity Drawer Base Cabinets



Model	Description
SW-3VDB12	Shaker White - Vanity Drawer Base - 12"W X 21"D X 34-1/2"H With 3 Drawer
SW-3VDB15	Shaker White - Vanity Drawer Base - 15"W X 21"D X 34-1/2"H With 3 Drawer
SW-3VDB18	Shaker White - Vanity Drawer Base - 18"W X 21"D X 34-1/2"H With 3 Drawer
SW-3VDB21	Shaker White - Vanity Drawer Base Cabinet - 21"W x 34-1/2"H x 21"D - 3 Drw
SW-3VDB24	Shaker White - Vanity Drawer Base Cabinet - 24"W x 34 1/2"H x 21"D - 3 DRW

Waste Bin



Model	Description
-------	-------------

Waste Bin - Al Waste bin

Shelf Board



Model	Description
Shelf Board – W	Shelf Board – Wall Cabinet 36"W x 22"H x 1/4"D
Shelf Board – B	Shelf Board – Base Cabinet 48"W x 10"H x 7/8"D

Skin Panel



Model	Description
Skin Panel-Interior	Skin Panel – Natural finish with clear UV coating – 48"W x 48"H x 1/4"D