

Directions

The “**U-Can Handle and Receiver™**” uses leverage to make a rolling can easier to move.

There are two separate pieces, Handle and Receiver


Handle



Receiver



Receiver parts and pieces



Directions


Set up procedure:

1. Wet long strap. This allows the nylon to stretch.
2. Take the long support strap and put on top of the trash can.




Directions

3. Hold the receiver bar and wrap the height-adjusting strap (short strap) around the middle of the trash can handle. Note: Adjusting the height of the receiver allows the U-Can handle to have a clear pathway through the barrel handle. Tighten the lock height strap through the ladder lock.





Directions

This is the correct alignment for the receiver to go through the barrel handles.



Directions

4. Wrap the large support strap around the can and then pull the loop handle on the strap to tighten the large strap. Make the strap as tight as possible. For best results, tighten the strap in the coolest part of the day, Wrap any slack so it does not dangle. Once receiver is secured and centered in place, it will stay with the can. **No need to remove receiver.**



Directions

5. Slide the U-Can handle into the receiver.



6. Take the locking pins and slide them through the receiver and handle. This will keep the handle locked in place for pushing and pulling.



Directions

Now you're ready to roll a heavy can!



Once at the curb, take the handle off when the can is ready to be picked up by the collection people.

Notes:

The locking pins can be put through the holes in receiver for storage.

The handle is detachable from the receiver to allow the trash truck to fully empty can.

The receiver with the long strap stays on garbage can.

Patent pending.

For more information contact,

Javier Arrieta