

HEFTMATE PIANOLIFT OPERATING MANUAL 1/2



01

Place the Piano Lift in front of the piano. Also place the Dolly within easy reach.



02


Move the Piano Lift forward until the lifting fork is fully positioned under the piano as far as it will go. Extend the foot pedal.



03

Use your foot to use the pump until the lift rises and the lift reaches the highest position.

HEFTMATE PIANOLIFT OPERATING MANUAL 2/2



04

Place the Dolly under the piano. Make sure that the dolly is positioned against the frame of the Piano Lift.



05

Lower the lift by pressing the left pedal. The piano is now on the Dolly.



06

Fold down the foot pedal of the Piano Lift. Move the Piano Lift backwards until it is completely out from under the piano. The piano is now ready to be transported on the Dolly.

HOW TO USE THE PIANOLIFT


Step 2



Step 4



Step 6



Step 1



Step 3



Step 5



Step 7

