OWNER OPTIONS USER GUIDE

OWNER OPTIONS – CONTENTS (12-12-2024)

Page.

OWNER OPTIONS CONTENTS

OWNER OPTIONS OVERVIEW

OWNER OPTIONS OVERVIEW

The **OWNER OPTIONS** menu allows the owner to set various parameters on the **ONIS** which will provide the users with a consistent secured device across the fleet.

Most options are a "check box" to enable / disable and each option has an adjacent help option with the " ? "

# OWNER OPTIONS OVERVIEW

OWNER OPTIONS MENU

OWNER OPTIONS MENU

Set the user message text colour to display the selection menu.

Open Import / Export Menus.

OWNER OPTIONS

? **IMPORT / EXPORT GEOFENCE SPEED ALERTS**

? **IMPORT / EXPORT GEOFENCE MESSAGES**

Option		Option	
Allow User To Disable "Geofence Messages"	☑ ?	Enable "Geofence Message Capture Tool"	☐ ?
Allow User To Disable "Speed Alert System"	☑ ?	Enable "Geofence Speed Alert Capture Tool"	☐ ?
Allow User To Disable "Geofence Speed Alerts"	☑ ?	Enable "Save & Edit Tracklogs" (Owner Mode)	☐ ?
Allow User To Enable "110 km/h Max Speed"	☑ ?	Enable "Save & Edit Waypoints" (Owner Mode)	☐ ?
SET MESSAGE TEXT COLOUR Allow User To Disable "Fatigue Timer"	☑ ?	Enable ONIS "Startup Message"	☐ ?
Allow users To RESET "Fatigue Timer"	☑ ?	Enable ONIS "Information Startup Tips"	☑ ?
Allow User To Set "Speed Alert Tolerance"	☑ ?	Enable "Speed & Location Data Logging"	☑ ?
Auto ☑ Allow Update "WWW Data" Manual	☑ ?	Enable Navigation App "Startup Password"	☐ ?
Allow User To Set "Time Zone"	☑ ?	**USER GUIDE** Enable "Settings Menu Password"	☐ ?
		Enable "Owner Menu Password"	☐ ?

Exit to the settings menu. document.

Select on ? description buttons to display explanations.

Help document.

Set check box's to enable / disable options.

OWNER OPTIONS MENU

IMPORT GEOFENCE SPEED ALERTS

IMPORT GEOFENCE SPEED ALERTS

The ''Import Geofence Speed Alerts'' allows the owner to import data that has been configured on a PC.

Typically, this data will have been configured using the PC version of ***OziExplorer*** and then saved in the OziExplorer waypoint format.

The owner can then import this waypoint data and the ***ONIS*** will then perform the calculations to convert the waypoint data into the CSV format required by the ***ONIS***. The owner has the choice of either appending the data to the existing data set, or replacing the data entirely.

Each option has a '' ? '' which outlines the requirements of the import data file.

IMPORT GEOFENCE SPEED ALERTS

Import / Export Geofence Speed Alerts (OziExplorer Waypoint Format)

18:03:26

Import & Fill Between Waypoints
(Geofence7 User Speed Alerts) **?**

Import Geofence7
User Speed Alerts **?**

Import & Fill Between 4 Waypoints
(Geofence6 User Speed Alerts) **?**

Import Geofence8
User Speed Alerts **?**

Export Geofence
User Speed Alerts **?**

Import Geofence9
User Speed Alerts **?**

Exit back to
Owner Options.

Select on ? description buttons
to display explanations.

IMPORT GEOFENCE SPEED ALERTS

IMPORT GEOFENCE MESSAGES

IMPORT GEOFENCE MESSAGES

The "Import Geofence Messages" allows the owner to import data that has been configured on a PC.

Typically, this data will have been configured using the PC version of *OziExplorer* and then saved in the OziExplorer waypoint format.

The owner can then import this waypoint data and the *ONIS* will then perform the calculations to convert the waypoint data into the CSV format required by the *ONIS*. The owner has the choice of either appending the data to the existing data set, or replacing the data entirely.

Each option has a " ? " which outlines the requirements of the import data file.

IMPORT GEOFENCE MESSAGES

Import / Export Geofence Messages (OziExplorer Waypoint Format)

Import & Fill Between Waypoints (Geofence7 User Messages) ?

Import Geofence7 User Messages ?

Import & Fill Between 4 Waypoints (Geofence6 User Messages) ?

Import Geofence8 User Messages ?

Export Geofence User Messages ?

Import Geofence9 User Messages ?

Exit back to Owner Options.

Select on ? description buttons to display explanations.