

Part Number	Alternate Part Number	CD	QTY	Part Description
382		NS	8	LAMP
415	MODEL415	SV	2	DB SYSTEMS AMP, AUDIO CTL
647.7820		NE	1	CROSS BRACKET AFT
904	SFENA	OH	1	INDICATOR, HORI
1172	11729LW	SV	1	NAV IND
1550		NS	1	SWITCH
1638		NS	1	ANNUNCIATOR HOIST
2342		SV	4	SWITCH
2772		NS	31	GROMMET
2790		SV	2	GPS, GYPSI/LESS HANDHELD
2793		SV	2	GYPSI 406 WITH GPS
2820		SV	8	PRESSURE SWITCH
3641		NE	8	HEATING CARTRIDGE ASSY
3641		SV	1	HEATING CARTRIDGE ASSY
5039	6615-99-712-8802	OH	4	VERTICAL GYRO
5039	NDN5039	OH	4	VERTICAL GYRO
5420		SV	1	LABEM UNIT
6920	63405	SV	1	SOLENOID VALVE
7030		SV	1	VSI
8047		OH	1	ALTIMETER
8047		OH	1	ALTIMETER
8695		SV	1	TEMP POTENTIOMETER
9560		OH	1	TURN AND BANK
10401		SV	1	ANTENNA
10706		SV	2	ANTENNA, GPS, UNS-1D
12800		OH	1	FIRE EXTINGUISHER
15625		SV	1	TRIP & DATE ENCODER
16101		AR	1	AREA MIC
16305		AR	1	STATIC WICK
020706		SV	1	JUNCTION BOX
24918		AR	1	FUEL PUMP POWER DRIVEN
026953	S0085-101	SV	2	FAN
30510		SV	1	STATIC DEFECT CORRECTION MOD
31483		OH	1	ADF INDICATOR
32734		SV	1	FUEL FLOW IND
033203	BC407/332	OH	1	AMETEK ROTRON INVERTER
37100		SV	1	VHF GUARD RX
37462		SV	2	V-H-F ANT-FEED UNIT
38194		SV	1	VHF HOMER IND-
45900		OH	1	LIGHT BEACON
48165	1560-055-1616	NE	2	REELS SHOULDER HARNESS
2033-1-1		SV	1	RF/IR REMOTE CONTROLLER
050026		AR	1	TIMER

56108		SV	1	RMI
61148.100		SV	1	ELECTRONIC UNIT
66501		SV	1	VDO INDICATOR
71428		SV	1	BRAKE MANIFOLD
76803		NE	3	CONTROL HANDLE
76955		SV	2	SARBE BEACON
78340		SV	1	SARBE BEACON
81021		NE	10	MICROPHONE COCKPIT RCRDR
81835	81835AOIA	SV	1	RACAL SATFONE FAX
90073	CMA-1100	NS	1	I/O CABLE ASSY
97167	704A44820006	OH	1	RELAY, BREAKING CURCUIT
99400	SAC69	SV	1	AUTO ANT TUNER
99897	SCU10	SV	1	HF CONTROL
99912		AR	2	TRANCEIVER
100140		SV	1	D1000 MODEM UNIT
100160		SV	1	CONTROL HEAD
102138		OH	1	FREE AIR TEMP IND
105145		AR	2	SPEAKER
106183		SV	1	TRANSFORMER
111302		OH	1	H-S-I-
115412		OH	1	CARB AIR TEMP IND
118600	214-075-231-7	OH	3	INDICATOR, COURSE SELECTOR
125780		OH	1	GYRO INDICATOR
125810		OH	1	GYRO INDICATOR
129222	222-375-041-1	SV	2	H-S-I-
129920		OH	1	ATTITUDE INDICATOR
132890		OH	1	HORIZONTAL SITUATION INDCATOR
133640		OH	2	H-S-I-
137783	5998-00-337-5820	SV	1	CIRCUIT CARD ASSEMBLY
137896	5998-00-337-5821	SV	1	CIRCUIT CARD ASSEMBLY
137902	5998-00-339-6967	SV	1	DECODER CIRCUIT A5
137908	5998-00-339-6969	SV	1	CIRCUIT CARD ASSEMBLY
137914	5998-00-337-5822	SV	1	CIRCUIT CARD ASSEMBLY
137944	5998-00-337-5832	SV	1	CIRCUIT CARD ASSEMBLY
138614	5998-00-337-5928	SV	2	BUILT IN TEST CIRCUIT CARD
138644	5998-00-337-6018	SV	1	CIRCUIT CARD ASSEMBLY
139658	5998-00-339-7006	SV	1	CIRCUIT CARD ASSEMBLY
139837	5998-00-335-7385	SV	1	CIRCUIT CARD ASSEMBLY
143224	MS28004-1	OH	1	INDICATOR TEMP
150615	5998-00-558-5864	SV	1	CIRCUIT CARD ASSEMBLY
150630	5998-00-558-5865	SV	1	CIRCUIT CARD ASSEMBLY
150638	5998-00-558-5851	SV	1	CIRCUIT CARD ASSEMBLY
160154		NE	1	LOCK DOOR
176188		SV	3	ACTUATOR, LINEAR

180806		SV	1	AMP ASSY
196716	5826-00-952-3709	OH	1	ID-1103/ARN INDICATOR
213565	213723	SV	1	ENGINE SYNC UNIT
213778	213787	SV	1	ENGINE SYNC UNIT
215544	213723	SV	1	ENGINE SYNC UNIT
260128		OH	1	WINCH LOAD INDICATOR
271927	271927	NS	17	IGNITERS
280701		NE	1	50 WATT LAMP
306023		NE	1	GASKET
310102		NS	1	SWX INSERT
310140		NS	1	BUTTON
311601		NE	100	CABLE
320562		NS	100	SPLICE
407240		SV	1	CONTROL UNIT, SIGNAL DEICING
416159		NE	1	CELL EXTRACTION TOOL
3040-05-02		SV	2	COCKPIT DISPLAY COMPUTER
3040-06-02		SV	1	APPLICATION SERVER UNIT
450004		SV	2	REMOTE
7-3133		SV	1	ACTUATOR, ROTARY
508534	1159SCAV381-3	SV	3	FAN MODULE
508617		SV	3	FAN MODULE
521645		NE	3	INDICATOR
521645		OH	1	INDICATOR
522246		SV	1	POWER SUPPLY
536834	A141936	NE	2	SLEEVE
3402-1-1		SV	1	VIDEO RECORDER MULTI SYSTEM
550986		NE	1	RAD ANGULAR BALL BEARING
610000	1666955	SV	1	7" BLOWER ASSEMBLY DC BRUSHLESS
616042		NS	1	CONNECTOR INSERT
618050		NS	14	CONTACT
656520		SV	3	FLUX VALVE
707395		NE	1	BURIN
707718	222-375-012-101	SV	1	DIMMER POWER SUPPLY
710104		OH	1	MOTOR
725222		SV	1	HOMING UNIT, VHF
728221		SV	1	RECEIVER VHF/AM
744619		NE	1	CONNECTOR
749823	704A47653101	SV	1	UNIT, FUEL INDICATORS
764591	7050C4284022	SV	1	GAGE, LOWER FUEL TANK
782013		NE	1	WHEEL WITH COMPONENT
794166	704A47651046	NE	1	FUEL GUAGE
800567		NE	1	STATIC SHIELDING
843772	76550-01001-103	SV	1	MASTER CAUTION/ADVISORY PANEL
902205		SV	1	CABIN DISTRIBUTION BUS RPT

912000		SV	4	AIRSHOW VIDEO SWITCH
912001		NE	1	AIRSHOW VIDEO SWITCH
914026		SV	1	AIRSHOW MOUNT
938012		SV	1	LAB TOP CABLE
962600		NE	1	ICG KIT
962601		NE	2	ICG KIT
1007783	3009514	SV	1	ANTENNA CONTROL UNIT
1122505		SV	1	TEMP PROBE
1242346		NS	1	GASKET
6001-1-1		SV	1	DISPLAY SWITCHING UNIT
1510113		NE	1	EXTERIOR MIRROR
6123-1-1		SV	4	COMM CTL
1741394		NE	1	BRACKET ASSY
1775143		SV	2	POWER SUPPLY
1775277		SV	4	FLUX VALVE
7-8159		NS	1	RECEIVER DRYER
7-8159		SV	1	RECEIVER DRYER
2593379		OH	1	DUAL REMOTE COMPENSATOR
3022375		NS	2	SEAL
3039305		NE	1	SENSOR
3039310		SV	1	LOW FUEL PRESSURE SWITCH
3043013		OH	1	BLEED VALVE
3066671		NE	1	RESISTOR
3071434		AR	1	CHIP DETECTOR
3073728		NS	1	TUBE
3201104		SV	2	JUNCTION BOX
3202311		NE	1	FLIR KIT
3202315		NE	1	FLIR KIT
3205495	3205495K	NE	2	FLIR KIT
3205581		NE	2	FLIR CONNECTOR KIT
3322412	5340-01-179-3507	NS	10	BUMPER
3322577	5845-01-178-9418	NS	10	COVER
3322599	5315-01-102-0448	NS	10	PIN
3329802		NS	30	CAP
3329806	8330-01-179-1455	NS	20	GASKET
4002001		SV	1	AP05VC-032-01
4002001		OH	1	AP05VC-032-01
4012566		FN	1	BRUSH ASSY
4016636		NS	1	LENS
4103052		NE	1	RECEIVER DRYER
4171072	704A46820007	OH	1	LANDING LIGHT
4202104		OH	5	LIGHT, LANDING
4217212	704A46820022	SV	1	LIGHT RETRACTABLE
4217228		OH	4	LANDING LIGHT

4361646	L334M3820101A003	SV	1	LANDING LIGHT
5006052	6150-01-103-1066	NE	3	CABLE ASSY
6004137		SV	1	BRAKE TEMP MONITOR IND
6020277		NE	1	LOCKING BARREL CATCH
6815120		SV	1	PHASE DETECTOR TORQUEMETER
6896482		NS	1	PLUG
7001483	412-001-304-101	OH	1	ACTUATOR ASSY
7024317		NS	1	SCREW CAP
7513260		NE	1	FILTER
7583740		NE	1	FILTER ELEMENT
7672892		NE	1	FILTER ELEMENT
8002826		NS	50	HLDR
8011899	5365-01-358-1238	NS	5	RETAINER DISC
8014053	5365-01-336-0136	NS	20	RETAINER
8014054	5365-01-371-5993	NS	20	RETAINER
8014055	5365-01-335-4173	NS	20	STRAP
8015238		SV	3	TDL-711 RCU
8032705		SV	1	ALLIED SIGNAL TEST BOX
9535061		NS	4	SEAL
9543973		NS	6	PLATE
9550904		OH	1	MLG BRAKE
30300014	IFR-485-05-1	SV	1	AUDIO INTL
30300038	BBK-2AH	SV	1	AUDIO MODULE
30300051	VA-400-1	SV	1	AUDIO INTL PANEL
30300078	AI-PS13-5-3	SV	1	AUDIO INTL MODULE
30300257	AI-PS12-3	SV	1	POWER SUPPLY
30300542	AI-VC-202-1	SV	3	AUDIO INTL PANEL
30500007	MDC-102-CH-1	SV	1	MULTI CD CHANGER
30500042	MCD-104-01-1	SV	1	CD PLAYER
30803829		SV	1	CONTROL PANEL
42623001		SV	2	CO2 CYLINDER
73844911		SV	1	UNIT CONTROL
75003298	64869-75003298	NE	1	LASER INTERLOCK REV B
83303139		NE	1	CONNECTOR
91000132		SV	1	NAV DATA LOADER
93400012		SV	1	TNL561 PLUS SYNCRO
0164247810		NE	1	COMPLETE FILTER
164548610		NE	3	FUEL CONTROL UNIT
174128150		AR	1	BLEED VALVE
177555120	6790623827	SV	1	OVERSPEED UNIT
0177987120		NE	2	CARD ASSY
0292117300		SV	1	FRONT SUPPORT
292687250	0292687250	NE	2	VALVE ASSY
319307840		SV	1	IGNITION INJECTOR

0319727970
319738330
319739400
319739560
0319850750
390242411
401287200
616785024
619051001
619054001
620022001
620075011
639493002
750133040
4107201222
4619002005
4619002005
4619003003
4619003003
4619003005
4619003005
4619003005
4619003005
4619208044
4619303081
4619310070
4619310072
4619311033
4638202007
4638302013
4638302093
4639001006
4639002001
4639002001
4639002005
4639003001
4639003007
4639205007
4639302052
4639306032
4639310005
4639310039
4649199001
4649208024
6700516000

NE 1 DRAIN PLUG
SV 4 HALF MANIFOLD, RIGHT INJECTOR
SV 1 RIGHT HALF FUEL MANIFOLD
AR 1 HALF MANIFOLD ASSY
SV 1 VALVE PUMP AND METERING ASSY
NE 1 WISCHERMOTOR
SV 1 REAR PLATE
NS 20 RADIALL CONN INSERT
NS 10 COAXIAL CONTACT
NS 4 COAXIAL CONTACT
NS 5 RADIALL CONN INSERT
NS 7 COAXIAL CONTACT
NE 2 DRAIN OIL
NE 1 FREEWHEEL UNIT
NE 5 02 REPAIR KIT - BEACON MEDAS
SV 1 INTERMEDIATE GEAR
AR 3 INTERMEDIATE GEARBOX
SV 3 TAIL ROTOR TRANSMISSION
SV 3 TAIL ROTOR GEARBOX
SV 1 TAIL ROTOR TRANSMISSION
NE 1 TAIL ROTOR GEARBOX
AR 1 TAIL ROTOR GEARBOX
NE 2 DRAIN HOSE
NE 1 ROLLER BEARING
NE 1 ROLLER BEARING
NE 3 ROLLER BEARING
NE 2 ROLLER BEARING
NE 3 FREEWHEEL-CLUTCH
SV 1 FREEWHEEL UNIT SHAFT
NE 6 FREEWHEEL WAVE
SV 1 MAIN TRANSMISSION
AR 1 TAIL ROTOR GEARBOX
OH 1 TAIL ROTOR GEARBOX
OH 1 TAIL ROTOR GEARBOX
NE 1 TAIL ROTOR GEARBOX
OH 2 TAIL ROTOR TRANSMITION
NE 1 SPACER TUBE
NE 1 FREEWHEEL SHAFT
NE 8 RING
NE 5 BEARING
NE 1 OIL SIGHT GLASS
NE 1 HARDWARE
NE 1 OIL PUMP
SV 1 INDICATOR, PRESSURE MB

6720004203		SV	2	ELECTROVALVE
6787300603		SV	1	VOLTAGE REGULATOR
6790623827		SV	1	OVERSPEED UNIT
8527400997		NE	1	OIL FILTER
8818457000		NE	1	POCKET ORESSURE GAUDE ASSY
8819329000		NE	1	ENGINE FRAME
9550166110		NE	1	OIL PRESSURE SWITCH
9550166160		SV	1	IGNITER BOX
9550171420		SV	1	TRANSMITTER P3
9550172970		NE	1	SPEED SENSOR (N1,N2) 1 NT
9560150490		SV	1	CLOGGING INDICATOR
9560170580		NE	1	MAGNETIC SEAL
9560176640		NE	1	HYDRODYNAMIC MAGNETIC SEAL
9580111170		SV	1	CLOGGING INDICATOR
9580114120		SV	1	ELECTRO VALVE
9580115210		NE	1	GENERATOR 1 NT
013020280010	7050A4331006	SV	1	POWER SUPPLY BLOCK
25000010010	704A46814115	SV	1	LIGHT PANEL
35093370700		SV	1	TOOL
70393000001		SV	1	WRENCH, SOCKET
526800163610		NS	3	SEAT BELT
864441835040		NE	1	RUBBER SEAL
56680016360012		NS	2	SEAT BELT
149E30	MS28006-1	SV	1	INDICATOR, TEMP
1945E245		SV	1	ROD END
000-8796-6		NE	2	SEAT COVERS
00-200-1050		NS	1	FILTER
005002-501	FERNO-12-2-AL16G	NS	2	STRETCHER
0100-002		SV	1	RECEPTICLE
010-00176-01		NS	3	GPS 500 black receiver w/rack
010-00286-01	GNS430A	NE	1	GNS430A NVG MOD.
010-01217-01		FN	1	GTX-345R ADS-B In/OUT Transponder
010-10201-06		NE	2	DATA CARD
01-0770028-05		AR	3	POWER SUPPLY
01-0770062-03		AR	2	POWER STROBE
01-0770285		SV	1	STROBE LIGHT
01-0770946-01		SV	1	LIGHT STROBE GRN LED
011-00582-00	GTX330	NE	1	BACKPLATE ASSY
011-00676-00	GNS430	NE	5	BACKPLATE ASSY
011-00676-01	GNS430	NE	1	BACKPLATE ASSY
011-00677-01		NE	2	BACKPLATE ASSY
011-00678-00		NE	1	BACKPLATE ASSY
011-00870-00		AR	1	MAGNETOMETER
011-00882-00		OH	1	GDU74A ADC

011-00979-03		NE	1	CONFIG MODULE
011-01060-00	010-00412-01	NE	5	GNS430W WITH INSTALL KITS
011-02278-01		SV	1	ARHS
011-02977-00	GTX335	NE	1	CONNECTOR KIT
011-04340-02	GTX345	SV	1	BACK PLATE W/ SCREWS
0130-2002-0010	1552644	SV	1	UNIT POWER SUPPLY
013-1885-010		SV	2	ANTENNA
0132NE		NE	1	OAT-SENSOR
017500-11	SX-16	SV	1	SEARCHLIGHT ASSY
01-768230		NS	1	GALLEY SWITCH
018-1394-010		NE	2	SHIELDING GASKET
01-P24481F001	PTRA-200	SV	1	MOTOROLA CONTROL PANEL
01R43129D02		SV	1	MOTOROLA CONTROL PANEL
0201992-001		OH	1	SEARCHLIGHT ASSY
0202644-005		SV	1	LANDING LIGHT AW139
02-0350034-00	A506	NE	2	STROBE BEACON
0204-0001		OH	1	HYDRAULIC RESERVOIR
0204-001		SV	1	HYDRO RESERVIOR
020-969-018	1159SCP460-18	SV	1	TANK UNIT FUEL QTY
02-1104-0006		NE	2	CABLE
02289-5600-S938		SV	1	RELAY, TIME DELAY
022TA1101	704A47723068	SV	1	FAILURE WARNING PANEL
0230191-001		SV	1	SEARCH LIGHT
0231102-004		SV	1	SEARCH LIGHT
023-138-842		NE	1	DTRESSCOVER MANGAN
024711-41	SX5	SV	1	SEARCHLIGHT ASSY
024711-41	030040	SV	1	SEARCHLIGHT W GIMBAL ASSY
024918-107		AR	1	PUMP ROTARY POWER DRIVEN
025234-11	SX5	SV	1	JUNCTION BOX ASSY
025323-150		AR	1	FUEL PUMP
02W101633		SV	1	FILTER
030-01184-0011		NS	3	PIN
030-02070-0005		NS	3	CONNECTOR
030-02250-0000		NS	1	CONNECTOR
030-02350-0062		NS	1	CONNECTOR
030-02351-0004		NS	1	HOOD/LVR-ASSY
0300-402		SV	1	ROSEN PANEL
03024473-0002		NS	1	CONNECTOR KIT
03024473-0003		NS	1	CONNECTOR KIT
030-600-002		SV	1	PLINTH
030611-15-72	W8-2P2	NS	1	NIGHTSUN CABLE
030752-34-25		AR	1	CABLE ASSY SX-5
031-00785-0505		NS	3	ANNUCIATOR
03-1100-0002		NE	1	LAMP

03-12-1062		NS	20	CONNECTOR
033002-1		SV	1	PENDANT, NIGHTSUN XP
038-220-2800-H	MSA00552323PSMOHGA5	SV	6	ACCORDIA WINDOW SHADE
038-220-3100-A	MSA00552323	SV	6	ACCORDIA WINDOW SHADE
03-9002-0004		NE	5	LED POSITION LIGHT GREEN
03972-2496-1B		SV	6	OVERSPEED CONTROL
03G10S		NS	2	LOCK WASHER
04-1120-0028		AR	2	POWER SUPPLY
04-327W001	04-327F001	SV	1	EGPWS RELAY/FUSE BOX
047-06054-0001		NS	1	SPACER
047-07531-0000	047-7531-00	NS	1	TRAY
0476-A-00364	AMT50	SV	1	LNA/DIPLEXER
0476-F-00364	AS100500-01-180	SV	1	LNA/DIPLEXER
050-01854-0000	KI229	NE	1	INSTALL KIT
050-01855-0001	KTU709	NE	1	INSTALL KIT
050-01864-0002	KTS156	NE	1	INSTALL KIT
050-02121-0001	KTR993	NE	1	INSTALL KIT KTR993 CRIMP
050-02251-0000	KA676/KA678	NE	1	INSTALL KIT
050-03044-0001	KA90	NE	1	INSTALL KIT
050-03392-0000		NS	1	INSTAL KIT (26)
0501002A	DEFT-1	SV	1	ELT
050-160-0248		SV	1	UNIT, PDR60 WARNING
0501-786-954		NS	3	INSTALL KIT
050-3111-00	KA670	NS	1	KA670
0511-781-954		NS	6	INSTALL KIT
0514-901-954		NS	3	INSTALL KIT
052-00009-0004		NS	4	SHOCKMOUNT
0520-110-1085		NE	1	SEAT 180/260
0520-514B-102		NE	1	CUSHION
055-1800-001		SV	2	TRANSMITTER
057-0719-002		NS	4	BACKSHELL
060-0013-01	KSG105	OH	2	DIRECTIONAL GYRO
060-0015-00	KG-102A	SV	1	DIRECTIONAL GYRO
06076-90G001-01		NE	4	RAD ALT INSTALL KITS
062-0004-00	KU193	SV	1	COMM
064-01047-0001		NE	2	RECEIVER
064-01083-0101	ITU-100	SV	1	AIRSAT 1 TRANSCEIVER
064-1009-00	KTR905	AR	2	COMM TRANSCEIVER
064-1047-01	3614001-4002	NE	2	RECEIVER
064-1047-12	064-01047-0012	SV	1	VHF TRANSCEIVER
065-00063-0006		FN	4	Annunciator Panel Blk.
065-00157-0200	KLA570	AR	1	SERVO ACTUATOR
065-00157-0300	KLA570	AR	1	SERVO ACTUATOR
065-00157-0400	KLA570	AR	1	SERVO ACTUATOR

065-00158-0102	KCP520	SV	2	FLIGHT COMPUTER
065-00158-0202	KCP520	SV	1	FLIGHT COMPUTER
065-00159-0402	KMS-540	SV	2	MODE SELECT PANEL
065-00162-0100	KSA572	SV	1	SERVO ACTUATOR
065-00162-0200	KSA572	SV	1	SERVO ACTUATOR
065-00165-0100	KSM575	OH	1	PITCH ACTUATOR ASSY
065-00165-0200	KSM575	OH	1	ROLL ACTUATOR ASSY
065-00165-0300	KSM575	SV	1	ACTUATOR ASSY YAW
065-00167-0200	KSM575	OH	1	YAW ACTUATOR ASSY
065-00167-0800	KSM575	NE	3	ROLL LINEAR ACTUATOR
065-00167-0900	KSM575	NE	3	PITCH LINEAR ACTUATOR
065-0064-08	KCP220	SV	1	FLIGHT COMPUTER
066-01066-0002	066-1066-02	SV	1	KING KDM 706
066-01069-0002		SV	1	KDI 573
066-01078-0004		SV	1	RECEIVER (KNR634)
066-01143-0201	MST67A	SV	1	MODE S TRANSPONDER
066-01143-0601	MST67A	SV	1	TRANSPONDER
066-01153-0101	KRA405B	OH	1	RADIO ALTIMETER RCVR
066-01153-4001	KRA405B	OH	1	RADIO ALTIMETER RT
066-01171-2304	IVA81D	SV	1	TCAS DISPLAY
066-01198-0102		FN	4	KXP-2290A Mode "S" Diversity Transpon
066-01201-0105		FN	4	GPS Receiver (WAAS)
066-03031-0004	066-3031-04	NE	1	KNI 415 RAD ALT INF NVG
066-03044-0000	KNI416	NE	1	RAD ALT INDICATOR
066-03046-0013	066-3046-13	NE	1	KI525A H.S.I. NVG
066-03062-0008	066-3062-08	OH	1	KEA346 ENCODING ALTIMETER
066-03062-0009	066-3062-09	OH	1	KEA346 ENCODING ALTIMETER
066-03062-0010	066-3062-10	OH	1	KEA346 ENCODING ALTIMETER
066-03062-0011	066-3062-11	OH	1	KEA346 ENCODING ALTIMETER
066-03123-1500	ED-461	AR	1	EFIS INDICATOR
066-03123-1600		SV	1	EHSI
066-03125-2600	ED462	NE	3	DISPLAY
066-03125-2600		SV	1	EHSI/EADI
066-04031-1122	KLN90B	SV	1	GPS
066-1024-03		AR	1	AUDIO CONTROL
066-1045-00	KDD693	SV	1	DME RANGE CONVERTER
066-1061-03	KRA10A	SV	1	RAD ALT RCVR
066-1061-03	KRA10A	AR	2	RAD ALT RCVR
066-1069-00	KDI572	SV	1	DME IND
066-1072-00	KR87	AR	3	ADF RCVR
066-1091-04	KDI573B	SV	2	NAV INDICATOR
066-1101-00	3614004-4101	SV	1	NAV RCVR
066-1105-00	DF431B	SV	1	ADF RCVR
066-1107-12	DM441B	SV	1	DME RT

066-3024-09	KPI552	OH	1	PICTORIAL NAV IND
066-3024-17	KPI552	OH	1	PICTORIAL NAV IND
066-3024-40	KPI552	SV	1	PICTORIAL NAV INDICATOR
066-3027-14	KPI553	OH	1	PICTORIAL NAV IND
066-3032-10	KDI571	AR	1	INDICATOR
066-3034-02	KI204	SV	1	VOR LOC GS IND
066-3034-24	KI206	SV	1	IND
066-3044-01	KNI416	OH	1	RAD ALT IND KNI 416
066-3045-14	KPI553A	OH	1	PICTORIAL NAV INDICATOR
066-3048-07	KI525A	SV	1	H.S.I. INDICATOR
066-3054-01	KI-250	SV	1	RAD ALT INDICATOR
066-3054-01	KI250	AR	1	RAD ALT INDICATOR
066-3056-00	KI208	AR	1	VOR/LOC/GS INDICATOR
066-3060-00	066-03060-0000	OH	1	RMI INDICATOR
066-3063-01	KI227	SV	1	ADF IND
066-3069-09	KPI553B	OH	2	PICTORIAL NAV IND
066-3077-25	KAV485	OH	1	ALT/VS IND
066-3096-00	IU-2023B	SV	1	REMOTE COMP UNIT
066-4004-00	KN77	SV	1	VOR/LOC CONVERTER
066-4006-01	KNR665	SV	1	NAV RCVR
066-4007-02	KNR632	SV	1	NAV RCVR
066-4009-00		SV	6	VOR LOC CONV
066-4010-12	KNS-81	SV	1	NAV COMPUTER
069-01033-0101	KX165A	SV	1	NAV COMM
069-01033-0201	KX165A	SV	1	NAV COMM 8.33 KHZ
069-01037-0102		FN	4	KTR-2280 MULTI-MODE DIGITAL RADIO
069-1026-01		SV	1	KX99 RECEIVER
070-0900-001		SV	3	CPT900 ADELT BEACON-
071-0006-00		SV	1	DME CODE CONVERTER
071-00158-0211	KAC502	AR	3	EGPWS MODULE
071-00166-0411	KAC504	SV	1	TRAFFIC MODULE
071-00168-0311	KAC504	SV	1	TRAFFIC MODULE
071-0025-00	CA308	SV	1	TDR94A TEST SET/MODULE
071-0031-00	KDL569R	SV	1	TEST BOX
071-01283-0012	071-1283-12	SV	1	CONTROL UNIT
071-01283-0012	071-1283-12	NE	1	CONTROL UNIT(KFS564A)
071-01315-0000		OH	1	RS181A Radar R/T Unit
071-01505-0203	GC-362A	SV	1	GRAPHICS ADAPTER
071-01507-5202		FN	1	KFS-578A TCAS CONTROL HEAD
071-01508-0201	KA90	AR	1	H-S-I- APAPTER
071-01511-0101	CP469A	AR	1	CONTROL PANEL
071-01542-0401	CD671C	NE	7	TCAS-II DUAL BLK
071-01545-0100	KA91	SV	1	GPS ANTENNA
071-01546-0101	KFS599A	SV	1	UHF COMMUNICATION CONTROL

071-01596-0201		FN	4	Primary Flight Display (PFD) Controller
071-01598-0901		FN	2	Multi-Function Display (MFD)
071-01618-0105		SV	1	PS-578A Control Panel
071-01619-0022		SV	1	PS-550 Control head
071-04025-0001	071-4025-01	NE	6	MTG RACK w/ SHOCKMOUNTS
071-04030-0001	071-4030-01	NS	7	MTG RACK
071-04051-0000	071-4051-00	NE	1	NC104B MOUNTING TRAY
071-04054-0000		SV	1	MOUNTING TRAY
071-1033-00	KFS580	SV	2	CONTROL ADF
071-1034-00	KA36	SV	1	ANTENNA
071-1052-00		AR	1	FLUX VALVE
071-1059-00	DMPN3-3A	AR	1	KA54 ANT-
071-1066-00		SV	1	ADF CTL
071-1073-00		SV	1	SUPER FLAG ADAPTER
071-1148-00		SV	1	MATCHING ASSY
071-1215-70	KFS598	AR	3	COMM CONTROL
071-1216-12	KFS564	AR	1	NAV CONTROL
071-1242-01	KA51B	SV	2	SLAVING ACCY
071-1242-06		AR	1	SLAVING ACCY
071-1271-00	KA161	AR	1	EXTERNAL CAPACITOR
071-1272-00		NE	1	KAC992 WHIP ANTENNA
071-1274-01	KFS594	SV	2	HF CONTROL UNIT
071-1279-01	KA68A	NS	2	PROGRAMMER
071-1313-31		SV	1	GC-360A Radar Graphics Unit
071-1316-00	3614165-5510	SV	1	10IN ANTENNA ARRAY
071-1316-00	3614165-5510	SV	1	10IN ANTENNA ARRAY
071-1335-00	CP103D	SV	1	CONTROL
071-1347-07		AR	1	ADF CONTROL
071-1377-01	8095444-4102	SV	4	NAV CONTROL CD413B
071-1446-00	8095635-1001	SV	1	EFIS CONTROL PANEL
071-1523-03	071-01523-0003	SV	1	KLN90B DATA BASE
071-2007-00	KAA455	SV	2	AUDIO CONTROL SYSTEM
071-22000-01		SV	1	ANNUNCIATOR ASSY
071-4002-00		SV	1	MOUNTING TRAY
071-4004-00		SV	1	MOUNTING TRAY
071-4022-01		SV	1	MOUNTING TRAY
071-4025-01		SV	1	KG102A MOUNT
07148-11126-2	214-075-186-1	SV	1	CONTROL UNIT TEMP
073-00044-0001		SV	1	PLATE
073-00866-0002		NS	2	KNOB
075-1800-005A		SV	1	HEADSET
0811-A-0001	AMT-50	SV	1	ANTENNA CONTROL UNIT
081252-3-10	TDFM-136B	SV	1	VHF FM TRANSCEIVER
0871GA1		NE	1	ICE DETECTOR

089-06159-0003		NS	6	SCREW
089-06200-0002		NS	10	SCREW
089-06592-0003		NS	4	SCREW
08GSW		NS	3	BEARING
090-00499-0003		NS	1	RING
090-00540-999		SV	1	SHEPHERD VIGILANT
090-00556-900		SV	1	SHEPHERD VIGILANT
09168P-18		NE	1	MICROPHONE
096-2100-030	SCORPIO2000	SV	2	MICROCONTROLLER MODULE
099-114-101	BHT407	SV	2	MODULE
1000670-1-006	3050087-04	SV	1	CONTROL ELECTRONIC ENGINE
100-0701-01	SECURAPLANE	SV	1	CDU
100-0850-01		SV	1	SECURAPLANE BATTERY PACK
100-0850-01		SV	1	SECURAPLANE BATTERY PACK
100-1021-01		SV	1	VOICE RESPONSE UNIT
100-1057-01	SECURAPLANE	NS	1	CAMERA
100-1088-01	SLA3000	SV	1	BATTERY EMERGENCY
100-1101-212		AR	1	ATC CONTROL
1-002-0102-1605	4B3500-3E-NB-CM-1605	SV	1	CONVERTER, FREQUENCY, STATIC
1002-033	USA-2	SV	1	UNIVERSAL SWITCHING UNIT
100-43677		SV	1	SELF SEALING COUPLING
100-43686M4		SV	1	VALVE
100-478448-001		AR	1	CONTROL DISPLAY UNIT
100-601260-002		AR	1	GROUNDSPED DRIFTANGLE INDICATO
100-601600-504		SV	2	GNSSU CMA-3012 TSO C-129
100-601721-001		AR	1	CMA 3000
10062-1-B		SV	1	TRANSMITTER
10067146-103		NE	1	CIRCUIT BOARD
10-0815-5		SV	1	DOMELIGHT
100CC01A		SV	1	RELAY
100CC01A		NE	2	RELAY
101001-10	DEI01-10	SV	1	AUDIO SELECTOR PANEL
101-00153	1811FER	SV	1	PITOT STATIC TEST SET
101-00167A0A	1811HA0A	SV	1	PITOT STATIC TEST BOX
1010-1	UNS1	SV	1	CDU
10102-0000		SV	1	ADAPTER PLATE
10-102-3C		SV	1	ANTENNA
10-104-6		SV	1	ANTENNA
1012ZH	MODEL010012	NS	2	EFIS BLOWER
101-331-45-100		SV	1	COMM CONTROL
101-380027-1		AR	1	REG VALVE
101-380031-1	70002-0131	OH	1	TURN AND SLIP INDICATOR
101-380094-3	43-206-1	OH	1	TORQUE INDICATOR
101-389025-3	424-1	SV	1	FUEL SHUTOFF VALVE

101420-11968E	102220-11886	OH	2	ALTIMETER, PRESSURE ALT REP
101435-11263	101435	OH	1	ALTIMETER
1014744-0001		NS	1	PHONE
1015-1-11		SV	2	EFIS / RADAR PANEL
101-525306-6001		SV	2	IFIS DATA LOAD
1016-1-110	UNS1	AR	1	CONTROL DISPLAY UNIT
1016-2-21		SV	1	CONTROL DISPLAY UNIT
101635-11839	8140B-S20-LW5V	OH	1	ENCODING ALTIMETER
101641-6		SV	1	DESICCATOR, PRESSURE EQUAL
101-641-C		SV	1	DESICCATOR
101730-01467		OH	1	ALTIMETER
1018-2-213		FN	1	5" FPCDU Black HI-Resolution
102-0053-02	RCA26AK-1	OH	1	ATTITUDE GYRO
102-0060-02	RCA26BK-9	OH	1	ATTITUDE GYRO
102006-1		SV	1	MODULE
102008-1		SV	1	MODULE
1020-1-3	AIRSHOW	SV	2	COMPACT AUDIO DISTRIBUTOR
102013-1		SV	2	MODULE
102089-22410001		AR	1	HEAD OF PROPELLER
1021-1-1	AIRSHOW	SV	3	VIDEO MODULE
102220-11886		OH	3	ALTIMETER
102264NVG		SV	1	DISPLAY, OXYGEN MINDER
10238-0011		NE	1	CAPACITOR
1029-1-1	AIRSHOW	SV	1	AUDIO MULTIPLEXER
102AUICK	102	SV	1	SENSOR, TOTAL TEMPERATURE
103-0023-01	RCA15BK-2	OH	1	DIRECTIONAL GYRO
103006-1		SV	1	MODULE
1-030-069-01	5365-00-784-3994	OH	1	SPACER
1030-1-2	AIRSHOW	SV	2	INFRARED INTERPRETOR
10312N01T00	76450-01076-111	OH	1	TURB TEMP IND
10313N01R00	76450-01076-112	OH	2	TRIPLE TACH INDICATOR
1033-1-1	AIRSHOW	SV	1	RF/IR REMOTE INTERPRETER
103-5	27908-1	OH	1	AIRSPEED
103500-103	7901-01A	SV	1	AUTO DATA ENTRY UNIT
10355N04T00	212-075-067-119	OH	1	ITT INDICATOR
10379-11-01		SV	1	ALTITUDE ALERTER
10406-12600		SV	1	FLIR LCU, LAP TOP CONTROL
10406-66110		SV	1	FLIR, QWIP 640X480 PIXEL FPA-
1041-020	9200-0102-430	SV	1	DISPLAY MONITOR
10420-11968E		NE	2	ALTIMETER
104500A9		AR	1	POWER TURBINE GOVERNOR
10-4804-359		NE	1	FLOOD LIGHT PLATE
10-4804-364		NE	7	FLOOD LIGHT PANEL
105-00001		NE	1	TAIL FLOODLIGHT KIT

10-501TA	SV	1	LIGHT ASSY
105-10101W4	NE	1	CENTERING DEVICE
105-101511.07	NE	1	TENSION ROD
105-10158	NE	1	TRANSM. STAND ASSY RH
105-101731	NE	2	STRUT
1051-1-3	SV	4	CABIN MANAGEMENT MODULE
1051-1-6	SV	1	CABIN MANAGEMENT MODULE
105-131035	NE	1	SAFETY LEAVER ASSY
105-13122	NE	1	PITCH LINK ASSY
105-13221	AR	1	DRIVING LINK ASSY
105-13221.08	NE	1	SPACER
105-13241	AR	1	FORK LINK ASSY
105-14101 W1	NE	1	ABZIEHVORRICHTUNG
105-14101.12	SV	1	MAIN ROTOR STAR
105-14101.91	NE	1	HEX BOLT
105-14102W1	NE	1	SUPPORT ASSY -M/R HUB
105-141081	SV	1	MAIN ROTOR HEAD
105-141081	AR	5	ROTOR HEAD
105-141091	SV	2	MAIN ROTOR HEAD
105-141091	AR	3	ROTOR HEAD
105-14181.01	SV	8	INNER SLEEVE ASSY
105-14181.03.5	NS	8	BUSHING
105-14181001	NE	1	ASSY FIX NEEDLE BEARING
105-14183	NE	3	INNER SLEEVE ASSY
105-15103W2	NE	1	BENDING FIXTURE
105-151091	AR	1	ROTOR HEAD
105-15181-001	NE	1	EROSION PROTEC W.PEEL TEST
105-15853	NE	30	BLADE FITTING ASSY
105-20161-001	NE	1	FRAME9BEH
105-20301.55	NE	1	GUSSET
105-20402	NE	1	LUG ASSY
105-20501.55	NE	1	GUSSET PLATE
105-21301	SV	1	NOSE DOOR CONTROL LINKAGE
105-21706	NE	1	MOD ENGINE FLOOR
105-21721.115	NE	1	STIFFENER
105-21801-77	NE	1	ANGLE LH
105-21831-100.26	NE	1	SIDE PLATE LH
105-21841-002	NE	1	REAPIR SHEET FRAME
105-21924	NE	1	CABINROOF F SANDFILTER MOD
105-22209	NE	1	GLASS PANE UPPER RH
105-231151	NE	1	REAR DOOR SUPPORT
105-23151	NE	1	REAR DOOR SUPPORT LH
105-23401.10	NE	1	LEVER RH
105-23587	NE	1	LINK UPPER

105-30591		SV	1	VERTICAL STABILIZER ASSY
105-30591		NE	1	VERTICAL STABILIZER ASSY
105-31702		AR	2	TAIL ROTOR HEAD
105-31702-20		NS	1	NUT
105-31702W12		NE	1	PUSHING OUT TOOL
105-31711 W1		NE	1	PULLER TAIL ROD PITCH BEARING
105-31711W5	105-31711	SV	1	MOUNTING TOOL
105-31711W5		NE	1	MOUNTING TOOL
105-31714		SV	1	TAIL ROTOR HEAD
105-31729W2		NE	1	MOUNTING SLEEVE
105-31734		AR	8	BLADE MOUNTING FORK ASSY
105-31734W1	105-31734	SV	1	EXTRACTOR
105-31734W2		NE	1	BONDING TOOL
105-317385		NE	1	CONTROL LEVER ASSY BLACK
105-317395		SV	1	TAIL ROTOR HEAD
105-31743W15		NE	2	CONTROL DEVICE
105-31754W7		NE	1	MASTER GAUGE
105-31762		AR	1	SLIDING SLEEVE ASSY
105-31784		NE	1	TAIL ROTOR HEAD
105-31796		NE	8	TAIL ROTOR BLADE PAINTED
105-31802-001		AR	3	REAR ROTOR WAVE
105-31803-01		SV	1	TAIL ROTOR SHAFT
105-31810		NE	16	TAIL ROTOR BLADE
105-40118		NE	1	BELLOWS STICK RH
105-40151		NE	1	LONGITUDINAL CONTROL LINK
105-40213		NE	1	BELLOWS
105-40213		NE	1	BELLOWS
105-41027		NE	1	LATERAL TRIMMER
105-41041		NE	1	TUBE
105-41043		NE	1	HOUSING
105-41045		NE	1	TUBE
105-41081.01.5		NE	1	ADAPTER
1054-1-1	AIRSHOW	SV	4	8 CKT 5A AC/DC MODULE
105-411091		NE	1	TRANSDUCER
105-41221		NE	1	PITCH SHAFT
105-41227		NE	1	BRAKE BOXQ
105-41230		AR	1	COVER ASSY
105-41235		NE	1	BELLOWS ASSY
105-41237		NE	1	COLLECTIVE PITCH STICK ASSY
105-41238		NE	1	COLLECTIVE PITCH STICK ASSY
105-41247		NE	1	HANDLE
105-414661		NE	1	ACTUATOR LATERAL ASSY
105-414661		AR	2	ACTUATOR ASSY
105-414691		NE	1	CONTROL ROD ASSY

105-42122W2		NE	1	MOUNTING TOOL
105-42123		NE	1	LAGERBOCK
105-42124		NE	1	ADJUSTABLE SUPPORT
105-42221.36		NE	1	FITTING
105-42310		SV	3	TORSION BAR ASSY LONGITUDINAL
105-43011		SV	1	BELLCRANK ASSY
105-44001V001		NE	5	KIT
105-450121		SV	1	HYDRAULIC PACK
105-450121		NE	1	HYDRAULIC PACK
105-45021.63		NE	1	ADAPTER
105-45023		SV	1	TANDEM HYDRAULIC UNIT 7VE
105-45023		SV	1	TANDEM HYDRAULIC UNIT 7VE
105-45028		SV	1	TANDEM HYDRAULIC UNIT 7VE
105-45028		AR	1	TANDEM HYDRAULIC UNIT
105-45028V004		SV	1	TANDEM HYDRAULIC UNIT 7VE
105-450391		SV	1	TANDEM HYDRAULIC UNIT
105-45041W19		NE	1	ASSY TOOL
105-45041W30		NE	1	ASSY TOOL
105-45046		NE	2	3-AXIS ACTUATOR
105-45047		OH	1	ACTUATOR
105-45051W3		NE	2	SOCKET WRENCH
105-45054	105-45054B	NE	1	3-AXIS ACTUATOR
105-45055	105-45054	OH	1	ACTUATOR
105-45067	105-45054	OH	1	ACTUATOR
105-45077	105-45054	OH	1	ACTUATOR
105-450811		NE	1	RESERVOIR SYSTÉM I
105-450861		NE	1	RESERVOIR SYSTÉM Ii
105-45353		NE	3	PRESSURE TRANSFER VALVE
105-466071	S4-3010180	NE	1	3-AXIS ACTUATOR
105-466071B	S4-3010180	NE	1	3-AXIS ACTUATOR
105-46621B		OH	1	ACTUATOR
105-46631		NE	1	VALVE BODY MANIFOLD
105-46636		OH	1	VALVE BODY MANIFOLD
105-46648.01		NE	1	CONTROL SPOOL
105-46649	105-46649B	OH	1	VALVE BODY MANIFOLD
105-46661011	105-45054	OH	1	VALVE BODY MANIFOLD
105-46668		NE	18	CONE BYPASS
105-46671.01		NE	1	SPACER SLEEVE
105-46683		NE	5	SERVO - VALVE I
105-46686		NE	1	SERVO-VALVE ii
105-46741.10	E2-2100440	NE	1	PISTON ROD
105-46743		SV	1	HYDRAULIC RESERVOIR
105-46744		NE	1	HYDRAULIC RESERVOIR
105-46753		SV	1	TRANSFER VALVE

105-50101-22	NS	1	NUT
105-51523.12	NE	1	SKID CUP
1055-80237	AR	1	PANEL
1055-80238	AR	1	PANEL
105-60001W2	NE	1	TOOL
105-60186	NE	1	EXHAUST PIPE LH INSIDE
105-60354	NE	2	ENGINE MOUNT ASSY RH
105-60593	NE	2	ADJUSTABLE LEVER ASSY
105-60611	NE	2	TELEFLEX-TUBE
105-612711	NE	1	OIL TRIP TRAY
105-614061	NE	1	FIRE DETECTOR ASSY
105-61704	AR	1	OIL TANK
105-61704	NE	2	OIL TANK
105-61761	NE	1	TUBE
105-61781	NE	1	FLANSCH
105-61802	NE	1	COOLER INTAKE ASSY
105-619011	NE	1	LUBRICATION TANK ASSY
105-619031	NE	1	LUBRICATION TANK ASSY
105-62456	NE	2	PANEL ASSY RH OUTSIDE
105-62457	NE	1	BACK WALL LH ASSY
105-62458 "B"	NE	1	RUCKWAND RECHTS VOLLST.
105-62458 B	NE	1	WALL RIGHT COMPLETELY
105-62461 "B"	NE	1	MITTERWAND VOLLST.
105-62464	NE	1	CASING ASSY
105-62464 "A"	NE	1	SCHACHT VOLLST.
105-625206	NE	1	ICE PROTECTOR
105-62720V001	NE	1	VENTILATING DUCT MONTAGE
105-62725	NE	1	COOLER COVER
105-62741	NE	1	LUBRIC COOLING SYSTÉM
105-62741.28	NE	1	ELBOW
105-62747	NE	1	MOD DRAIN LINE FUSELAGE
105-62904	NE	1	MUFF
105-70221	NE	1	SEAT
105-70221GRAU	NE	2	BACK CUSHION COVER
105-70322	NE	1	REWORK SHOULDER HARNESS
105-70501.08	NE	1	LAP BELT FITTING
105-71286	AR	1	SITPOLSTER
105-71286GRAU	NE	1	SEAT CUSHIONING GRAY
105-72321.01	NE	1	FLOOR PANEL
105-73205	NE	1	CABIN STRUCTURE PANELLING
105-73207	NE	1	CABIN STRUCTURE PANELLING
105-73212	NE	1	CABIN STRUCTURE PANELLING
105-73215	NE	2	ROOF PANELLING LH
105-73216	NE	1	ROOF PANELLING RH

105-73248	NE	1	PANELLING, CABIN REAR WALL
105-73511	NE	1	ACTUATING DEVICE LH
105-79511.87	NE	1	SCHEDULE
105-80032	NE	2	RETRO BO15CBS
105-800390	NE	1	MODIFIC HYDRAULIC
105-80097	NE	2	INST. HEAT. A. VENT. SYSTÉM
105-80171	NE	1	NOZZLE LH
105-80239	AR	1	PANEL
105-80240	AR	1	PANEL
105-80329	NE	1	RETR. CYC. PITCH STICK RH ASSY
105-80335	NE	1	LOAD HOOK DETACHABLE FIX
105-80335	SV	1	LOAD HOOK DETACHABLE FIX
105-80335	AR	2	LOAD HOOK DETACHABLE FIX
105-80337	NE	1	LOAD HOOK DETACHABLE FIX
105-803441	NE	1	CARGO HOOK PERM. FIXTURE
105-80351	NE	1	MOUNTING
105-80428	NE	1	KIT
105-807214	AR	1	TURBINEN EINLASS
105-81022	SV	1	VIBRATION ABSORBER
105-81022	NE	1	VIBRATION ABSORBER
105-81022.04	NE	1	SHAFT
105-81022.12	NE	2	PART BY WEIGHT
105-81110	AR	1	RESCUE WINCH DETACHABLE PART
105-81112W2	NE	1	RITZELADAPTER
105-81210	NE	1	BUMBER UNIT INSTAL
105-81511	NE	1	REVERSED COPILOT SEAT ASYY
105-81511.09	NE	2	SHEET
105-81931	NE	2	PANEL
105-81936	NE	2	PANEL
105-82101	NE	4	INST. AUXILIAR TANK. AIRCR. SIDE
105-82102	NE	1	LONG RANGE FUEL TANK FIX. PROV.
105-82151	NE	1	SWITCH ASSEMBLY
105-82206	SV	1	AUXILIARY FUEL TANK ASSY RH
105-82216	NE	1	TUBE
105-82226	NE	1	BELLOWS ASSY
105-82503	NE	3	PASSENGER SEAT
105-82521	NE	1	TUBE ASSY, SHORT
105-82761	NE	2	ARM
105-83011	SV	1	TANDEM HYDRAULIC UNIT 7VE
105-83011	AR	1	TANDEMHYDRAULIC UNIT
105-83101	NE	1	PARTIAL COVER
105-83111	NE	1	REAR ROTOR GEAR COVER
105-83116	NE	1	REAR ROTOR BLADE COVER
105-83121	NE	1	COVER ROTOR HEAD

105-83196		NE	1	ENGINE COVER
105-832061		NE	1	COVER ENGINE INTAKE
105-832111		NE	1	COVER ENGINE OUTLET
105-83216		NE	1	COVER EXHAUST AND AIR INTAKE
105-83221		NE	1	TIE-DOWN FOR MAIN ROTO
105-83231		NE	1	SACK AND BELT
105-83516		NE	1	DRAINING TANK
105-83591		NE	1	FAD FILTER
105-83869		NE	1	EXT LOUDST PERM FIXED
105-83956		NE	2	MEDICAL EQUIP WALL ARMAN
105-84002		NE	1	STR RAIL LH FIXED PT
105-84007		NE	1	STR RAIL RH FIXED PT
105-84115		NE	1	YUBE PIPE
105-84717.05		NE	1	SKID PROTECTIVE PLATE
105-84931		NE	1	SIDE SECTION LH
105-84932		NE	1	SIDE SECTION RH
105-84935		NE	1	U-PROFILE
105-853056		NE	1	ENG COWLING FWD LH MOD
105-853066		NE	1	ENG COWLING FWD RH MOD
105-853076		NE	1	CAB ROOF F PART SEPER MOD
105-85327		NE	1	COVER
105-853336		AR	3	SANDFILTER DETACH FIXTURE
105-853346		NE	1	INSTAL PART SEPARATOR FOR SANDFIL1
105-853521.01		NE	2	SHROUD
105-85354		NE	1	SEALS ROTOR MAST CONTROL RODS
105-85502		NE	1	ENG COWLING FWD RH REWOEK
105-85503		NE	1	ENG COWLING FWD RH REWOEK
105-86490		NE	1	KIT
105-86559		NE	1	SWITCH PANEL ASSY
105-880068		NE	1	Konsole GA56
105-88921		SV	1	CONTROL UNIT
105-895666		NE	1	INSTAL HEADREST
105-899926		NE	1	SNOW SKID RH MOD
105-90986		NE	1	FRAME ASSY
105-90996		NE	1	GROUNDING CABLE
1059-1-1	AIRSHOW	SV	6	CKT MODULE
105-91106		NE	1	REL BOX
105-911151		NE	1	P/C BOARD GEN INTERLOCK
105-912021		NE	1	RELAISKASTEN 10VE
105-93975		NE	1	DRUCKSCHALTER VOLLST
105-93975		NE	1	PRESSURE SWITCH ASSY
105-94020		NE	2	WIRING HARNESS 2VB
105-94104		AR	1	IOVE PANEL
105-94107		AR	1	RELAY BOX

105-943101	NE	1	WIRE HARNESS
105-94563	SV	1	MAST MOVEMENT INSTALLATION
105-94563	SV	1	MM-SYSTÉM ASSY
105-94563	AR	1	SP. P MM INSTALATION
105-94563	NE	1	S.P.-MAST MOMENT INSTALLATION
105-94564	AR	1	MM INDICATOR
105-945657	NE	1	S P MAST MOMENT INSTALLAT
105-94575	NE	1	MM-DREHUEBERTRAGER
105-94641	NE	2	WIRING HARNESS 19VB
105-96273	OH	2	GH-14 WITH NVG MOD
105-98036	NE	1	CONTROL UNIT FERRANTI 29VE
105-98041	NE	1	CONTROL ROD LONGITUDINAL
105-98043	NE	1	SERVO ACTUATOR
105-980624	SV	1	CSAS CONTROL UNIT
105-98224	NE	1	FOLLOW UP TRIM
105-98301.01	AR	1	LANDING LIGHT
105-983121	NE	1	ELT SYSTÉM STROBE LIGHTS
105-98328	NE	3	WIRING HARNESS
105-98328	NE	1	WIRING HARNESS 22VB
105-98334	NE	1	BLEED AIR HEATING
105-98341	AR	1	CONTROL UNIT
105-98341.06	AR	1	APPARATUS
105-98342	SV	1	CONTROL DEVICE
105-98359	NE	1	CONTROL UNIT, LONG RANGE FUEL
105-98359-1	NE	1	PANEL RANGE TANK
105-98359-9	NE	1	PANEL RANGE TANK
105-98380	NE	1	CONTROL UNIT
105-98383	NE	1	P/C BOARD SWITCHING AMPL
105-98385	NE	1	PIC BD PWR SUP
105-984041	NE	1	LANDING LIGHT
105-98407.01	NE	1	SWITCH PANEL
105-98502	NE	3	WINDSHIELD WIPER SYSTÉM
105-985386	NE	1	INSTL ELT PARTS SANDFILTER
105-985396	NE	1	INSTL EL. SYSTÉM PART SEP. DET. (SANC
105-98706	AR	1	BOX
105-98751	NE	1	HG. WIRING PLATE MOD.
105A103-1	NE	2	PETR CONTROL BOX ASSY
105-E0006-6	NE	1	BRACKET ASSY
105H213-1	NE	1	PETR VALUE. MOD
105H522-2	NE	1	COMPRESOR
105H535-1	AR	1	COMPRESSOR
105-SB10-35-3.1	NE	1	KIT
105-SB30-105-3.1	NE	1	SB KIT

105-SB60-40/3.1		NE	1	KIT
105-SB80-69-3.1		NE	1	KIT
105V202-1		NE	1	HEAT PUMP FILTER DRIER
1060-1-1	AIRSHOW	SV	1	MODULE
1060-1-3	AIRSHOW	SV	2	DIGITAL POTENTIOMETER MODULE
10-60207-18	5985-01-633-1120	NS	1	WAVEGUIDE
106075-1		SV	1	AC POWER CONTROLLER
10-60897-69		SV	1	WAVEGUIDE
106090-3		NS	4	OUTLET ASSY
106096-1		NS	1	OUTLET ASSY
106096-2		NS	2	OUTLET ASSY
1061-1-1	AIRSHOW	SV	2	CALL MODULE
10-614950-1		AR	1	EXCITER ASSY
10-614950-1C		SV	1	EXCITER ASSY
1062-1-1	AIRSHOW	SV	1	MODULE
106272-1		SV	1	AV PORT
106354-1	106354-1MODB	SV	1	AC POWER CONTROLLER
106356-2		SV	1	OUTLET
1066-10-000		SV	1	DATA LINK
1075L26CEW0BFC-QMT05	1075L26CEW0BFC	SV	1	HANDSET
107CDC20		SV	1	PUMP-VACUUM
1080-01	GPS-1200	SV	1	GPS
10811-12		NE	1	CABLE ASSY
108-1249-001		SV	1	10IN TRACK INTERFACE
109-0010-09-103		NE	5	BEARING
109-0011-03-105		NE	10	TORQUE TUBE ASSY
109-0011-76-109		SV	1	CONTROL STICK ASSY
109-0020-06-1		SV	1	TORQUE TUBE AND LEVER ASY
109-0020-51-3		NE	1	BUSHING SLEEVE
109-0020-86-3		OH	1	CONNECTING LINK RIGID
109-0020-87-1		NE	1	ROD END ASSY
109-0020-88-1		NE	1	COUPLING
109-0020-89-1		NE	2	NUT
109-0021-17-1	L108BDM	SV	1	TRIM AND FORCE GRADIENT ACTUATOR
109-0030-05-1		SV	1	LEVER
109-0030-05-3		SV	1	LEVER
109-0030-17-103		SV	1	SUPPORT
109-0030-19-1		SV	1	BELLCRANK ASSY
109-0030-19-5		SV	2	BELLCRANK ASSY
109-0030-20-5		SV	1	BELLCRANK ASSY
109-0030-26-1		SV	1	SLIDING RACK ASSY
109-0030-28-1		SV	1	BELLCRANK ASSY
109-0032-01-13		SV	1	CONNECTING LINK RIGID
109-0032-01-29		SV	1	CONNECTING LINK RIGID

109-0032-01-61		SV	1	CONNECTING LINK RIGID
109-0032-01-69		NE	1	CONNECTING LINK RIGID
109-0032-02-25		SV	1	CONNECTING LINK RIGID
109-0032-02-41		NE	1	CONNECTING LINK RIGID
109-0032-02-57		SV	1	CONNECTING LINK RIGID
109-0032-07-1		SV	1	CONNECTING LINK RIGID
109-0033-02-103		SV	1	SUPPORT
109-0040-33-1		SV	1	LEVER BELLCRANK ASSY
109-0040-49-5		OH	1	SUPPORT ASSY
109-0040-49-5		SV	1	SUPPORT ASSY
109-0101-11-7		NE	2	SHIM
109-0101-61-1		NE	1	RING
109-0101-62-107		NE	25	BOLT MAIN ROTOR LOCKING
109-0104-04-1		NE	2	WASHER
109-0110-53-1		SV	1	SUPPORT ASSY
109-0110-70-3		NE	5	BUSHING
109-0110-70-3		NE	5	BUSHING
109-0111-09-103		NE	1	SLIDING RING ASSY
109-0111-25-101		NE	4	PITCH CONTROL LEVER BUSHING
109-0111-28-107		NE	1	PIN DROP STOP ASSY
109-0111-32-103		NE	16	SLEEVE BUSHING
109-0111-34-101		NE	1	UPPER FLAPPING LIMITER
109-0111-42-109		NE	4	FIXED SUPPORT
109-0112-05-107		OH	8	MAIN ROTOR LAG DAMPER
109-0130-91-105		SV	1	PITCH CHANGE SLIDER ASSY
109-0131-34-107		NE	8	SHIM TR TRUNNOIN
109-0135-03-101		SV	1	LEVER TR ASSY
109-0135-07-101		NE	10	BUSHING
109-0135-07-103		NE	14	BUSHING
109-0135-09-101		NE	7	BALANCING PLUG
109-0135-16-101		NE	9	LINER ASSY BEARING
109-0135-17-101		NE	2	BOOT BELLOW AFT
109-0210-29-103		NE	12	WASHER LAMINATED
109-0210-31-208M01	109-0210-31-208	NE	1	RH AFT FAIRING
109-0301-26-149	109-0301-26-149M01	NE	1	PANEL ASSY LEFT
109-0301-26-150		NE	1	PANEL ASSY
109-0301-27-129		NE	2	BRACKET ANGLE
109-0310-02-102		NE	1	BRACKET
109-0310-02-124		NE	6	SHIM
109-0310-02-139		NE	20	FRAME OUTSIDE LH
109-0310-02-140		NE	14	FRAME OUTSIDE RH
109-0310-02-206		NE	1	DOUBLER OUTSIDE RH
109-0310-02-207		NE	6	DOUBLER LH
109-0310-02-212		NE	5	BRACKET RH

109-0310-02-319		NE 4 DOUBLER
109-0310-03-2		NE 2 LATCH HOUSING RH
109-0310-27-13		NE 1 RETAINER
109-0310-27-15		NE 1 RETAINER
109-0310-27-16		NE 1 RETAINER
109-0310-27-195		NE 2 DOUBLER LH
109-0310-27-196		NE 1 RETAINER
109-0310-27-197		NE 2 RETAINER LH
109-0310-27-198		NE 1 STRIP RETAINER
109-0310-27-31		NE 1 RETAINER
109-0310-47-101		NE 1 HINGE ASSY REAR
109-0310-94-104M01	109-0310-94-104	NE 1 WINDSHIELD RETAINER RH
109-0310-94-105	109-0310-94-105M01	NE 2 CENTRAL RETAINER
109-0310-94-108		NE 1 RETAINER SUP RIGHT
109-0310-94-108		NE 1 RETAINER
109-0310-97-109M01		NE 1 RETAINER LOWER LH
109-0310-97-115M01		NE 1 LATERAL RETAINER PORT
109-0310-97-116M01		NE 1 LATERAL RETAINER RH
109-0310-97-121M01		NE 1 WINDOW RETAINER
109-0313-03-141		NE 4 SUPPORT
109-0313-58-113		NE 1 LH LWR NOSE COVER
109-0313-61-113		NE 3 GASKET
109-0313-88-107		NE 1 PEELING SHIM
109-0313-88-111		NE 1 PEELING SHIM
109-0313-89-125A1		NE 1 DOOR ASSY
109-0313-90-105		NE 1 FWD HINGE ASSY
109-0313-91-101		NE 1 HINGE ASSY AFT
109-0315-22-101		NS 2 MACHINED DOUBLER
109-0320-05-127M01	109-0320-05-127	NE 1 FIREWALL ASSY
109-0320-26-15		NE 1 UPPER FRAME RIB
109-0320-48-311		NE 1 ANGLE
109-0322-10-507		NE 1 BRACKET ANGLE INTERNAL LH
109-0322-76-111		SV 1 DOOR ASSY
109-0322-76-111		SV 1 PANEL ASSY
109-0322-76-203		NE 1 PANEL ASSY
109-0323-33-3		NE 14 PIN STRAIGHT HEADED
109-0324-35-101		NE 1 SLIDING DOOR HOUSING ASSY
109-0324-35-102		NE 1 ASSY HOUSING PIN
109-0324-35-103		NE 1 HOUSING PIN
109-0324-35-104		NE 1 PIN HOUSING ASSY
109-0324-73-119		NE 1 TRAILING
109-0325-08-1		NE 1 BRACKET
109-0325-08-1		SV 1 BRACKET ASSY
109-0325-08-111		NE 1 LOWER FITTING

109-0325-19-205		NE	1	ASSY LOCK
109-0325-34-109		SV	2	CATCH SAFETY
109-0326-47-107M01		NE	1	CHANNEL SEAL LH
109-0326-47-108	109-0326-47-108M01	NE	4	CHANNEL SEAL RH
109-0330-12-7		NE	1	ANGLE
109-0342-43-203M01	109-0342-43-203	NE	1	PANEL COVER UP
109-0360-05-1		NE	1	FORK
109-0360-06-101		NE	1	BRACE DRAG
109-0360-07-103		NE	1	BELLCRANK LH
109-0360-07-104		NE	1	BELLCRANK RH
109-0360-26-101		NE	1	THREADED BUSHING
109-0360-28-102		NE	1	LOWER CARRIAGE ASSY RH
109-0360-46-125		NE	1	EDGE LH
109-0360-49-217		NE	2	STRAP
109-0360-49-402		SV	1	DOOR ASSEMBLY COCKPIT RH
109-0360-49-402		AR	1	COCKPIT DOOR ASSY RH
109-0360-60-103		NE	1	DOOR ROD
109-0360-74-123		NE	2	WINDOW ASSY
109-0361-09-101		NE	3	LATCH DOOR HOOK LH
109-0361-09-102		NE	6	HOOK RH OPP
109-0361-29-103		NE	1	SHIM PEELING
109-0361-41-104		NE	2	LEVER ASSY
109-0361-45-101		NE	4	PIN ASSY
109-0361-66-101		NE	12	LATCH SEAT
109-0361-66-101		NE	8	SEAT LATCH
109-0361-78-117		NE	10	SEAL BASKET
109-0361-78-117		NE	7	SEAL BASKET
109-0361-82-103		NE	1	HANDLE PIVOT
109-0361-86-101		NE	1	HANDLE
109-0361-93-103		NE	21	WELDED MOUNTING ASSY
109-0361-93-103		NE	15	WELDED MOUNTING ASSY
109-0361-93-109		NE	2	PEELABLE SHIM
109-0361-93-111		NE	9	PLATE
109-0361-93-111		NE	6	EXTERNAL PLATE
109-0361-93-117		NE	2	PEELABLE SHIM
109-0362-05-105		NE	2	CONNECTING LINK DOOR
109-0362-11-104		NE	1	SHAFT
109-0362-20-103		NE	1	SHAFT
109-0362-20-103		SV	1	SHAFT
109-0362-20-103		NE	1	SHAFT
109-0362-23-207		NE	1	DOOR LATCH CONTROL ROD RH
109-0362-23-208		NE	1	DOOR LATCH CONTROL ROD RH
109-0362-24-103		NE	3	SHAFT ASSY
109-0362-24-103		NE	3	SHAFT

109-0362-24-105	NE	1	SHAFT
109-0362-25-107	NE	1	HOUSING
109-0370-50-103	NE	1	SUPPORT TR SHAFT
109-0370-59-107	NE	1	ANGLE AFT LH
109-0370-59-203M01	NE	1	RIGHT ANGLE
109-0370-59-219	NE	1	ANGLE DETAIL
109-0371-28-1	NE	1	SUPPORT
109-0371-32-3	NE	1	SHIM
109-0371-32-4	NE	1	SHIM
109-0371-33-13	NE	2	COVER ACCESS
109-0372-24-101	NE	1	PANEL ASSY
109-0372-34-101M01	NE	1	ANGLE LH PROFILE
109-0372-34-103	NE	1	ANGLE LH
109-0372-53-205	NE	1	BRACKET
109-0372-57-105	NE	1	SKID ASSY TAIL
109-0372-94-107	NE	1	STRIP RETAINER
109-0373-21-107	NE	2	SHIM
109-0373-21-109	NE	1	SHIM
109-0400-03-109	AR	1	A109 TRANSMISSION ASSY
109-0400-03-109	SV	1	A109 TRANSMISSION ASSY
109-0405-13-1	NE	1	NUT RING STOP
109-0405-94-103	NE	1	WASHER
109-0406-52-1	NE	1	SPRING
109-0406-52-103	NE	1	SPRING
109-0406-53-1	NE	1	SCREW REGULATOR
109-0407-41-101	NE	3	RING
109-0407-43-103	NE	3	RING LOCK
109-0407-43-105	NE	1	RING LOCK
109-0407-72-103	NE	1	SHIM UPPER
109-0407-80-101	NE	1	THERMOSWITCH
109-0424L02-101	NE	1	BEARING BALL
109-0425-06-5	NE	2	PTR DRIVESHAFT PIN
109-0425-38-1	NE	1	BUSHING SLEEVE
109-0425-45-105	NE	1	PIN
109-0425-45-107	NE	1	PIN CHECKING
109-0425-49-101	NE	1	ADAPTER SLIDING
109-0425-70-103	SV	1	RING NUT
109-0425-72-101	NE	5	RETAINING RING
109-0435-15-1	NE	2	SPACER
109-0435-15-103	NE	1	SEAL SPACER
109-0435-17-3	NE	1	PIN
109-0435-24-3	SV	2	OIL INDICATOR
109-0435-24-3	NE	3	OIL INDICATOR
109-0435-24-3	NE	3	INDICATOR OIL

109-0440-06-105		SV	3	TAIL GEARBOX ASSY 90 DEG
109-0445-15-103		NE	1	SEAL
109-0445-50-101		NE	1	SEAL TR GB INPUT
109-0445-52-101		NE	3	SEAL
109-0501-11-1		NE	2	PIN BEARING
109-0501-20-1		NE	3	BUSH
109-0501-21-3		NE	2	BOLT MACHINE
109-0504-24-1		NE	4	WASHER NONMETALLIC
109-0506-11-1		NE	1	SPRING BRACKET
109-0506-99-101		NE	1	ROTOR BRAKE CONT CABLE
109-0512-14-105		NE	1	PIVOT
109-0518-45-103		NE	1	TUBE ASSY METAL
109-0570-03-110		NE	1	ASSEMBLY SKID RH
109-0570-06-104		SV	1	LANDING GEAR SADDLE RH
109-0570-09-103		NE	1	LOWER SUPPORT AFT CROSS BEAM ASS
109-0570-10-103		NE	1	BULLONE SPECIALE
109-0570-23-106		NE	1	SHOE ANTIABRASION PROOF REAR
109-0570-32-107		SV	3	LANDING SKID DAMPER
109-0600-37-105		NE	2	SPACER
109-0601-47-107		SV	1	OIL BREATHER TUBE ASSY
109-0601-47-141		NE	1	OIL BREATHER PIPE ASSY
109-0601-66-111		NE	24	GASKET
109-0601-66-111		NE	24	GASKET
109-0601-81-119		AR	1	EXHAUST TUBE
109-0601-81-143		SV	1	EXHAUST DUCT ASSY LH
109-0601-83-109		NE	1	AIR INTAKE DUCT ASSY
109-0602-17-105		SV	1	ASSY LH SUPPORT
109-0602-17-106		SV	1	ASSY RH SUPPORT
109-0605-50-105		NE	1	LINK SUPPORT ASSY
109-0605-53-101		SV	2	BRACKET AFT
109-0605-63-109	NSCM A-126	SV	1	ENGINE MOUNT TRIPOD ASSY AFT RIGH
109-0605-69-103		SV	1	BIPOD ASSY ENGINE MOUNTS
109-0605-74-103		NE	2	ENGINE BRACKET
109-0610-19-5		NE	1	RUBBER TUBE
109-0610-20-1		NE	2	PLATE
109-0610-20-3		NE	2	PLATE
109-0610-48-1		SV	2	DRAIN DISH
109-0612-23-1		SV	2	GUARD ASSY DRAIN
109-0613-93-101		NE	1	FLEX HOSE
109-0614-18-101		NE	2	FILLER
109-0619-06-1		NE	6	SEAL
109-0620-88-101		NE	1	LINK STRAP ASSY
109-0621-31-101		NE	1	METALLIC TUBE ASSY
109-0630-70-105	65761-1	SV	2	GEARBOX ASSY W RVDT OPTION

109-0641-43-167		NE	1	DOOR ASSY
109-0641-46-134		NE	1	SEAL
109-0641-71-301		NE	1	LEFT DOOR ASSY
109-0641-90-303		NE	1	LEFT DOOR COWLING
109-0641-90-304		NE	1	RIGHT DOOR COWLING
109-0680-11-101		NE	1	DUCT
109-0702-97-103		NE	1	FERMO
109-0702-97-105		NE	1	STOP
109-0710-31-111		NE	1	AIR DUCT ASSY
109-0711-08-1	109-0711-08-3	NE	1	CONTROL AIR TEMP SYSTEMS
109-0712-10-109		NE	1	CUSHION SEAT BACK ASSY
109-0712-10-111		NE	1	HEAD CUSHION
109-0714-82-102		NE	2	DUCT ASSY AIR CONDITIONING RH
109-0714-82-201		NE	1	DISTRIBUTION BOX ASSY
109-0716-79-119		SV	1	SUPPORT ASSY
109-0718-77-101		NE	2	HANDLE SLIDING DOOR
109-0722-10-101		NE	2	BUSHING
109-0729-08-111	15DA01U	OH	1	INDICATOR, TACH
109-0729-08-5	15DA01-TYP1201	OH	1	INDICATOR, TACH
109-0729-13-3	5021-3048	OH	1	INDICATOR, TURB OUT TEMP
109-0729-19-1	AG-06-1	SV	1	COMMUNICATION CONTROL UNIT
109-0729-19-3	AG-06-1-A	SV	1	PANEL, POWER DISTRIBUTION
109-0729-20-107	PAL-12-7	OH	1	CONTROL SIGNAL
109-0729-21-105	PGI-12-3	OH	1	PANEL ALARM
109-0729-22-113	RBE25-11	OH	1	DETECTOR, RPM LIMIT
109-0729-22-5	RBE15-5	OH	1	DETECTOR, RPM LIMIT
109-0729-23-103	04DB04A-TYP1857	OH	1	INDICATOR LIQUID LEVEL
109-0729-26-3	14DB01G-TYP1360	OH	1	INDICATOR, OIL TEMP AND PRESS
109-0729-27-109	14DB01F	OH	1	INDICATOR, OIL TEMP
109-0729-27-113	14DB24	OH	1	INDICATOR, OIL TEMP
109-0729-27-3	14DB01F-TYP1359	OH	1	INDICATOR, OIL TEMP
109-0729-28-1	4344-3022	OH	1	INDICATOR, FUEL PRESSURE
109-0729-28-3	124-003	OH	1	INDICATOR, FUEL PRESSURE
109-0729-29-1	4344-3021	OH	1	INDICATOR, HYD PRESS
109-0729-29-109	14DB01F	OH	1	INDICATOR, OIL TEMP
109-0729-29-3	124-419-1	OH	1	INDICATOR, HYDRAULIC PRESS
109-0729-30-109	13DC02B-TYP1350	OH	1	INDICATOR, DUAL TORQUE
109-0729-31-21	PAL19-21	OH	1	PANEL ALARM
109-0729-31-5	PAL19-5	OH	1	PANEL ALARM
109-0729-32-1	124-486	OH	1	TOT INDICATOR
109-0729-32-115	08DC06G	OH	1	INDICATOR
109-0729-32-117	08DC06N	OH	1	INDICATOR, ITT
109-0729-33-1		SV	2	VSI
109-0729-34-1	16034	OH	1	ALTIMETER

109-0729-38-1	124-487	OH	1	INDICATOR,DUAL VOLTMETER
109-0729-38-3	124-488	OH	1	INDICATOR,DUAL VOLTMETER
109-0729-46-1		SV	1	BOX, AMPLIFIER
109-0729-50-1	PMB20-1	SV	1	PANEL, CONTROL
109-0729-51-1	PMA10-1	SV	1	PANEL ASSY
109-0729-87-101	06DB43	OH	1	INDICATOR, DUAL PRESSURE
109-0729-96-103		SV	1	AUDIO GENERATOR
109-0729-99-105	DCEB37V-1	SV	4	ELECTRICAL BOX
109-0730-16-113	15DA03B-TYP1487	OH	1	INDICATOR TACH
109-0749-93-101		NE	1	VNL PANEL
109-0760-03-34		SV	1	TANK ASSY WELDED
109-0760-42-107	4212403	SV	1	PUMP HYDRAULIC AP1.5V-01-03
109-0760-53-101		AR	1	PUMP ROTOR BRAKE
109-0763-86-101		NE	1	TUBE ASSY METAL
109-0784-82-209		NE	1	EXTENSION TNC/TPS
109-0810-79-123		NE	2	BRACKET AIR COND
109-0811-76-153		NE	4	DECAL PLACARD
109-0821-47-101		NE	37	ROLLER
109-0822-68-113		SV	1	SLIDING WINDOW
109-0822-68-113		NE	1	SLIDING WINDOW
109-0822-68-113		NE	1	WINDOW ASSY
109-0822-75-132		SV	1	ROD TUNING
109-0822-75-137		NE	4	WASHER
109-0822-75-139		NE	4	WASHER
109-0823-29-113		NE	2	BOLT
109-0823-29-117		NE	5	WASHER
109-0823-31-105		NE	1	SUPPORT
109-0823V36-101		NE	1	HOSE INSULATED ASSY
109-0859-90-103M01	109-0859-90-103	NE	1	DOUBLER
109-0881-33-210		NE	1	SUPPORT ASSY RH OPP
109-0881-33-316		NE	1	FITTING RH SLIDING DOOR
109-0881-34-103		NE	1	RIB
109-0881-34-109		NE	1	ANGLE LH
109-0881-34-111		NE	1	COVERING
109-0881-34-113		NE	1	SHIM SPACER
109-0881-34-121		NE	1	ANGLE
109-0881-34-123		NE	1	COVER
109-0881-34-129		NE	1	ANGLE LH
109-0882-29-121		NE	1	ANGLE PLATE
109-0900-08-109	EAP12-15	SV	1	WARNING LIGHT PANEL
109-0900-21-107		NE	2	CUP
109-0900-38-101		SV	1	CONTROL PANEL COMPASS
109-0900-42-2A08	10563D02M13	AR	1	AGUSTA DISPLAY
109-0900-54-211		NE	1	FUEL PROBE TRANSMITTER

109-0900-54-211		SV	2	FUEL PROBE TRANSMITTER
109-0900-54-211		SV	1	FUEL PROBE TRANSMITTER
109-0900-66-3A01	193860-11	SV	1	INTEGRATED DISPLAY SYSTEM
109-0900-66-3A02	193860-13	SV	2	INTEGRATED DISPLAY SYSTEM
109-0952-84-107		NE	1	DOUBLER
1092T100MBB	105-93921	OH	1	ANTI ICE ACTUATOR
10933001-1		NE	1	LITE ASSY KIT LEFT
109-3900-30-1		NE	1	PIN STRAIGHT HEADED
109-3900-37-1		NE	7	PIN TOW
109-3900-51-1		NE	1	CLEVIS FOR TOW BAR
109-4160-19-101		OH	1	MIDDLE LEVER ASSY
109-4160-21-101		NE	2	BUSSOLA
109-8131-22-111		NE	12	WEIGHT, STATIC BALANCE T/R
109-8131-22-115		NE	24	MASS BALANCING
109-8131-22-117		NE	8	MASS BALANCING
109-8131-22-117		NE	16	WEIGHT COUNTER BALANCE
109-8131-30-109		NE	2	BUSHING
109-8131-38-117		NE	8	SHIM
109-8131-38-119		NE	4	SHIM
109-8131-38-121		NE	10	SHIM 2.685-2.695
109-8131-38-123		NE	10	SHIM 2.705-2.715
109-8131-38-125		NE	8	SHIM 2.725 - 2.735
109-8131-38-127		NE	12	SHIM 2.745-2.755
109-8131-38-129		NE	14	SHIM 2.765 - 2.775
109-8131-38-131		NE	10	SHIM 2.785-2.795
109-910106-33		NE	14	WASHER
109-A816-03-126-1		NE	1	BRACKET ASSY
109-A816-04-119		AR	1	AFT LITER BOARD MOUNT
109-A816-05-117-1		NE	1	LITER SUPPORT GUARD
109-A816-09-111-1		NE	2	AFT SEAT BOTTOM
109A816-20-113-1		NE	5	LITTER LATCH DISC ASSY
109-A816-50-116-2		NE	1	POUCH RH
1-10-015223REVC		NE	1	RESTRAINT 3PT BOLT ON REEL LH
1-10-175301BCR		NE	1	3 POINT AUTOM HARNESS
110-323		NE	1	ANTENNA KIT
110-328-0		SV	1	406 BLADE ANTENNA
110-337		SV	1	ANTENNA
110-338		SV	1	ANTENNA ARTEX
110-338		AR	1	ANTENNA
1-1041-144		NS	2	COMPONENT
11097-1		SV	1	SWITCH IMPACT
1-10-E50301	1-10-E50301/AGU080	SV	1	SEAT BELT AND HARNESS ASSY
110PN01Y01	704A47621035	OH	1	TACHOMETER IND
1110-A-0501-10	CNX-100	SV	1	CABIN NETWORK XCELERATOR

1110-A-0501-20	CNX-200	SV	1	ACCELERATOR, NETWORK
111-11111-0000	TS10B	NS	1	HARNESS
1-1118ZG		SV	2	PRESSURE XMTR
111302-5		OH	2	H-S-I-
111303-4		SV	1	ADI
1114-039480		NE	1	HARNESS
1120-81024		SV	1	VIB ABSORBER
1121-10151W1		NE	E	GUIDE SLEEVE
1121-21451		NE	1	HOLDER
1121-31508		AR	1	ROTOR WAVE
1121-31566		NE	1	SHAFT
11213AL		SV	1	PRESSURE SWITCH
1121-41903.24		NE	2	BELLOWS
1121-41903.24		NE	1	BELLOWS
1121-51002		NE	1	SKID SHOE
1121-62671		NE	1	HOUSING ASSY
1121-70561		NE	3	HEADREST
1121-70651.71		AR	1	TUBE
1121-70651.75		AR	1	TUBE
1121-70651.89		AR	1	TUBE
1121-71124		NE	1	COVER PLATE ASSY
113300-03A1		AR	5	FUEL PUMP
11336AA		OH	1	VACUUM GAUGE
1135K5-1		NE	3	KIT FDC BARRIER FILTER EC135
1138PGCP1-15		SV	1	SWITCH LOW PRESS OIL
114-049		OH	1	IND, FAN SPEED
115-01771-01	GTX345	SV	1	RACK
1151324-1M218		SV	2	ELT - GERMANY CODED
115-201-3		SV	1	PRESSURE INDICATOR
115-201-4		SV	1	DUAL PRESS IND
115-201-4		NE	1	SIGNALCONDITIONER
115-230NVG	AC410047-NVG	OH	1	AIR TEMP IND
1152394-1		SV	1	ELT BRACKET
1152394-2		SV	1	ELT BRACKET
1152572-2	PC-251-123J2	SV	1	STATIC INVERTER
115-810034		NE	4	SHIM ACTUATOR LANDING GEAR
1159AV50723-1	W50723	NS	2	HARNESS
1159C20080-23		NE	1	CABLE
1159H47440-1		AR	2	PULSATION DAMPER
1159SB40396-11		NE	1	BRACKET
1159SB40588-3		SV	1	NOSE WHEEL PANEL
1159SB47807-13		NS	1	BRACKET
1159SB49016-1		FN	1	APU WIRING HARNESS
1159SCAV462-5	700-D36409A-008	SV	1	NAV CONTROL

1159SCAV462-7	700-D36411A-008	SV	1	ADF CONTROL
1159SCAV462-9	700-D36415A-004	SV	2	MRK CONTROL
1159SCF208-1	DRA45C-26	SV	1	OVERSPEED WARNING SWITCH
1159SCF412-11	523273	OH	1	ENGINE MONITOR
1159SCF426-2	128-413	SV	3	EL INDICATOR
1159SCF427-3	128-406	SV	2	ELPU
1159SCF452-5	3A1320A	AR	1	FDR POSITION SENSOR
1159SCF578-5		SV	1	LIGHTPLATE REV D
1159SEAV40123		SV	1	APU TEST BOX
115-MA1-132		NE	4	FAN ASSEMBLY
116012-0000	5935011959995CW	NS	3	CONNECTOR
1161-21-140		FN	2	NAVIGATION COMPUTER UNIT
117-0550-2		AR	1	KLIMA
117-0550-3	117-0550-3-2	NE	1	AIR CONDITIONING UNIT
117-10521		NE	1	BRAKE HAND LEVER
117-1111-01.00		NE	1	TANK COMPL INSTALL
117-11123.06		NE	1	HEX BOLT
117-11137		NE	1	TORQUE STRAP
117-11203-01		NE	1	ROD ASSY
117-11203-01		SV	1	ROD ASSY
117-12001W3		NE	1	OIL DRAIN HOSE
117-12010W11		NE	1	WRENCH SET
117-12010W15		NE	2	PULLER
117-12010W19		NE	2	HOLDER
117-12010W2		NE	1	PUSHER
117-12010W28		SV	1	MOUNT
117-12010W29		NE	1	PULLER
117-12010W3		NE	1	PUSHER
117-12010W40		NE	1	GUIDE SET
117-12010W43		NE	1	PULLER
117-12010W44		NE	1	PULLER
117-12010W45		NE	1	PULLER
117-12010W56		NE	1	GUARD
117-12010W63		SV	1	PUSHER
117-12010W63		NE	1	PUSHER
117-12010W68		NE	1	PUSHER
117-12010W70		NE	1	MOUNT
117-12010W70		NE	1	MOUNT
117-12010W72		NE	1	WORKING STAND
117-12010W75		NE	1	REACTION ARM
117-12020W2		NE	1	PUSHER
117-12020W4		NE	1	Montagewerkzeug
117-12020W7		NE	2	PUSHER
117-12060W5		NE	1	PUSHER

117-12110W6	NE	1	PUSHER SET
117-12140-01	NE	1	ACC. GEARBOX ASSY LH
117-12140W2	NE	1	PUSHER
117-12140W7	NE	1	PULLER
117-12150W1	NE	1	PUSHER
117-12150W2	NE	1	PUSHER
117-12170W1	NE	1	PUSHER SET
117-12250W16	SV	1	PUSHER
117-12250W19	NE	1	IMPRESSIVE TOOL
117-12250W6	NE	1	PUSHER
117-12256-01	NE	1	SEAL RING
117-12300W5	NE	2	PUSHER
117-12300W7	NE	1	PUSHER
117-12303-01	FN	1	SEAL SPACER
117-12303-01	NE	1	SPACER
117-12415-01	SV	1	MOUNT ASSY
117-12601-01	NE	2	BALL BEARING
117-12602-01	NE	8	BALL BEARING
117-12603-01	NE	10	ROLLER BEARING
117-12605-01	NE	5	ROLLER BEARING
117-12606-01	NE	6	ROLLER BEARING
117-12607-01	NE	10	ROLLER BEARING
117-12609-01	NE	10	BALL BEARING
117-12610-01	NE	4	ROLLER BEARING
117-12610-01	NE	2	ROLLER BEARING
117-12612-01	NE	6	ROLLER BEARING
117-12614-01	NE	8	ROLLER BEARING
117-12615-01	NE	6	ROLLER BEARING
117-12616-03	NE	8	BALL BEARING
117-12617-01	NE	6	ROLLER BEARING
117-12619-01	NE	4	BALL BEARING
117-12621-01	NE	8	ROLLER BEARING
117-12622-01	NE	12	BALL BEARING
117-12623-01	NE	7	BALL BEARING
117-12645-05	SV	5	LUBE PUMP ASSY LH
117-12645-05	SV	1	SCHMIEROLPUMPE
117-12645-07	SV	2	LUBE PUMP ASSY RH
117-13901.01	NE	1	HUB CAP
117-141081	NE	2	MAIN ROTOR HEAD
117-141081	AR	1	HEAD OF PROPELLER
117-141831	SV	7	INNER SLEEVE ASSY
117-141831	AR	4	INNER SLEEVE ASSY
117-152111	NE	1	TYP CAP ASSY
117-15856 C	NE	1	ELASTIC BUSHING

117-15860		SV	10	CONNECTION FITTING
117-16010-01		SV	2	MAIN DRIVE SHAFT
117-21181-01		NE	3	WINDOW ASSY LH
117-21197-04		NE	1	GUSS SET
117-21199-52		SV	1	WINDSHIELD ASSY RH
117-21199-52		NE	1	WINDSHIELD ASSY RH
117-22462-01		NE	2	STAY
117-22581-01		SV	4	SIDE WINDOW ASSY LH
117-22953-21		SV	2	COVER ASSY
117-23392-08		NE	1	BLANKET ASSY RH
117-24101-18		NE	2	COCKPIT DOOR ASSY RH
117-24202-13		NE	1	CABIN DOOR ASSY LH
117-24234-02		NE	1	STOPPER RH
117-24253-01		NE	4	SHIM
117-24261-03		NS	2	SEAL
117-24261-07		FN	1	SEAL
117-24261-09		FN	1	SEAL
117-24261-09		NE	1	SEAL
117-24261-11		NE	1	SEAL
117-24283-08		NE	1	RAIL RH
117-24285-01		NE	2	SPACER
117-24292-13		NE	1	EMERG. RELEASE MECH. ASSY L
117-24292-13		NE	1	EMERG. RELEASE MECH. ASSY LH
117-24302-02 "H17"		NE	2	CARGO DOOR
117-24612-01		NE	1	HINGE ASSY
117-24627-01		FN	1	SHIM
117-24627-01		NE	1	SHIM
117-24646-05		SV	1	DOOR LOCKING CYLINDER
117-30640		AR	1	RETROF. HORIZ. STAB FIN ASSY
117-31547		NE	1	SHAFT
117-315671		NE	1	SHAFT
117-31714		NE	1	TAIL ROTOR HEAD
117-31714		NE	1	TAIL ROTOR HEAD
117-317391		SV	1	TAIL ROTOR HEAD
117-317411		SV	2	TAIL ROTOR BLADE ASSY
117-31742		AR	8	TAIL ROTOR BLADE
117-31748		SV	1	TAIL ROTOR BLADE BONDED
117-384031-1	20B380-5	OH	1	TURN AND BANK INDICATOR
117-410271		NE	1	LATERAL TRIMMER
117-41110-02		NE	1	COVER ASSY
117-41111-01		NE	1	BOOT ASSY
117-41201-01		NE	4	TORQUE TUBE ASSY
117-41201-01		NE	4	TORQUE TUBE ASSY
117-412581		NE	1	GRIP ASSY

117-41308-05	NS	1	BUSHING
117-41314-01	NE	1	BOOT ASSY
117-41340-01	NE	1	HOUSING ASSY
117-41634	NE	1	PEDAL ASSY RH
117-41904-07	SV	1	CARDANRING, TWO PART
117-42185-25	NE	1	CONTROL ROD
117-42185-25	NE	1	CONTROL ROD ASSY
117-44001W5.06	NE	1	WEDGE
117-44001W5.07	NE	1	WEDGE
117440-1	SV	1	BASE, RADIO BEACON
117-44115W3	NE	1	PUSHING OUT TOOL
117459-2	SV	1	ADELT BEACON
117-467531	NE	1	TRANSFER VALVE
117-5000211	NE	1	SKID PROTECTIVE PLATE
117-601131	SV	1	FIRE WALL AFT LOWER LH
117-601141	SV	1	FIRE WALL AFT LOWER RH
117-61268-01	NE	1	FITTING
117-61311-01	NE	3	PRESS SWITCH
117-62616-01	NS	1	BOLT
117-63518-01	NS	1	BUSHING
117-64134-01	NE	1	SEAL
117-64141-21	NE	1	FILLER ASSY
117-64141-21	NE	1	FILLER ASSY
117-64151-03	NE	12	BOOSTER PUMP
117-64151-03	SV	4	BOOSTER PUMP
117-64152-01	SV	1	FUEL QUANTITY TRANSMITTER
117-64155-01	NE	2	SEAL
117-64159-01	NE	1	METAL O SEAL
117-64159-01	NE	1	SEAL
117-64172-03	SV	6	SUPPLY FUEL CELL ASSY
117-64173-01	SV	1	REAR FUEL CELL ASSY
117-64173-01	NE	3	REAR FUEL CELL ASSY
117-64174-01	SV	1	FWD FUEL CELL ASSY
117-64174-01	SV	3	FWD FUEL CELL ASSY
117-64174-01	SV	2	FWD FUEL CELL ASSY
117-64569-03	NE	1	PRESS SWITCH FUEL
117-64664-11	NE	1	CONNECTOR ASSY
117-66260-01	NE	1	FIRE WALL ASSY AFT LH
117-67122-01	NE	1	STRAINER ASSY
117-67172-01	NE	1	OIL TANK LH
117-67172-02	NE	1	OIL TANK RH
117-68101-01	SV	1	SCROLL ASSY
117-68121-01	NE	1	HOUTTING
117-68132-01	NE	6	SHIM

117-69005-03		OH	1	INDICATOR, TORQUEMETER
117-712261		NE	1	COVER SEAT PAN
117-712271		NE	1	COVER BACK REST
117-71305-01		NE	3	WIPER CONVERTOR
117-71305-01		AR	1	CONVERTER
117-72150-01		NE	2	NOZZLE ASSY LH
117-72150-02		NE	2	NOZZLE ASSY RH
117-72461-01		SV	1	SENSOR
117-725021		NE	1	REWORK BLEED AIR HEATING
117-725041.08		NE	1	COUPLING SLEEVE
117-72582-03		SV	1	MIXING VALVE
117-72582-05		NE	2	MIXING VALVE
117-72582-05		NE	1	MIXING VALVE
117-72623-01		NE	1	COVER
117-770051		NE	1	COVER ENGINE INLET
117-770071		NE	1	COVER ENGINE OUTLET
117-80023		NE	1	SUPPORT ASSY
117-80036		NE	1	INST. RAILS
117-80044		NE	2	FUEL VENT AND DRAIN LINES
117-80047		NE	1	PROV FLOOR
117-80064		NE	1	ASSEMBLY
117-80070		AR	1	DECKEL
117-80078		NE	1	MOD OF INTERIOR PANEL UP RH
117-80094		NE	1	SCOOP
117-80127		SV	1	LOAD HOOK DETACH. PART
117-80156		NE	1	STRUT
117-80168		SV	1	VIBRATION ABSORBER
117-80170		SV	1	VIBRATION ABSORBER
117-80170V001		SV	2	VIB ABSORBER REPAIR
117-80175	117-80175B2	NE	3	TANK
117-80180		SV	1	VIBRATION ABSORBER
117-80180		NE	1	VIBRATION ABSORBER
117-80284.09		NE	1	FITTING
117-80355		AR	1	VIP FIXED PROVISION
117-80356		NE	1	MOD SET VIP-LRFT
117-804181		NE	1	ANTI STATIC CABLE
117-804251.10		NE	1	CONSOLE
117-81104-01		NE	1	COVER ASSY
117-81353-01		NE	1	WIRING HARNESS
117-83617-01		NE	2	PROTECTOR ASSY
117-83617-01		AR	2	PROTECTOR ASSY
117-83617-03		AR	1	PROTECTOR ASSY
117-84045		NE	1	SKID PROTECTIVE PLATE
117-841014		NE	1	SCAVENGE OIL FILTER SYSTÉM

117-84109		NE	2	SETTLING PROTECTOR
117-84113		NE	1	SETTLING PROTECTOR ASSY
117-84271		NE	12	WEIGHT ASSY LH
117-84271		NE	1	WEIGHT ASSY LH
117-84272		NE	2	WEIGHT ASSY RH
117-84272		NE	7	WEIGHT ASSY RH
117-84292		NE	1	WEIGHT RH ASSY
117-84338		NE	1	CARDS BAG
117-84442		NE	1	STOP
117-84624		NE	1	WATER CONDUCTORS
117-847054		SV	1	SETTLING PROTECTOR
117-85111-01		AR	1	SEAT BANK
117-85171-03		NE	3	CO-PILOTEN SEAT
117-85171-03		AR	1	SEAT
117-85194-23		NE	1	INT. PANEL CARGO WHITE ASSY - KIT
117-860024		NE	1	PEDAL COVER ASSEMBLY
117-86061		NE	1	COVER F PASS SEATS
117-86111		NE	1	HIGH DEFIT. SEAT
117-86119		NE	1	HOSE ASSY
117-86138		NE	1	FLAP ABOVE
117-86146		NE	1	FITTING BELOW
117-86214		NE	1	INST JUCTION BOX
117-86249		NE	2	SEARCHLIGHT SX16
117-86307		NE	1	OUTB. L. SP. PERM. FIXT. VA
117-879111		NE	1	INSTALATION KIT
117-88024		NE	1	PLATE ASSY
117-883541		SV	1	MOTHER BOARD
117-884311		SV	1	SIGNAL PROCESSING SPAS
117-88659		SV	1	BELLCRANK ASSY
117-88814		NE	5	TRANSDUCER
117-897321		NE	1	LAMP
117-89783-01		NE	2	FUEL PUMP FAIL DETECTOR
117-89783-01		NE	1	FUEL PUMP FAIL DETECTOR
117-902011		OH	1	TRIPLE INDICATOR RPM
117-902011		SV	1	TRIPLE TACH INDICATOR
117-902031	124T499-7	SV	2	TOT INDICATOR
117-902041		OH	2	ENG. OIL T/P INDICATOR
117-902061	124L507-6	SV	1	DUAL AMMETER 200A
117-902061		NE	1	DUAL AMMETER INDICATOR
117-902141		AR	1	CSAS
117-902141		SV	1	CONTROL UNIT CSAS
117-91034-03		SV	1	DETECTOR
117-92031-03		NE	1	CONTROL UNIT
117-92031-03		OH	2	CONTROL UNIT

117-92031-07		SV	2	CONTROL UNIT
117-92031-07		NE	1	CONTROL UNIT
117-92040-03		SV	1	LIGHT EMERGENCY EXIT SIGN
117-92042-01		SV	1	IMPACT SWITCH
117-92049-01		NE	3	POWER SUPPLY
117-94035-03		SV	1	TEMPERATURE INDICATOR
117-94035-05	124-500-3	NE	1	IND. XMSN OIL PRESS. DUAL
117-94035-05		SV	2	INDICATOR XMSN OIL TEMP
117-94036-05		OH	2	DUAL OIL PRESS INDICATOR
117-940471		NE	1	INDICATOR-AIRSPEED
117-940481		SV	1	AIRSPEED INDICATOR
117-94051-05	124-499-4	SV	1	TOT INDICATOR
117-94051-05		SV	1	INDICATOR-TOT
117-94051-05		OH	1	T4 INDICATOR
117-94051-07	124-499-5	SV	1	TOT INDICATOR
117-94051-07		OH	1	TOT-INDICATOR
117-94052-07	82000-05605	SV	1	ANNUNCIATOR PANEL
117-940521		NE	4	AIRSPEED INDICATOR
117-94052-11		NE	1	ANN PANEL
117-94052-17		SV	1	ANNUNCIATOR PANEL
117-94052-17		NE	4	ANNUNCIATOR PANEL
117-94054-01	PF240-N3	OH	2	INDICATOR FUEL QTY KG
117-94054-03	PF240-N4	SV	1	INDICATOR FUEL QUANTITY (GA)
117-94056-03	6503A-3101	OH	1	N1 INDICATOR
117-94056-03	6503A-3101	OH	2	INDICATOR N1
117-94057-01		SV	2	TEMPRETURE
117-94058-07	124.498-6	OH	1	INDICATOR TEMPRATURE OIL
117-94058-07	124.498-6	NE	2	INDICATOR TEMPRATURE OIL
117-94061-01		SV	1	RPM WARNING CONTROL UNIT
117-943231		OH	1	STBY HORIZON IFR
117-945641		NE	1	MM-ANZEIGEGERAET
117-94564W2		NE	2	MM-BALANCER
117-945661		SV	1	SP MAST MOMENT INSTALLATION
117-945661		AR	1	SP. P MM INSTALATION
117-94680-03		NE	1	HOSE ASSY
117-95769-01		NE	1	WIRE HARNESS
117-95788-01		NE	2	WIRING HARNESS
117-95879-01		NE	1	WIRING HARNESS
117-958811		NE	1	WIRING HARNESS
117-958812		NE	1	WIRING HARNESS
117-98043		NE	1	FILTER
117-980601		NE	1	VENTILATION EQUIP DESK
117-98130		SV	1	P/C BOARD LR FUEL TK
117-98130.01		AR	1	BOARD ASSY

117-98133		NE	1	LR FUEL TANK
117-98135		NE	1	MOD PART RETROFIT VIP TANK
117-98192		NE	1	WIRING HARNESS 302VB
117-982021		NE	1	WIRE HARNESS
117-982041		NE	1	WIRE HARNESS
117-98228		NE	3	PANEL-LTG PLASTIC
117-98230		NE	1	WIRING HARNESS BOVB
117-98248		NE	1	WIRING HARNESS 48VB
117-98295		NE	2	WIRING HARNESS 67VB
117-98331		NE	2	BATTERY INST AFT SECT
117-98336		SV	1	CONTROL UNIT YAW CSAS
117-98336		NE	1	CONTROL UNIT YAW CSAS
117-98439		SV	2	CONTROL UNIT
117-98538		NE	1	WIRING HARNESS 538VB
117-98609		SV	1	RELAY VOLLST
117-98682		NE	1	PRINTED CIRCUIT BOARD ASSY
117-99701L9600		NE	1	CSAS P/R TEST SET
117-ASB20-104-3.1		NE	1	KIT
117-ASB80-127-3.1		NE	2	KIT
117-ASB90-105-3.1		NE	1	KIT
117C2-SB71-001-2.C	B711M4143101	NE	1	POWER PLANT, BLANKET ENG.
117-E0018-2		NE	1	COVER PLATE ASSY
117-SB20-1-3.1		NE	1	KIT
117-SB40-103-3.1		NE	1	SB KIT
117-SB40-104-3.1		NE	1	SB KIT
117-SB60-102-3.1		NE	4	KIT
117-SB80-105-3.1	KIT:117-SB80-105-3.1	NE	1	KIT CONV. A-3 TO A-4
1180-1-12	UNS1	SV	1	UNS1 NCU
11-8150-1		AR	1	TIMING KIT
11-9110-1		AR	1	TIMING LIGHT TESTER
1192-30-111106		SV	1	NAV COMPUTER UNIT
120-03048-0002		NE	6	IC LM139J
12042-0061		NE	5	DIODE
121-0011-000		NE	1	ANTENNA
121-016796-01	AT-51	SV	1	ANTENNA
121-049075-02		NE	1	ANTENNA
12192-00		NE	3	SMOKE DETECTOR
1-2233-28		NE	1	SEAL
1229-1		OH	1	INDICATOR, BATT TEMP
1234T100-7TZ		AR	1	TURN COORDINATOR
124-1128-1		OH	1	INDICATOR DUAL DC AMMETER
124-244-2	209-070-263-009	OH	1	IND VOLTMETER
124-444-2		OH	1	TOT INDICATOR
124-507-04		NE	1	AMMETER DC DUAL

124-545	222-375-024-101	OH	1	INDICATOR
124-546	222-375-016-101	OH	2	INDICATOR
124-549	222-375-017-101	OH	2	INDICATOR, XMSN OIL TEMP
124-550		OH	2	INDICATOR, ENGINE OIL TEMP
124-550-3		OH	1	INDICATOR, ENGINE OIL TEMP
124-679-1		SV	1	CGB-PRESS/TEMP-IND-
124L507-6		NE	1	DUAL AMMETER INDICATOR
1250120-4		OH	1	COMPRESSOR
12507G-44		SV	1	HEADSET MIC
1259T100-3		SV	5	ACTUATOR
126-182-10	AC410004	SV	1	ENGINE TORQUE IND
126-306-5	222-375-064-105	OH	1	INDICATOR, TOT DUAL FUEL QTY
126PN01Y07	704A47-621-086	OH	1	INDICATOR, ENGINE TORQUE
128-413	1159SCF426-2	SV	2	EL INDICATOR
1286-1-1	212-077-200-3	SV	1	COMMUNICATION CONTROL UNIT
129-0160-43-101		NE	13	SPACER INTERNAL
129-0160-44-101		NE	10	SPACER EXTERNAL
12903-4	PB0134004	NS	1	SWITCH PRESSURE
129415-024		NS	1	SOLENOID
1297C-4-04		OH	1	AIRSPEED INDICATOR
129920-3		OH	1	ATTITUDE INDICATOR
1300160-3	3G2150V10651	SV	1	COCKPIT CONTROL PANEL, ECS
130-034356-607		SV	3	KING AIR 300 EFIS PANEL
1-300-363-03	2925-00-950-2516	NE	6	IGN-UNIT
1301S		NS	1	FAIL SAFE
130-380041-7	41-402-1	OH	1	TEMP TURBINE INTERSTAGE
130-380045-7	83-183-1	OH	1	OIL TEMP & PRESS IND
1305-1-5	1305-58-2	SV	2	SMART SWITCH ADAPTER
1308-85		NE	1	ANTENNA
13-1-0110		SV	1	SERVO MOTOR
13-11014P		NE	1	PART
1312-1-1		SV	1	RCVR/TRANS MODULE
1312-1-2		SV	1	MODULE
1317S		NS	2	FAIL SECURE
132NE		NE	1	OAT-SENSOR
1330-16		SV	1	SCAT COMPUTER
1333-200-200	071-50014-0400	SV	2	HGA-48 HIGH GAIN ANTENNA
1333-300-200	071-50014-0203	SV	1	BSU-48A BEAM STEERING UNIT
1333-500-100		SV	1	DIPLEXER
1343-85		NE	1	VHF ANTENNE
13477-11281		OH	1	DIR GYRO
134E0505-054		SV	1	MOUNTING TRAY
135-0350-4		NE	1	AIR SWITCH ASSY
135-0550-3		SV	2	COMPRESOR CONDENSATOR PALLET A

135-0550-3		NE	2	COMPRESOR CONDENSATOR PALLET A
135-0553-1		SV	1	COMP.COND.PALLET EL.SSTART
135-0553-1		NE	1	COMP.COND.PALLET EL.SSTART
135-1401-1		NE	3	AUX BLOWER ASSY
135ME1339.		SV	1	Pulse Generaor IFR6000
136266-1		SV	1	CONTROL UNIT CCU32A
13636-93921-1		SV	1	MOUNTING TRAY
137685-01	5990-00-073-1810	NE	1	SYNCHRO
13824-12-0211	TNL2000A	SV	1	GPS
13824-12-0234	TNL2000A	SV	2	GPS
138740-19	704A47330088	SV	1	HORIZONTAL SITUATION INDICATOR
1394T100-7A		OH	1	TURN COORDINATOR
1394T100-7B		AR	1	TURN COORDINATOR
1397-1		SV	1	AMP SLEW SWITCH
13F141		NS	5	RESISTOR
140100-03-01		SV	1	ATTITUDE IND
1401-020		SV	1	MONITOR
1401-1T-B3		OH	1	INDICATOR AIRSPEED
1402-1T-C1		OH	1	AIRSPEED INDICATOR
1403-01-11		SV	1	DATA TRANSFER UNIT
141063-2	BAU-35A	SV	1	BEACON, AIRFOIL UNIT
14141-0203-	GNSX	SV	2	GNSX
141987-0001		SV	1	A-C-U-
142185-1100	LCR-93	SV	1	AHRU
142185-1100	LCR-93	AR	1	AHRU
1426-1AE-A1		OH	1	AIRSPEED IND
1426-37A-A6		OH	1	AIRSPEED IND (MPH)
1426-6M-B17		OH	1	AIRSPEED INDICATOR
143236-0420	BAU-35A	SV	1	BEACON, AIRFOIL UNIT
14347-0101-06	GNSX	SV	2	GNSX CDU
1445-1-1	20001-004	SV	2	TCC AUDIOFILE
145-0174-1		SV	2	COCKPIT BLOWER ASSY
145-0250-1		NE	1	COCKPIT BLOWER ASSY
1453PGCP		OH	1	FUEL PRESSURE SWITCH
1461-BU-8-03	E-32	SV	1	INDICATOR, TACHOMETER
147B30A	MS28008-1	OH	1	INDICATOR TEMP
147B31A	MS28009-1	OH	1	INDICATOR TEMP
147B32A	MS28004-1	OH	1	INDICATOR TEMP
1-480710-0		NS	3	CONNECTOR
1486-1-16		SV	1	SWITCH PANEL
1486-1-20		SV	1	SWITCH PANEL
1486-1-6		SV	1	SWITCH PANEL
1486-1-7		SV	2	SWITCH PANEL
1486-1-8		SV	2	SWITCH PANEL

149-0020-003		SV	1	MOUNTING TRAY
149-015932-0001	C5000	NE	1	INSTALL KIT
1500-01-13		SV	1	AIR DATA COMPUTER
15-0007-127		SV	4	LIGHT ASSY
15-0105-1		NE	1	PANEL LIGHT
152HL2W	206-070-267-007	OH	1	TOT INDICATOR
152HL2W3		OH	2	TOT INDICATOR
153-017713-01		SV	2	FF HANDSET
153-168		NE	2	FIRE PROTECTION
1534-1-8		SV	1	AIRSHOW PANEL
1534-1-9		SV	1	AIRSHOW PANEL
153510-000017	STRATUS ESG	SV	1	ADS-B OUT TRANSPONDER
1550184-503		SV	1	ANNC COUPLER UNIT
155-02578-0001	TS10B	NS	1	HARNESS
155-02581-0000	TS10B	NS	1	APPLE BOARD CABLE
156-01	EDO AIRE	SV	1	ADF CONTROL HEAD
1564T100-5		SV	1	SERVOMOTOR
156F115B0084S180		NS	3	TUBE
156M1		SV	1	ADF CTL
1575-1-1	1305-58-2	SV	1	32 I/O ADAPTER MODULE
1575-4		SV	1	GPS AMP
1589-1F		SV	1	VOLTAGE REGULATOR
15989-005		NS	1	ANN- DCPL- FD- "OFF"
15989-006		NS	1	ANN- CYCLIC POSITION CTR
159AV10001EQ5		SV	1	TURBINE GAS TEMP
159AV10001TEQ5		SV	1	TURBINE GAS TEMP
15E02-1	222-325-013-102	SV	1	VALVE
15PX308		AR	1	GUARD RCVR
1601B-DC28		SV	1	COFFEE MAKER
1602-01-03	CVR30A	SV	1	COCKPIT VOICE RECORDER
1602-02-03		OH	1	CVR-30A Cockpit voice recorder
16030S	160305	OH	1	ALTIMETER
160SG139Q-2		OH	1	STARTER GENERATOR
1612-02		SV	1	CVR CONTROL
1616-050-02A		SV	1	SKY CONNECT
1616-050-03A		SV	1	SKY CONNECT
1616-055-00		SV	2	SKY CONNECT CONTROL HEAD
1616-450-01A		SV	1	SKY CONNECT TRANSCEIVER
162-1		NS	1	VIDEO ISO TRANS 75 OHM
16248-11		SV	5	GPS ANTENNA
162LC601A		SV	1	INDICATOR, TEMP ELEC
164BT-2		OH	1	ROTARY ACTUATOR
164ZS01Y		SV	1	AUDIO WARNING
1656A1100-01		SV	1	TRAILING ARM LH

1656A2100-02		SV	1	TRAILING ARM, RH
16650-1142		OH	1	ALTIMETER
16650-1172		OH	1	ALTIMETER
16722-007	13986-001	NS	30	ANNUNCIATOR
168SR101		SV	3	SWITCHING RELAY
17000-003		SV	1	BOWL AND TANK ASSY
170-431-02-100		SV	1	COMM CONTROL
17-100		SV	1	COMPASS
1713121-501		SV	1	RADAR PHASED ARRAY
1713122-501		SV	1	BASE
171-431-02-000		SV	1	COMM CONTROL
171-431-45-100		SV	1	COMM CONTROL
1716803-502		SV	1	ANTENNA ARRAY
171BS101-1		SV	2	AMPS500
172937-001		SV	10	RELAY
17343-62-340		NE	1	FIRE DETECTOR
173819-001		SV	1	RELAY
174213-02-01		SV	5	FLIGHT DATA RECORDER
1742500-09		NE	9	FILTER ASSY
1742500-09		NE	2	OIL FILTER
1742510-05		NE	1	FILTER ELEMENT
17479-549		NS	1	ANNUNCIATOR
175096-101		SV	1	RELAY
1762A020000		OH	1	DRAIN KIT
17680-01		NE	1	CONFIG MODULE
1778686-655		SV	1	C6 INDICATOR
1783180-122		SV	1	INTEGRATED INST RACK
18013B-011		OH	1	VSI
18013B-012		OH	1	VSI
1801-CH		OH	10	INDICATOR SIMPLE
180806-007		SV	1	AMP ASSY
1810-010		SV	1	ROSEN MONITOR
18-1030-2		SV	1	INVERTER
1811D605		NE	1	PILOT STATIC TEST SET
18152-1		SV	1	MODULE
18152-309		SV	1	IND
18152-907	422-18152-907	SV	1	MODULE
18152-983		SV	1	MODULE
18-1814	96774-18-1814	OH	1	TORQUE PRESSURE IND
18-2021	MS28010-1	OH	1	IND, PRESS, MULTIPURPOSE
18253G-19		NE	1	ADAPTER HEADSET
183-0251-000	183-0251-00	NE	5	CAPACITOR
18-380011	19B428	OH	1	FUEL QTY GAGE
18422-0		AR	1	THERMOSWITCH HEATER CONTROL

184-7668-000		NE 45	CAPACITOR
18650-000-04	704A44242008	SV 1	DAMPER TAIL SKID
1865-40		SV 3	FILTER DIFF- PRESSURE SWITCH
18790-500		NE 1	FLIR HARNESS
188-3305-901		SV 2	EMERGENCY LIGHTS BOX
18-947-1		SV 3	INVERTER
189-740-2		SV 1	INVERTER
189-740-2		NE 3	INVERTER
18-994		SV 3	ALC INVERTER
18-996		SV 4	ALC INVERTER
19095-100-00	19095-100-00B	SV 1	DRAG STRUT JACK, NLG
19100-0101		SV 1	GPU
1916400-7		NE 2	SHUT OFF VALVE
1918312-1		NE 1	TEMPERATURE SENSOR
19210-00-04		SV 1	CRASHWORTHY SEAT
192743-0001		AR 1	PSU SPEAKER
1936AA		SV 1	TRANSMITTER
1-936-BA		SV 1	TRANSMITTER
1945F200	1945F200W01	SV 1	ACTUATOR, MLG
1945G200A01		SV 1	MAIN LANDING GEAR L/H
1957EG		OH 1	INDICATOR DOUBLE
1957EH	3160.S.73.47.940	OH 6	INDICATOR DOUBLE
195-83072-1		NE 1	DEFLECTOR, FWD, WINDSHIELD
1962-26-1		SV 1	SWITCH PANEL
1-99302		NS 2	LINING
19A2593	206-073-913-1	SV 2	BLOWER
19A2696	222-325-009-101	SV 1	BLOWER
19E143-1A		NE 2	BENDIX SHAFT
1C27-10		AR 1	PUMP FUEL CARTRIDGE
1C27-11		SV 1	FUEL BOOST PUMP
1C469-6-443		OH 1	TRIM SERVO
1C64-7		SV 4	PUMP
1D1917		OH 1	INDICATOR
1G-1272		SV 1	AUDIO GENERATOR
1S14980-1		SV 1	FCU PUMP & MOTOR
1U262-001-10		AR 1	DIRECTIONAL GYRO
1U262-001-39	4000B39	OH 1	GYRO
1X25166857	EUROCOPTER	SV 1	DRIFT
1X25170023	EUROCOPTER	SV 1	DRIFT
1X31711W5	EUROCOPTER	SV 2	MOUNTING TOOL
1X36166806	EUROCOPTER	SV 1	SOCKET WRENCH
1X53166817	EUROCOPTER	SV 1	PULLER EXTRACTOR
1X53170049	EUROCOPTER	SV 1	PULLER EXTRACTOR
1X53174739	EUROCOPTER	SV 1	DRIFT

1X54176702	EUROCOPTER	SV	1	DRIFT
200000-1		OH	1	TANK RH, LONGI CRASHWORTHY
2000029-61		SV	2	SECURITY BELT
2000-106	SRC-2000	SV	1	SPECIFIC RANGE COMPUTER
200-0452-00	200-0452-00-R12	NS	1	MODULE
200-05330-0002		SV	1	EFIS AP FD PANEL
200-071-003	76450-01078-102	OH	1	FUEL PRESSURE INDICATOR
200-08777-0010		FN	1	SONY REPLACEMENT
2000-902	SRC-2000	SV	1	SPECIFIC RANGE COMPUTER
2000-902-2G	SRC-2000	SV	1	SPECIFIC RANGE COMPUTER
2001-053-01-0	A0089-100N	SV	1	DISPLAY UNIT
20-0158-1IR		NE	1	EYE BROW LIGHT
20018-11308	20020-11365	OH	1	AIR SPEED INDICATOR
20020-11190		OH	1	AIRSPEED INDICATOR
20020-11212	222-375-027-107	OH	1	AIR SPEED INDICATOR
20020-11293		OH	5	AIRSPEED INDICATOR
20020-11293E034-438		OH	1	AIRSPEED INDICATOR
20020-11327		OH	1	AIRSPEED INDICATOR
20020-11388	222-375-027-113	OH	1	INDICATOR, AIRSPEED, PITOT, STATIC
200-2752-03	200-02752-0003	NS	1	VCO
200-2752-04	200-02752-0004	NS	1	VCO
200-4273-00		AR	1	RADAR ADAPTER
200-92704-101	MT-851	AR	1	MOUNT ASSY
200SGL115Q-2		OH	1	STARTER GENERATOR
200SGL129Q		OH	1	STARTER GENERATOR
20110-1-03	21105-2-03	SV	1	NDB-2 NAV DATA BANK
20230M1		SV	3	CONTROL UNIT
203-021-003	76450-01078-103	OH	1	FUEL QTY IND
203-022-005	76450-01078-101	OH	1	ENGINE OIL TEMP AND PRESS IND
203-022-008	76450-01078-112	OH	1	TRANS OIL TEMP IND
203-022-009	76450-01078-126	OH	2	OIL TEMP AND PRESS IND
203-022-012		OH	1	INDICATOR OIL PRESS & TEMP
203-022-013	76450-00906-102	OH	5	INDICATOR OIL PRESS & TEMP
203-022-016	76450-00907-103	OH	2	INDICATOR, OIL TEMP & PRESSURE
203-023-003	76450-01078-104	OH	1	DUAL HYD- PRESS-IND
20322-501		SV	2	CO-PILOT ANNUN CPLR
2035482-0701	5985-01-109-8878	NS	10	ISOLATOR,RADIO FREQUENCY
2037923-0503	5975-01-307-3609	OH	1	FRONT PANEL
2038070-0501	5998-01-107-4863	SV	1	ROLL AMP ASSY
2038992-0501	5841-01-089-2745	OH	1	RADAR SET SUBASSEMBLY
2039016-0501	5996-01-088-6358	OH	1	AMPLIFIER, RADIO FREQ
2039272-0502	5841-01-340-3771	OH	1	RADAR SET SUBASSEMBLY
2039273-0501	5841-01-088-3812	OH	3	POWER SUPPLY
204-001-264-1	204-001-264-001	NS	1	BOX ASSY

204-010-937-007	SGT520-6	SV	2	DAMPER ASSY
204-011-164-001		NS	2	STOP
204-011-174-1		NS	1	SPACER
204-011-179-1	5340-00-157-7846	NE	1	CLEVIS, ROD END
204-030-846-001		NS	1	SWIVEL ASSY
204-030-893-91		NS	4	BRACKET
204-032-743-1		NS	1	PLASTIC
204-032-743-1		NS	1	PLASTIC
204-040-219-001		NS	1	PACKING
204-040-760-3	204-040-760-003	OH	1	OIL FILTER
204-040-801-1	204-040-801-001	OH	1	GEARBOX
204-040-929-2	204-040-929-002	SV	1	COVER AND LIFT PLATE
204-060-005	76450-00904-105	OH	2	TURBINE INLET TEMP IND
204-060-006	76450-00904-106	OH	2	TURBINE INLET TEMP IND
204-060-663-003	204-060-663-3	NE	18	SWITCH ASSY, FUEL FL
2040918-0501	7021-01-269-3244	OH	1	COMPUTER,DIGITAL
2041441-0101	5975-01-192-0723	OH	1	MOUNTING BASE
2041442-0102		NS	1	MOUNTING BASE
204A-1A1A	MS28008-1	OH	1	INDICATOR TEMP
204A2F1A	MS28004-1	OH	1	INDICATOR TEMP CYL HEAD
205-001-916-1	205-001-916-001	NS	2	BELLCRANK ASSY
205-032-161-006		NS	1	BRACKET
205-032-616-006		NS	1	BRACKET
205-040-229-001		SV	4	GEAR
205-050-125-1	205-050-125-001	OH	3	FIXED FLOAT DAMPER
205-070-283-003	8D181CDG	OH	1	TACH N1
205-070-710-1	205-070-710-001	NS	1	LEG ASSY
205-070-729-5	205-070-729-005	NS	1	CUPPORT BRACKET
205-072-708-001		NS	1	TUBE ASSY
205-075-158-001	205-075-158-1	OH	1	OIL PRESSURE INDICATOR
205-961-383-21		NE	1	CABLE ASSY
205RGU/FA/1		SV	1	RATE SENSOR
206-001-173-107A		NE	1	STICK ASSY
206-001-400-9		AR	3	LEVER ASSY
206-032-445-007		NS	1	SUPPORT ASSY
206-040-407-7	206-040-407-007	OH	1	TAIL ROTOR OUTPUT SHAFT
206-050-141-024		NS	8	AXLE ASSY
206-062-627-003	22A649	SV	1	TACH GENERATOR
206-062-831-1		NS	1	LINE ASSY
206-070-266-9	6501-3008	OH	1	N1 INDICATOR
206-073-913-1	19A2593	SV	1	BLOWER
206-075-190-001		OH	1	TOT INDICATOR
206-075-676-103	124-1014	OH	1	INDICATOR, FUEL PRESS & LOAD
206-075-681-117	DL401-15	OH	1	DUAL TACH IND

206-075-681-123	DL401-18	OH	1	DUAL TACH IND
206-075-711-001	6620-01-034-0883	OH	1	INDICATOR, TORQUEMETER
206-075-711-1	6620-01-034-0883	OH	1	INDICATOR, TORQUEMETER
206-076-037-001	206-076-037-1	OH	1	VALVE
206-360-501-101	10687D	AR	1	OIL COOLER
206-706-201-021		NS	1	NULL
2068623-0701		NE	1	WAVEGUIDE
206-951-383-011K		NS	2	CABLE ASSY
206-961-383-21		NS	1	CABLE ASSY
2070499-0101		SV	1	MOUNTING TRAY
2070499-0102		SV	1	MOUNTING TRAY
2070499-0104	MBA-1L	SV	1	MOUNTING TRAY
2070965-0101	5841-01-089-1022	SV	1	RADAR CONTROL
2087772-7304	CVA73-190	SV	1	ANTENNA COUPLER
209-062-005-001	209-062-005-001WTD2	SV	1	INSPECTION TOOL
209-062-104-001		SV	1	TUBE ASSY
209-063-010-1		NE	5	GASKET HEATING SYSTEM
209-076-021-013	209-076-021-13	OH	1	CYLINDER ASSY HYD
2090JFA		OH	1	PUMP FUEL BOOSTER
209-175-301-001		SV	1	VOLTAGE
20919-031		NS	1	INDICATOR
20919-033		NS	1	INDICATOR
20919-034		NS	1	INDICATOR
20919-035		NS	1	INDICATOR
20919-036		NS	1	INDICATOR
20919-037		NS	1	INDICATOR
20919-039		NS	1	INDICATOR
20919-042		NS	1	INDICATOR
20VR4D		SV	1	BATTERY PACK
2100-1020-00	FA2100	SV	2	SSCVR
2100284-4		SV	1	NAV COMPUTER UNIT
2100-8006-00		NS	1	MOUNTING TRAY
2103401-2		SV	1	SOURCE
2107-B-6		OH	1	RMI
2107D-B-6		SV	1	RMI
2116-40-1116	UNS-1L	SV	1	FMS
2117404-5	SERIES 4	OH	1	ELECTRONIC CONTROL UNIT
2118478-1		SV	2	CONTROLLER, ELECTRONIC UNIT
212-030-044-001	212-030-044-1	NS	1	COVER
212-030-044-001		NS	1	COVER
212-070-108-001	8DJ131AAJ	OH	1	INDICATOR TACHOMETER
212-070-116-003	124-972A	OH	1	OIL TEMP & PRESS IND
212-070-116-009	124-045	OH	1	OIL TEMP AND PRESS IND
212-070-116-3	124-972A	OH	1	OIL TEMP & PRESS IND

212-070-116-9	124-045	OH	1	OIL TEMP AND PRESS IND
212-070-160-007	9813-25-07	SV	1	DUAL TORQUE INDICATOR
212-070-160-017		SV	1	TORQUE INDICATOR
212-070-160-021	18-1838-21	OH	1	INDICATOR, DUAL TORQUE
212-070-160-129FM	9813-25-17	SV	1	DUAL TORQUE INDICATOR
212-073-912-1	30756-1	SV	1	SQUIB VALVE
212-075-523-101		SV	1	COMM PANEL
212-6000-09-1		NE	8	GASKET
212CW		SV	1	DRY AIR PUMP
21311MI		SV	1	INTERFACE UNIT
2133VENT		NE	2	VENT ASSY
213522B	213723	SV	1	ENGINE SYNC UNIT
213545A	213723	SV	1	ENGINE SYNC UNIT
213798C		SV	1	GOVERNOR COM
2138-50000-106	76900-01880-106	SV	2	AMPLIFIER
214-001-347-005	67A370	SV	1	ACTUATOR
214-001-347-007		SV	1	ROTARY ACTUATOR
214-001-347-101		OH	1	ACTUATOR
214-040-013-115	214-040-020-103	OH	1	GEAR BOX ASSY, COMB
214C50-60		SV	1	SWITCH, PRESSURE
215371-0		NE	1	DIGITAL PRESSURE GAUGE
217596-0		SV	1	FWD LEFT E.F.S. ASSY
217597-0		SV	1	FWD RIGHT E.F.S. ASSY
217598-0		OH	1	AFT LEFT E.F.S. ASSY
217599-0		OH	1	AFT RIGHT E.F.S. ASSY
217-601933-215	CMA-1100	NE	1	I/O CABLE ASSY
21867-1		OH	1	GENERATOR
2193-10C		NS	2	SERRATED DISC
21B67-1A	21B67-1	SV	1	CONTROL UNIT, GEN, AC
220-352864-000		NE	1	LAMP
22125BC050042L		NS	4	SCREW
221-3992-803		NS	1	AIR ASSY
22-1863-048		SV	1	FAILURE WARNING PANEL
22-1863-089	704A47723068	SV	1	FAILURE WARNING PANEL
22-1863-089-REP	704A47723068	SV	1	FAILURE WARNING PANEL
222-001-072-105		OH	1	SPR CART ASSY
222-001-072-109		OH	2	SPR CART ASSY
222-005-001-101		OH	1	ACTUATOR
222-005-030-101		OH	1	RPM LIMIT DETECTOR
222-005-030-111		OH	2	RPM LIMIT DETECTOR
222-025-182-001		NS	2	SEAL NOSE SKIN
222-031-306-033		NS	1	PANEL
222-036-017-001		NS	2	SHIM
222-065-562-133		NS	1	SEAL

222-075-132-101		SV	1	PANEL
222-366-684-103		SV	1	LOWER PROBE
222-366-684-103		AR	1	LOWER PROBE
222-375-010-107	80-0500-1	SV	1	ANNUNCIATOR PANEL
222-375-010-131	80-0500-17	SV	1	ANNUNCIATOR PANEL
222-375-020-103	HAI222070110	OH	1	TRIPLE TORQUE IND
222-375-021-101	78200000-01	OH	1	TRIPLE TORQUE IND
222-375-027-111	20020-11365	OH	2	AIRSPEED IND
222-375-033-101	4300-8170-1L	OH	3	ALTITUDE IND
222-375-071-105	78300000-05	OH	1	INDICATOR, TRIPLE TORQUE
222-375-077-113		SV	1	PRESSURE TRANSDUCER
222-382-002-103	143000-104	SV	1	DIRECTIONAL SERVO
22251BC050060L		NE	20	SCREW
22252BC050011L		NS	10	BOLT
22-260-014		OH	1	MANIFOLD PRESS IND
22-260-042-1A		OH	2	MANIFOLD PRESS IND
22-280	22-280-015A	OH	1	TACHOMETER INDICATOR
222-899-604-101		OH	1	PA CONTROL
222-899-604-113		SV	1	PA CONTROLLER
2231321-4		SV	1	UNIT-INTEGRAT FDR/HUMS
2231896-2		SV	1	PANEL-CONTROL PANEL
2241500-4A		SV	2	MDAU
225398-6		NS	1	CONNECTOR
225973-4		NS	1	CONNECTOR
2260-1001-1	209-075-326-1	OH	1	DETECTOR, RPM LIMIT
22-697-06-1		OH	1	AIRSPEED INDICATOR
22885-21-4174		SV	2	WING LIGHT
22885-22-4174		SV	2	WING LIGHT
229-0324-010		SV	1	VERTICAL ACCELEROMETER
229-0324-010-M		SV	1	VERTICAL ACCELEROMETER
229-0324-020		SV	1	ACCELEROMETER
229-0324-020-M	SA111128-020	SV	1	ACCELEROMETER
229-1001-000	229-1001-00	NE	1	MOTOR CONTROL
229-3044-040		NS	1	SYNCHO
229-6026-030		NE	1	SYNCHO
22A703		SV	1	GENERATOR
230-0257-00	6105-00-578-7304	NE	1	MOTOR DC
2302KGA/CP/1		SV	1	TACH GENERATOR
23032-022		SV	1	STARTER GENERATOR
23032-048		NE	2	STARTER GENERATOR
23032-048		SV	5	STARTER GENERATOR
23032-049		NE	2	STARTER GENERATOR
23032-049		SV	2	STARTER GENERATOR
23032-062		NE	1	STARTER GENERATOR

23032-062		SV	4	STARTER GENERATOR
23032-2711		NS	4	BACK PLATE
2306-557-00-10	704A37-650-100	OH	2	FUEL QTY IND
23081-001		NE	2	STARTER GENERATOR
23081-043		NE	1	STARTER GENERATOR
23081-043		OH	3	STARTER GENERATOR
23081-043		AR	3	STARTER GENERATOR
23081-303		NE	1	SUPPORT ASSY BEARING AND BRUSH
2309-355-00-11		SV	1	AMMETER, DC
2311M-205-2		NE	1	MOTOR ASSY ELECTRIC
2312G-25		SV	1	TESTER
2312M41-12		NE	1	CONVERTER
2312M41-12		NE	2	CONVERTER
2312M-41-13		SV	1	CONVERTER
2312M-41-20		NE	1	CONVERTER
2313M-427-1	02313M-427-1	AR	1	WIPER MOTOR ASSY
2313M-427-1	222-625-001-101	SV	1	WIPER MOTOR ASSY
2315M116-1		NE	1	WIPER BLADE ASSY
2315M116-1		NE	2	WIPER BLADE ASSY
2315M6-1		NE	1	BLADE
2315M-75-2		NE	1	BLADE
233-1-2		SV	1	CURRENT SENSOR
233209-03		SV	1	FILTER
2338-50		AR	1	ANTENNA DME/TRANS
2381-05-L-18-IG-C		NS	1	EYEBROW
2383-05-L-18-IG-C		SV	2	EYEBROW
2393-05-L-18-IG-C		NS	1	EYEBROW
23932-005	570-23932-005	OH	1	ALTIMETER
23932-101	570-23932-101	OH	1	ALTIMETER
23932-901	570-23932-901	OH	2	ALTIMETER
2400-25-4-4-2		AR	1	PULSELITE CONTROL UNIT
24043GR79		NE	10	LINING ROTOR BRAKE ASSY
241-0570-010		NE	3	FILTER,LP
2420C1		NE	2	CONTROL UNIT
24353-0001		NE	1	CONNECTOR
244-602183-000		SV	1	POWER INTERFACE UNIT
245-604128-000	CMA-1100	SV	2	PILOT VIEW
245-604129-000	CMA-1100	SV	2	PILOT VIEW
245-604170-008	CMA-1100	SV	2	EMU
245-604244-215	CMA-1100	SV	2	EFB MOUNT
24640QAE0101		NE	1	FUEL JETTISON ASSY
24640QAE0101		SV	5	FUEL JETTISON ASSY
249-1398-000		NE	2	CONNECTOR ASSY
24HP883-101		NS	2	SHROUD PAD BASE

250003-1		SV	2	DC POWER SUPPLY
2500979-1		NS	6	CONTACT
25011-00312		SV	2	CVR CONTROL UNIT
2501-1-192H101A		SV	1	LAV SWITCH PANEL
2501-2-029H402A	2501-2-029	SV	1	SWITCH PANEL
2501-2-030H402A		SV	1	PANEL
2501-2-252/H101A	2501-2-252	SV	1	AIRSHOW MODULE
25020-1157	704A47-113-102	SV	1	AIRSPEED INDICATOR
25020-9601		OH	1	AIRSPEED IND
2504094-5		NE	2	COIL
2504-3002A-040M	6610-01-214-5884	OH	1	COMPUTER UNIT
2504-3002A-04ET		OH	1	COMPUTER UNIT
2504-600-004A		NS	1	TEMP PROB MOUNT
2504-900ET		OH	1	TRANSDUCER ASSY
25100-004	540-25100-004	SV	1	ALTITUDE ALERTER
25174A-25A		SV	1	ANGLE OF ATTACK TRANSDUCER
2524667-12		SV	1	POWER TRUB GOVERNOR
2524667-4		SV	1	GOVERNOR
2524738-30		AR	1	RR250 FUEL CONTROL
2524738-30		OH	1	RR250 FUEL CONTROL
2524843-1		SV	1	GOVERNOR CONTROL
2524843-1A		SV	1	GOVERNOR CONTROL
2524843-3		SV	1	N2 REGLER
253-E0873-00		SV	1	S ROTOR SPEED ENCODER
25486-00426		NE	2	RELAY ARMATURE
256-1		SV	3	AIRSHOW CURRENT SENSOR
257.011-001		NE	1	RN6 EURONAV IV DIGITAL MAP
257.01-15G		NE	1	RN5-2.9 MAP-COMPUTER 2 RS422
257.012-002		NE	1	RN6-CM EURONAV DIG MAP
25850-219		OH	1	MAX ALLOW A/S IND
2586257-1		SV	6	COMPENSATOR
2586689-902	SP-50A	SV	1	AP CONTROLLER
2587193-42		OH	1	GYRO
2587193-43		OH	1	GYRO
2587400-844		SV	1	AIR DATA COMPUTER
2587516-8		SV	1	ELEC ASSY
2588302-4		OH	1	GYRO DIRECTIONAL
2588767-901		SV	1	RADIO DIR IND
2590004-904	SP50G	SV	1	ALT PRESELECT COUPLER
2591201-922	CL-201	SV	2	COMPASS COUPLER
2591202-902		SV	1	COMPASS CONTROLLER
2591411-444	HZ444	OH	2	HORIZON FLIGHT DIRECTOR
2591714-14		SV	1	ALT COMPUTER
2591715-4		SV	1	AIRSPEED COMPUTER

2593342-932		SV	1	COMPUTER
2593342-932		AR	1	COMPUTER
2593342-976		SV	1	COMPUTER
2593342-976		AR	1	COMPUTER
2594775-200		SV	1	ALTITUDE CONTROL
25ARM300-20E20		NE	1	INSULATOR
25ET1-S		NE	1	SWITCH
2-5X15-21B6		NS	1	ORING
26000-30-07		AR	1	Secondary Flight Display
2600-600-0000		SV	1	TAS/PLUS COMPUTER UNIT
2600-700-0000		SV	2	TAS/PLUS COMPUTER UNIT
260-2351-01		OH	1	IND, DUAL FUEL PRESSURE
262-2348-010	KW204S	NE	2	DIGITAL DISPLAY IND
26400-102		SV	1	CONVERTER
265-100A		NE	5	RELAY
266-7566-010		NE	4	SWITCH
2670104-2RX		NE	1	ANNUCIATOR PANEL
267-937-005		OH	1	IND, FUEL FLOW
269A1278		NS	5	SEAL
269A2063		NS	4	OIL SEALS
269A2335		NS	1	DAMPER PLATE
269A4714		AR	1	PANEL
269A5050-44P		NS	4	BEARING
269A5463		NS	4	CLAMP
269A5492-3		NS	6	SHIM
269A6053-3		NS	1	BUMPER
26ET32-T		NS	1	SWITCH
27000-01-20	9030-3046	NS	1	AIR DATA UNIT
2700-004A22		SV	1	COCKPIT DISPLAY
27005-00-08		SV	2	AIR DATA DISPLAY UNIT
2700-500-A2A00BJDGF		NS	1	DIGITAL CABIN DISPLAY
270-2196-010	590B2	OH	1	AIRSPEED SENSOR
270-2878-070	G7632-108	OH	2	CTL32G NAV CONTROL
270-839	839	SV	2	MICRO TOUCH PANELS
2716-00		NE	1	AEROTHERM AIR TEMP GAGE
273AA-205	311601	NS	1	COAX CABLE ASSY
273AA-206	311601	NS	1	COAX CABLE ASSY
273AA-207	311601	NS	1	COAX CABLE ASSY
273AA-208	311601	NS	2	COAX CABLE ASSY
273AA-220	311601	NS	1	COAX CABLE ASSY
273AA-221	311601	NS	1	COAX CABLE ASSY
273AA-222	311601	NS	1	COAX CABLE ASSY
273AA-223	311601	NS	1	COAX CABLE ASSY
277200-002		AR	1	COURSE DEVIATION INDICATOR

277200-214		SV	1	COURSE DEVIATION IND
2797-4		SV	4	AQUAFIX 406 GPS
28-1750-18	A141938	NS	2	RING
28260-004	930-28260-004	SV	1	DISPLAY CONTROLLER
282K2770-051		NE	1	CHCECK VALVE JET PUMP
2850-1		NS	1	SWITCH
28711-902	930-28260-004	SV	1	DISPLAY CONTROLLER
2891ESR		OH	2	DIRECTIONAL GYRO
29007-007	521-29007-007	SV	1	ALTIMETER
29007-204	521-29007-204	SV	1	ALTIMETER
29-1000		OH	2	OIL TEMP IND
2915-12-341-8026	300991124	SV	1	GOVERNOR
29264-001	CA-154-3A	SV	1	EMERGENCY BATTERY SUPPLY
29342-001		AR	1	DISPLAY CONTROL TIME
29400-212		SV	2	RAD ALT CONVERTER
29400-4117		SV	1	RAD BAR CONVERTER
29400-4217		SV	1	RAD BAR CONVERTER
29400-8101		SV	2	RAD BAR CONVERTER
29400-8112		SV	1	RAD BAR CONVERTER
2-95X23-47-61D6		NS	1	ORING
2A350-1D1		SV	1	STATIC INVERTER
2C12-1	4320-01-483-9169	OH	1	FUEL PUMP
2LA001625-04WS		NE	2	TAIL LIGHT
2LA455359-00		NE	1	LED NAVIGATION LIGHT GREEN
2N3637		NE	3	TRANSISTOR
2N4925	5961-00-479-1735	NE	5	TRANSISTOR
2N6764		NE	5	TRANSISTOR
2N6782		NE	4	TRANSISTOR
2N6788		NE	4	TRANSISTOR
2S2C31		NS	1	RELAY
3001-01-100		NE	1	Accelerometer single axis
3001-01-101-4		SV	1	SINGLE AXIS ACCEL
300-2184-0000	300-2184-000	SV	1	RT30 GUARD RECEIVER
300-2202-000		SV	1	MOUNTING TRAY
300-2241-000		SV	1	GUARD RECEIVER WITH CRYSTAL
300-2265-000	H4	SV	4	RET CORD
3003-12-R		SV	1	BOWL ASSY
30050-0707-1121	GNSX	AR	1	GNSX RPU
30050-0909-1121	GNSX	SV	1	GNSX RPU
30-0504-23		NE	1	ANTI COLL STR LIGHT
30-120-16		NS	185	PIN
3014C		SV	2	POWER UNIT
3017-42-211	UNS-1EW	SV	1	FMS WITH FC06 SOFTWARE UPGRADE
3019-41-201	UNS-1ESPW	SV	3	FMS WITH FC06 SOFTWARE UPGRADE

3019-41-209	UNS-1ESPW	SV	3	FMS WITH FC06 SOFTWARE UPGRADE
30-1994-1		SV	1	LIGHT, NAV, STROBE
30230-1165	222-375-030-001	OH	2	INDICATOR, VERTICAL VELOCITY
30-231-31		SV	1	SMOKE DETECTOR
30-2478-1		SV	2	FWD POSITION LIGHT
30-2478-2		SV	2	FWD POSITION LIGHT
303-006-005	76450-01078-123	OH	2	DUAL TORQUE INDICATOR
303-006-006	76450-01078-125	OH	2	DUAL TORQUE INDICATOR
30-303A		OH	1	CONTROL AMP FIRE DETECT
30-303AT		SV	1	AMPLIFIER
303990-02	TC-M	NS	1	ALTIMETER
3043574-01		NE	2	FUEL FILTER KIT
3044180-01		NE	1	FUEL AIR BLAST
3045819-01		NE	1	KIT FUEL FILTER CHANGED
3050562-01		SV	4	ACCUMULATOR, ECOLOGY SYSTEM
30510-133	422-30510-133	SV	1	AIR DATA COMPUTER
305154-00		AR	1	SAE5-35
3054015-3		OH	1	AUX SERVO PRESS REDUCER
30542-102		SV	1	CABIN DISPLAY PANEL
3057-147		OH	1	TORQUE IND
3057-148	704A47621092	OH	1	TORQUE INDICATOR
3057-148-1	704A47621094	OH	1	TORQUE INDICATOR
3057-148-2		OH	1	TORQUE IND
3057-149-6	704A47621120	OH	1	TORQUE IND
3057-165-2		OH	1	TORQUE INDICATOR
3057-169-2		OH	1	TORQUE INDICATOR
3057-3-10-143		SV	1	TORQUEMETER
3057-3-134		OH	1	PRESSURE INDICATOR
3057-3-136-6	704A47621128	SV	1	TORQUEMETER INDICATOR
3059026-01		SV	1	CARBON SEAL-CLUTCH DRIVE
306-4-1200		NS	5	10FT HOSE
30690B		SV	1	WINSLOW AEROFILTER
3070-00-01		SV	1	UNIVISION COMPUTER
30702-2		SV	1	MOUSE KEYBOARD INT EXT
3076214-01		OH	1	HEATER, OIL TO FUEL
3080-201-1		SV	1	INDICATOR
3080-201-2	117-94069-1	OH	2	DUAL TORQUE INDICATOR
3080-201-3	117-940711	OH	1	TORQUE INDICATOR
3080-201-4	117-902121	OH	1	TORQUE INDICATOR
30-97		SV	1	BRAKE ASSY
30E01-1B		OH	1	GENERATOR
30Y1000		OH	1	TACHOMETER INDICATOR
310-007-003	76450-00902-103	OH	1	DUAL TORQUE IND
310155-2		SV	3	AUDIO JACK

310155-2		NS	1	AUDIO JACK
3113645-01		NE	2	COVER
3121-748		FN	8	INNER SLEEVE
3121-748		NE	8	SLEEVE
31230-1120		OH	2	VSI
31300-0101-0111	C5000	SV	1	CONTROL UNIT
31300-0101-1200	C5000	SV	1	CONTROL UNIT
3130S35-60-010		NS	1	SUPPORT LH
3130S-68-00-907		NS	2	BEARING
3130S-88-10-020-1		NS	2	CABLE
31480-7123	575-31480-7123	OH	1	COMBINED SPEED IND
315A-88-00-0101		NS	3	CABLE
3160S12-20-960		NS	2	SEAL
3160S33-20-017		NS	1	THREADED PIN
3160S68-10-001		SV	2	HOUSING
3160S86-02-000-1		OH	1	PEDAL ASSY
318-00140		SV	1	TRANSMITTER
3192936-7		NE	60	STUD
32005-023		OH	1	TACH GENERATOR
320-1066-000	030-24478-0001	NE	7	COAX CONNECTOR
3202312-AB077		NE	2	FLIR HARNESS
3202312KAB240		NE	2	FLIR HARNESS
3202313KAD		NE	2	FLIR KIT
3203487-1	3203487-1K240	NE	1	FLIR KIT
3203487-1K240		NE	3	FLIR KIT
32-1012		SV	1	RATE OF CLIMB INDICATOR
32120-001		SV	1	COFFEE MAKER G280
3230008-3	3000U	SV	1	ALTITUDE SERIALIZER
324700M00		SV	1	DAMPER, ROLL
324900M03		SV	1	DAMPER, YAW
324AG64		SV	1	AFT FLOAT PACK ASSY PORT
3252013-0601		OH	1	ALTIMETER, ENCODER
326A25-30		SV	1	ELECTRO VALVE
32979-001		SV	1	ALT COMPUTER
33075-541	575-33075-541	OH	1	MACH AIRSPEED IND
330A98-3532-00		SV	1	WRENCH
331-0015-292		NS	1	CONN KIT
331-0025-292		NS	1	CONN KIT
3311724-1	6220-00-576-3922	NE	4	PANEL INDICATING
3311A		SV	1	FUNCTION GENERATOR
331A		SV	1	FUNCTION GEN
332A67-4260-0051		SV	1	UNIT CONTROL, 426VU
332A67-4270-0051		SV	1	AUX- ENGINE CONTROL PANEL
332A67-4270-01		SV	1	AUX- ENGINE CONTROL PANEL

332A67-4271-00AA		SV	1	AUXILIARY CONTROL PANEL
332C-1		OH	1	DUAL RMI
332P61-6512-09		SV	1	AVIONICS SHELF
3357-9209		NS	1	JUNCTION SHELL
33776-0002-044		SV	1	ACTUATOR FITTING
33776-44788-041		SV	1	UNIT, RADAR ALTIMETER
33776-57574-042	76286-33776-57574-042	SV	4	S76 HEADLINERS
33776-66142		NE	4	RAD ALT KIT
33776-66143-041		NE	12	PLATE ASSY
33984-002	585-33984-002	SV	1	FUEL TANK TEMP C
34-0428020-65		NS	1	LAMP
34100-001	635-34100-001	SV	1	AIR DATA CONVERTER
34170-1X		SV	1	BAGGAGE LIGHT
341-93-3308-00		SV	1	TOOLING
341A31-4900-00		SV	1	BEARING BALL
341A41525400		SV	1	FILLET,LEG LH FWD
34401-30A22-1	6620-00-067-4946	OH	1	TRANSMITTER,PRESSURE
35020-11111		OH	1	VSI
350-321		OH	1	CYL TEMP IND
350-370		OH	1	TACHOMETER
350-93-3011-01	350A93-3011-01	SV	1	TOOLING
350-93-3302-01		SV	1	TOOL
350-93-3309-01	350A93-3309-01	SV	1	TOOLING
350-93-3711-00		SV	1	TOOL
350A00-0122-25		NS	2	LABEL
350A00-0138-31		SV	5	WEIGHT
350A00-0138-32		SV	1	WEIGHT
350A07-1156-71		SV	1	CONTROL PANEL
350A07-6544-75		NE	1	AFT COMMAND IMPROVEN
350A08-6011-14		SV	1	FOOTSTEP, RIGHT
350A08-6042-0151		SV	1	DOOR, RIGHT EQUIPED
350A08-8000-0072		NE	9	PIN AND FITTING
350A21106805		SV	1	BEAM ASSY, FRONT
350A21-1318-02		FN	2	FASTNER
350A21-1318-02		NE	1	FASTENER
350A2114382151		NS	1	DALOT
350A25-1082-20		NE	1	SHIM
350A31-1858-00		NS	1	SPACER
350A31-1872-21		FN	1	BUSHING
350A32110921		NE	3	WASHER LOCKING
350A32-3152-20		NS	1	BOLT
350A32-3152-20		NS	1	BOLT
350A-34-1015-21		NS	3	SPACER
350A37000305M		SV	1	MAIN ROTOR SHAFT

350A-37-1096-20		NE	5	LOCK WASHER
350A37-1178-20		NS	1	SHIM
350A55-1004-20		NS	6	SEAL
350A55-1031-04		NS	1	STRAP
350A58-1031-20		NE	4	DOG
350A73-0367-04		OH	2	ALTIMETER
350A73-1633-01		SV	1	ASSY ISO MOUNT
350A75-4005-02		SV	1	TANK,LOWER HYDRAULIC
350A76010701		SV	1	INDICATEUR EQUIPE
350A76014100		NE	1	COVER ASSY
350A76-1013-20		NS	1	HALF-FLANGE
350A76-1070-1		OH	1	INDICATOR EQUIPE
350A93-3201-00		SV	1	TOOLING
350A93-3204-00		SV	1	EXTRACTOR
350A93-3303-01		SV	2	EXTRACTOR
350A93-3405-10		SV	1	TOOLING
350A93-3405-11		SV	1	BUSH ASSY, LOCKING
350A93-3705-20		SV	2	EXTRACTOR
350D038-09		NE	1	CREW AUDIO PANEL MACHINING
351-1112-010		NE	7	IC LINEAR
351-1530-010		NE	50	MICROCIRCUIT
352-001		SV	3	AUDIO SELECTOR PANEL
352-1006-030		NE	2	TRANSISTOR
353-3740-200		NE	42	DIODE
355A32-0022-00		SV	1	BOX PRIN TRAN
355A32020002M		SV	1	PUMP OIL MGB
355A58-0917-03		NE	1	INDICATOR FLAG RH AFT
355A86-2008-20		FN	8	SHIM
3567401-3001		SV	1	TRANSMITTER
3571251-9110	222-375-022-101	OH	2	GAD PRODUCER TACHOMETER
3571251-9119	222-375-023-103	OH	2	INDICATOR
3571442-1004		SV	1	HORIZON IND
3571442-1004		AR	1	HORIZON IND
357-7204-010		NE	2	CONNECTOR
3600338-0001		NS	1	RDR1500B PHASED ARRAY
360-27-1210		SV	1	VSI
3603247-0001		SV	1	ELECTRON TUBE
3604618-0501		SV	1	MEMORY TIMER
3604989-0501	5841-01-331-9898	NE	3	REG BOARD ASSY
3605588-0501		SV	1	MOUNTING TRAY
360A32-1152-21		SV	1	VALVE
360A32-1163-01		SV	1	SUPPORT, EQUIPPED
360A32-3526-23		SV	3	BEVEL RING
360A57-2083-22Z		NS	1	SPACER

3614001-4001	064-1047-00	SV	2	VC-401B VHF COMM
3614002-4003		SV	1	COMM CONTROL
3614165-5512	AA5512B	SV	1	PHASE ARRAY ANTENNA
3614258-0802		SV	2	MT-1508 MOUNT
3614276-1004	CP-103A	SV	1	CONTROL
3614330-1001	071-1335-00	SV	1	CP-103D EFIS CTL PANEL
3614331-1001	066-4017-00	SV	2	NC-104B NAV CONCENTRATOR
3614331-1005	NC104B	SV	1	UNIT INTERFACE RADAR 1400
3614335-1002	SG101B	SV	1	SYMBOL GENERATOR
3614477-8601	IN861A	OH	1	RADAR INDICATOR
3614522-1019	CP-103E	SV	1	CONTROL PANEL
3614549-1008	3614549-1008-K	SV	1	RDR1500 INDICATOR MOUNT
36200-101	222-366-615-101	SV	1	VALVE
362-00135-100		SV	1	FLIGHT STATUS CONTROL
365A00-0337-DT		NS	1	DECAL
365A00-0337-DX		NS	1	DECAL
365A27326601		SV	1	ROD
365A2733050401		SV	1	COLLECTIVE PITCH STICK COPILOT
365A31117904		SV	1	MAIN ROTOR SHAFT
365A31-4706-00		SV	9	UPPER FLANGE,W SLEEVE & MASK
365A33-2167-20		NS	1	WEIGHT
365A33-2168-20		NS	5	WEIGHT
365A33614520		SV	2	CONTROL ROD
365A52-1266-20		NS	1	JOINT SEAL
365A57-3178-21		NE	1	DECAL
365A61-3416-21		NS	1	LOWER CUP
365A84-3061-20		NE	2	HOOK
365A91-2141-01		AR	1	JACK ADAPTER
365S67-8413-20		NS	1	PRESSURE TRANSMITTER
365W84-3061-20		NS	2	HOOK
366.684-921		NE	1	SERVICE SATION BOX
366-D-455-01		SV	1	ASSY-MGB FIRE DETECTOR
369A1140		NS	2	PAD
369A7951-47		NS	4	BEARING
369D21333		NS	1	STRIKER PLATE
369D27517NC		NS	8	COUPLER
37.014.20.000		NE	1	COLLER OIL AIR
37.016.20.000/3		NE	1	OIL COOLER
37.036.24.000		NE	5	VENTILATION
371-007-002		OH	2	PRESS TRANS
371-007-004		OH	1	PRESS TRANS
371-1-4		SV	5	CONTROLLER, 6 CIRCUIT
3718009-30		NS	2	SCREWLOCK
3718547-5		NS	1	BACKSHELL

375-1-3		SV	1	CONTROLLER, 5 CIRCUIT, 2 DELAY
37695-422629-811	422629-811	NS	1	HARNESS
380-004		SV	1	AUDIO PANEL
380-020		SV	2	AUDIO SELECTOR PANEL
3809-066-015		NS	2	BUSHINGS
38100-0128	PA520A	SV	1	ACTUATOR
38210-3941		OH	1	VSI
38210-490		OH	1	VSI
383392-1-1		OH	1	ENGINE AIR STATER
38399-330		OH	1	AIRSPPEED INDICATOR
38399-330-02	704A47113066	SV	1	INDICATOR,AIRSPPEED,MPH
38399-480		OH	1	AIRSPPEED INDICATOR
386500-4		OH	1	PUMP, GEAR TYPE
386500-5		SV	2	FUEL PUMP
39.1-1100-02		NE	2	SPAS-ACTUATOR
390-389001-0001	MG94A-1	OH	2	STARTER GENERATOR
3911213-9012	222-DK117	OH	1	MGT INDICATOR
3911213-9016	222-375-023-111	OH	2	MGT INDICATOR
3-912S0613-60		NE	52	ORING
393026-03236		SV	1	INDICATOR,LIQUID QUANTITY
393086-01236		SV	1	FUEL QTY IND (US GALS)
393086-01236		SV	1	FUEL QTY IND
3932241-9002	222-375-064-101	OH	1	IND, TOT DUAL FUEL QUAN
3932241-9008	222-375-064-103	OH	1	TOTALIZING DUAL FUEL IND
3941213-9003	222-375-022-105	OH	1	IND, GAS PRODUCER TACH
3941213-9014	222-375-022-111	OH	2	IND, GAS PRODUCER TACH
394400-1		AR	1	FUEL PUMP
395-6798		NE	1	BEARING
39600-584	704A47-212-002	SV	1	ENCODING ALTIMETER
396A7951-5L		NS	2	BEARING
397578-4-1		SV	1	TEMPERATURE SENSOR
397964-8		SV	1	VALVE
3A.63.32.20F.28.1.AB		SV	1	ALTIMETER
3A250-1A1		SV	1	STATIC INVERTER
3A43.32.50F.05.1.EG		OH	1	COUNTER DRUM ALTIMETER
3A43-42-50F-05-1-FT		OH	1	ALTIMETER
3A55.32.35F.00.0E		SV	2	Encoding Altimeter
3A61-22-20F-28-1-DS		OH	3	ALTIMETER
3A63.32.20F.28.1.AB		OH	1	ALTIMETER
3A632235F281HS		SV	1	Altimeter Drum Scale
3A65.22.20F.05.1.RB	3A652220F051RB	SV	1	ENCODING ALTIMETER
3A67.32.50F.05.1AE		SV	1	ENCODING ALTIMETER
3A67-22-20F-58-1-AZ		OH	1	ALTIMETER
3CRJ5		NS	1	SPEEDAIRE ENGRAVING PEN

3D2314-06		SV	1	ADJUSTER FLOW VALVE
3E2044-1		NE	1	DE-ICE BRUSH
3G20F		NS	4	PUSH BUTTON
3H55.32.35F.00.0.AE		SV	1	Encoding Altimeter
3H65.32.20F.28.4.BP		NE	5	ALTIMETER
3L0-453/4-5		AR	1	G SWITCH
4000020-002		NE	3	LIGHT ASSY COCKPIT UTILITY
400-0073-010	C-962A	SV	1	CONTROL UNIT 28V
4000096-001		NE	1	FILTERCAP NVG
4000-10		SV	1	ELT
4000-1002	206-070-275-5	OH	1	CLOCK
400-0106-000	C-1000	SV	1	CONTROL UNIT 28V
400-0106-010	C-1000	SV	1	CONTROL UNIT 28V
400-0125-101	RT18D	SV	1	FF RT
400-0130-002	C118	SV	1	CTL UNIT
400-0130-003	C118	SV	1	CTL UNIT
400-0130-005	C118	SV	1	COCKPIT CONTROL
400-0130-005	C118R	NS	1	CONTROL PANEL
400-0131-005	C118BR	SV	1	COCKPIT CONTROL
400-0132-013	WH5HFR	SV	1	FF CABIN CTL
400-0138-002		SV	1	FF COCKPIT CONTROL
400-0140-025		SV	1	VHF FM TX/RX
400-014135-01		SV	1	GPS DOWNCONVERTER
400-014635-0101	IC-18	SV	1	FLITEFONE INTERCOM
400-018100-12	1014744-001	SV	2	FF HANDSET
4000369-8501	DH861A	SV	1	HORIZON IND
400-041181-0001	CDM-451	SV	1	DME TRANSCEIVER
400-045500-0005		SV	1	AFIS DMU
400-045500-2011		SV	2	AFIS DMU
4000460-0501	AD3405A	SV	1	SYS INTER ADAPTER
400-047152-9005	CVC-152	SV	10	COMM CONTROL NVG
400-048100-0008	CVC-151	SV	10	VHF COMM TRANSCEIVER
4000503-0203	IN1202A	SV	1	INDICATOR
4000504-0301	DA1203A	OH	2	ANTENNA DRIVE
4000525-1212		SV	3	RDR1400 PHASED ARRAY ANT
4000525-1218		SV	1	PHASED ARRAY ANTENNA
40007-1A64		NS	6	ADAPTER
4000833-0207	IN1401A	SV	2	RADAR IND
4000833-0208	IN1402A	SV	1	RADAR IND
4000965-0210	IN1302B	OH	2	RADAR INDICATOR
4000985-3101	DM-2031A	SV	1	DME R/T
4000986-3101	IN-2032A	SV	1	INDICATOR
400100-128		NE	1	COMPASS STANDBY 28 VOLT
40-0103-31		OH	1	LIGHT BEACON

40-0117-1		SV	1	LIGHT ASSEMBLY
4001291-2104	IN2021A	OH	1	RADAR INDICATOR
4001597-2304	IU-2023B	SV	2	REMOTE COMPUTER UNIT
4001598-2303	IU-2023C	SV	1	REMOTE COMPUTER UNIT
4001639-2405	CC-2024C	SV	1	MULTI-FUNCTION CHECKLIST UNIT
4001922-5201	IN-1152A	SV	1	COLOR RADAR INDICATOR
4001943-0401	AA1504A	SV	1	RDR1500 ANTENNA ARRAY
4001974-0207	IN1502A	SV	1	RADAR INDICATOR
4001977-0654	CN1506A	SV	1	RDR1500 CONTROLLER NVG 28V
40020-01		SV	8	HYDRAULIC PUMP
40020-01		OH	10	HYDRAULIC PUMP
4002963-404	RH404	OH	2	RMI
4002963-444	RH444	OH	2	RMI
4002963-904	RH404	OH	1	RMI
4004444-901	RA-210	OH	2	RADIO ALT IND
4004T63G04		OH	2	STATOR VANE ACTUATOR
4005088-0502		SV	1	MOUNTING TRAY
400-6		NE	25	AIRSPEED POINTER
4007261-0502		SV	1	RACK
4007543-0502		SV	1	MOUNTING TRAY
4007550-0507		NE	1	CONNECTOR KIT
4007561-0502		SV	1	MOUNTING TRAY
4007637-2	AT222	SV	1	ALTIMETER ANTENNA
4007701-9		NS	1	CONNECTOR
4008-103		NS	1	ECS RACK
400GL		SV	1	VOLTMETER
400R-1		SV	1	EMERGENCY LIGHT
400R-1		SV	1	EMERGENCY LIGHT
401/262		SV	1	ANTENNA CTL UNIT
4012373-812		OH	2	ACTUATOR
4012373-817		OH	2	ACTUATOR
4012373-903	SM710	OH	3	ACTUATOR
4012373-904	SM710	OH	3	ACTUATOR
4012373-905	SM710	OH	3	ACTUATOR
4012373-905	SM710	NE	10	LINEAR ACTUATOR
4012373-906	SM710	OH	3	ACTUATOR
4012373-907	SM710	OH	3	ACTUATOR
4012373-908	SM710	OH	3	ACTUATOR
4012373-909	SM710	OH	3	ACTUATOR
4012373-910	SM710	OH	3	ACTUATOR
4012373-911	SM710	OH	3	ACTUATOR
4012373-912	SM710	OH	3	ACTUATOR
4012373-913	SM710	OH	3	ACTUATOR
4012373-914	SM710	OH	3	ACTUATOR

4012373-915	SM710	OH	3	ACTUATOR
4012373-916	SM710	OH	3	ACTUATOR
4012373-917	SM710	OH	3	ACTUATOR
4012373-918	SM710	OH	3	ACTUATOR
4012373-919	SM710	OH	3	ACTUATOR
4012373-920	SM710	OH	3	ACTUATOR
4012455-2		FN	1	DC MOTOR BRUSH RING
4012565-1		FN	2	COND ASSY
4013013-907	VS200	SV	3	VER AIRSPEED
4013241-903		OH	1	AIR DATA COMPUTER
4013241-937	AZ-241	SV	1	AIRDATA COMPUTER
4013242-708	AZ-242	SV	1	AIRDATA COMPUTER
4013242-726	AZ-242	SV	1	AIRDATA COMPUTER
401-40-2		SV	1	AIRSPEED SWITCH
4018285-901	AL-205	SV	1	ALTITUDE ALERT CONTROLLER
4018368-901	MS500	SV	1	MODE SELECTOR
4018368-913	MS500	SV	1	MODE SELECTOR
4020501-594	GH14	OH	1	GYRO HORIZON
4020550-904	AD300H	OH	1	ATTITUDE DIRECTOR INDICATOR
4021541-191	GH14B	OH	1	GYRO HORIZON
4021541-331	GH14	OH	1	GYRO
4021541-391	GH14	OH	2	GYRO HORIZON IND
4021541-560	GH14	OH	1	GYRO HORIZON IND
4021541-590	GH14	OH	1	GYRO HORIZON IND
4021541-671	GH14	OH	2	GYRO HORIZON IND
4021541-671		NE	1	GYRO HORIZON
4021541-671NVG	GH14	OH	2	GYRO HORIZON IND
4021541-791	GH14	OH	1	GYRO HORIZON IND
402-2301		NS	1	SPDT 1GHTZ COAX RELAY
4023400-0503	RT-859A/APX-72	SV	1	TRANSPONDER
4023400-0506	RT-859A/APX-72	SV	1	TRANSPONDER
4025008-910	SP711	SV	2	HELIPILOT COMPUTER
4025008-911	SP711	SV	2	HELIPILOT COMPUTER
4025008-915	SP711	SV	2	HELIPILOT COMPUTER
4026206-902	RI-206	SV	1	INST REMOTE CONTROLLER
4026206-972	RI-206	OH	1	INST REMOTE CONTROLLER
4027395-023		NS	1	PANEL
402-90-1		OH	1	PRESSURE SWITCH
4029377-907		FN	1	SP600 Autopilot Computer
4029377-912	SP600	AR	1	AUTOPILOT COMPUTER
403001-005	153-017310-01	SV	1	HPA/LNA
403001-006		SV	3	HPA LNA GPS PRE AMP
4030182-901	AC702	OH	1	ALTITUDE SENSOR
40-41320-1010		NE	3	DIAPHRAGM ASSY,ALTI

404-38-X018		SV	1	MOUNTING TRAY
404-910-1	5841-041-0540	SV	1	RT-833AV1/APN-175V
404-910-1	RT-833AV1/APN-175V	SV	1	RECEIVER TRANSMITTER
404A-25-S-D/DPXB-0		SV	2	TRAY
404A-38-S-1/DPXB/C-0		SV	2	TRAY
404A-50-X003		SV	1	MOUNTING TRAY
405001A-PMA		FN	1	Satcom IGA Antenna
405010A	AERO-I	SV	2	SATCOM HPA
405012A	AERO-I	SV	1	SATCOM DLNA
405016A		FN	2	TT-5016A High Power Amplifier
405033A-01	AERO-I	SV	1	SATCOM SDU CONFIG MOD
405033A-UAT-NRS	AERO-I	SV	1	SATCOM SDU
405622A-UAB		SV	1	SATCOM CRADLE
405624B-THR		FN	6	AVIATOR Wireless Handset Black
405AD		SV	1	AC ADAPTER
4-063-020-17		OH	1	INLET HOUSE
4-063-020-17		AR	1	INLET HOUSE
4-063-140-02		NE	2	PANEL ASSY
4066010-910		SV	1	TCAS II COMPUTER
407-240-018-101		SV	1	DRIVESHAFT TOOL SPAN
407-375-001-105	90090001-02	OH	1	MGT INDICATOR
407-375-008-101	DL439	OH	1	DUAL TACHOMETER INDICATOR
4-081-080-11		SV	1	FUEL PUMP DRIVE
4088622-2		NS	3	CONNECTOR
4088622-3		NS	7	INSULATR
4088622-4		NS	2	CONNECTOR
4092745-901	XMDPRT-02	SV	2	XMWX DATA PORT
40T15K		NE	1	PUSH BUTTON ASSY
4-101-060-13		SV	1	SHROUD ASSY
41102010-01		SV	1	ACTUATOR
41-104082-01		SV	1	RELAY UNIT
412-075-008-111	9813-25-21	OH	2	DUAL TORQUE IND
412-075-008-113	DT410-2	OH	2	DUAL TORQUE IND
412-075-010-111		SV	1	TRIPLE TACH
412-075-205-101	18-1842-7	OH	2	PRESSURE TORQUE TRANSDUCER
412-075-706-107	292-412-706-107	NS	2	PANEL
412-075-710-101	67564-101	NS	2	PANEL
412-075-711-101	97499/412-075-711-101	NS	2	PANEL
41222-100-009-001	100-009-001	SV	1	CVR
412-375-702-101	292-412-702-101	NS	2	PANEL
412-375-703-101	292-412-703-101	NS	2	PANEL
412-375-704-101	292-412-704-101	NS	2	PANEL
412-375-711-103	292-412-711-103	NS	1	PANEL
412-375-712-103	292-412-712-103	NS	2	PANEL

412-375-713-101	292-412-713-101	NS	2	PANEL
412-375-714-101	292-412-714-101	NS	2	PANEL
412-832-151		NS	2	SEARCHLIGHT CONTROL PANEL
4-141-010-24		SV	1	HOUSING
4-141-026-05		NS	1	SPACER
414-180615-3		NS	1	LENS RH WING
4-143-020-07		SV	1	HOUSING
4-143-020-07		NE	2	COMBUSTOR HOUSING
416-00293-010		SV	1	P/R SAS COMPUTER
416-00293-100		SV	1	P/R SAS RECHNER
416-00293-120		SV	1	SAS2000 COMPUTER
416-00297-302		SV	2	PA 4-AXES DUPLEX SAR
416-00297-310		SV	1	AUTO PILOT MODULE
416-00298-100		SV	2	APMS2100 EFIS
4-161-417-02		NS	2	REDUCER
418-00275-003	1560SA0572907	SV	3	BAROMODULE, AP AIR DATA CONTRO
418-00302-000	704A47-1350-08	SV	1	ELECTRIC ACTUATOR
418-00475-600		SV	1	SYSTEM UNIT AIR DATA
418-00487-700		SV	1	AUTOPILOT MODULE
418-00529-102		SV	1	TRIM ACTUATOR
418-00579-800		SV	1	AUTOPILOT COMPUTER
418-00625-114	704A47135033	SV	1	ACTUATOR,ROLL
418-00625-174		SV	1	ACTUATOR
418-00847-100		SV	1	SEMA 8399
418-00870-101		SV	1	AUTOPILOT SERVO
418-00874-001	704A47-1320-58	SV	3	ACTUATOR,PITCH TRIM
418-00876-250		SV	1	SMART ACTUATOR
418-00876-800		SV	2	ACTUATOR
418-00876-800		AR	5	ACTUATOR
418-00881-000		SV	1	DUPLEX TRIM PARALLEL ACTUATOR
418-01141	212-061-010-001	SV	1	TRANSMITTER, OIL PRESS
418-02461-001		SV	1	ACTUATOR
418-09084	45AS86825-005	OH	1	OIL PRESSURE TRANSMITTER
4184NX		NE	1	FAN
41850A14-4580		SV	2	LANDING LIGHT
41850A17-4580		SV	1	LANDING LIGHT
419-00320-561	704A47-1332-05	SV	1	COUPLER, CDV 85
419-00320-660		SV	1	CDV AUTOPILOT COUPLE
419-00320-660		AR	1	CDV AUTOPILOT COUPLE
419-18		NS	1	SWITCH
41950-0000		SV	1	RECEIVER ACCESSORY
4200-005-2		NE	1	CIRCUIT BREAKER
420-00332-411		SV	2	AHRU APIRS F201
420-00332-460	261500123-0460	SV	2	AHRU

420-00339-000		NE	2	MAGNETOMETER
422-18152-933	18152-933	SV	1	STATIC CORR
422-23080-027	23080-027	AR	1	LEAR 35A/36A STATIC DIFF COR
422559-2WH	336695-802WH	AR	2	MAGNASTAR PHONE
422650-801	1HGD9REVB	SV	1	CABLE
42325-371		NE	3	MOTOR FAN ASSY
42325-389		NE	2	FAN MOTOR
4254A010-100		NE	8	SWITCH DIFFERENTIAL PR
426-1-13		SV	1	GALLEY SWITCH PANEL
42701-1	42701-01	SV	4	MOUNT
4271-606		NS	1	CONNECTOR
4271-613		NS	3	SWITCH MATRIX
427-375-001-103	160M020	SV	1	IIDS DISPLAY
42960-00	704A47612052	SV	1	INDICATOR,TACHOMETER
42HP601-19		NS	6	PANEL
42HP605-1		NS	1	PANEL
42HP911-1		NS	5	PANEL
42HP920-7		NS	4	PLATE
42HP926-1		NS	4	RING
42HP928-1		NS	1	PANEL
4300-20000-00		FN	1	DCU
430-040-080-101		OH	1	LOWER MAST BEARING CASE
4300-8170-1L	222-375-033-101	SV	2	ATTITUDE GYRO
4-301-099-10		OH	1	T1 SENSOR 650B1
4-301-099-10		AR	1	T1 SENSOR 650B1
4-301-128-04 C	4-301-128-04	NE	1	FUEL PUMP
4-301-483-01		OH	1	CONTROLLER
4-301-483-01		AR	1	CONTROLLER
4-301-687-01	6860501E1	OH	1	FUEL MANIFOLD
430-215-100-101		SV	1	GAUGE, TRIM TAB BEND
43025-0400		NS	20	RECEPTACLE
430-360-055-101		SV	1	SOLENOID MECH
4305-7150L		SV	1	DIRECTIONAL GYRO
4305-8175-1L	222-375-034-101	SV	2	ATTITUDE GYRO
430-6090-600	GSL71	SV	1	UAT CONTROL PANEL
4308-05000-20-101		NE	1	FAERITO AVIONICS RECORDER
4308-15003-23-101		NE	1	RIGHT HAND CAMERA
4344-2020	206-075-706-3	OH	1	OIL PRESSURE IND
4351-1203		SV	1	TORQUE METER
43622-02-03-01		SV	1	ROLL ROD ASSY
437-1-4		SV	1	CONTROLLER: GALLEY CALL
438-00100-021		NE	2	PITCH YAW GYROMETER
438-00100-021		SV	1	PITCH YAW GYROMETER
4-381-128-10		SV	1	FUEL PUMP

442042-1		SV	1	FUEL CONTROL APU
44301-406		NE	1	FLOAT ASSEMBLY
44301-700		SV	1	FUNCTION BOX
44311-721		SV	1	PENDANT CONTROLLER, HOIST
44410-2-245		SV	1	ROTATING
444-DMC57-1	CD-571	SV	1	ANTENNA, UHF, BLADE
4484-100-020		SV	1	MASTER CAUTION PANEL
449-2	212-075-962-1	SV	1	POWER SUPPLY
45-0019-7		OH	1	LANDING LIGHT
450-1000-200		SV	1	CAMERA POD FLIR 4000, ULTRA
450120-H		NS	16	SEAL PLAIN ENCASED
45-0182-1	76550-02005-101	OH	1	SEARCHLIGHT
45-0182-3	76550-02005-102	OH	1	SEARCHLIGHT
45-0182-5	76550-02005-103	OH	1	SEARCHLIGHT
45-0182-7	76550-02005-104	OH	1	SEARCHLIGHT
45-0182-7M		OH	1	SEARCHLIGHT
45-0253-11		OH	1	LAND LIGHT RETRACT
45-0300-1		SV	1	NVG SEARCHLIGHT, CONTROL, F3
45-0300-1		SV	3	SEARCH LIGHT
45-0339-11		SV	1	SEARCH LIGHT
45-0350-3-2		AR	1	LANDING LIGHT
45-0350-3-2		SV	1	LANDING LIGHT
452-0111		SV	1	ANTENNA
452100-02		SV	3	MODE SELECTOR UNIT
453-0150-01	ELT100HM	SV	2	ELT
453-6603		SV	1	ELT
4545-00-5	209-072-433-101	SV	1	VALVE
454640-01	LTN72	SV	1	CONTROL DISPLAY UNIT
454C01		NE	6	DRAIN VALVE
455-0407		SV	1	ELT
455-5001(999)	455-5001	NE	1	EMERGENCY TRANSM C406-2H
455-6196		NE	16	INSTALL KIT W/NAV REMOTE SWITCH
455-6500		NE	4	ELT/NAV INTERFACE
45900-1		SV	1	ANTI-COLL-BEACON
45AS88856-3		SV	1	CONTROL BOX
46035-31		NE	1	BRACKET ASSY
46036-8		SV	1	BRACKET
46060-10	706-10	OH	2	GYRO DISPLACEMENT
46060-11	706-11	OH	2	GYRO DISPLACEMENT
4632AA	704A49430049	SV	1	BOX, DETECTOR VIBRATION ANALYSIS
46700-1	704A47111037	SV	1	IND-W SETTER, VERT- SPEED FT/MN
46D36		NE	1	VENTIL
47-00000-9		SV	1	CHADWICK CONTROL
47-120-142-1		NS	4	SEAL

47360-1100		SV	1	TRANSCEIVER
47-620-200-12T210		SV	1	PLUG TOOL
47-620-617-007	2802-070-8060-80080	NS	80	PLATE
47-644-213-003		NS	3	BEARING HOUSING
481-301-104	76450-00706-104	OH	2	T5 INDICATOR
481-401-103	76450-00706-103	OH	1	DUAL TORQUE IND
481-501-104	76450-00706-102	OH	1	TRIPLE TACH INDICATOR
482-5086-010	6695-00-438-3977	NE	10	METER MOVEMENT
483GC01Y032	704A46570104	SV	1	MASTER,ELECTRICAL,RT
48707-002	527-48707-002	OH	1	SERVO ALTIMETER
48770017-01		SV	1	NAV SENSOR UNIT
488-3305-001		SV	1	CONTROL
492-1-50		SV	1	UNIVERSAL SPC
492GC01Y021	704A46570068	SV	1	ELECTRICAL MASTER BOX,LH
494-116-001-694		SV	3	HEADSET, MIC
4A16.32.60F.28.4.CE		NE	8	VERTICAL SPEED INDICATOR
4A2000-1B		SV	1	FREQ CONVERTER
4AA-010-105-103		NE	4	STUD
4D1000-B604-1659		SV	2	CONVERTER FREQ GALLEY PWR
50-0002-01	50-000X-XX	SV	1	CDI-500 COURSE DEV IND
500185-5		SV	1	AEROROUTER 700
500-21	C668520-0101	OH	1	OAT INDICATOR
500-23164-101		NE	1	KIT, HSD-400 RF COAX
500-280		SV	1	3 PHASE AC
500-30577-17		NE	1	HPA TO ANT COAX
500-30577-18		NE	1	HPA TO ANT COAX
5006-1036		OH	1	TOT-INDICATOR
5006-1039		NE	1	EXHAUST TEMP. INDICATOR
500-83007-01	311501	NS	1	COAX CABLE ASSY
500-83007-02	311501	NS	1	COAX CABLE ASSY
500-83007-03	311501	NS	1	COAX CABLE ASSY
500-83007-04	311501	NS	1	COAX CABLE ASSY
5008512-002		SV	1	DATA BUS COUPLER
500N5433		NS	1	SEAL
50-1-053		SV	3	NO SMOKING PANEL
501-1038-01	AC111D	SV	1	FLT CONTROL
501-1121-01		SV	1	VG208A Vertical Gyro
501-1121-01		OH	1	VG208A Vertical Gyro
501-1121-01		AR	2	VG208A Vertical Gyro
501-1142-03	AD102A	SV	1	AIR DATA SENSOR
501-1142-04	AD102B	SV	1	AIR DATA SENSOR
501-1170-21		OH	1	ATTITUDE GYRO
501-1170-23	AI-904U/HA/B	OH	1	ATTITUDE GYRO
501-1170-27		OH	1	ATTITUDE GYRO

501-1170-40		OH	1	ATTITUDE GYRO
501-1185-01	FN100A	SV	1	RFI FILTER NETWORK
501-1197-29	AI-804CE	OH	1	ATTITUDE INDICATOR
501-1207-08	DC-2001H	SV	1	DIGITAL NAV COMPUTER
501-1210-01	VG208C	OH	1	VERTICAL GYRO
501-1224-02	76600-02113-102	OH	1	VERT GYRO
501-1240-01	SI-100A	SV	2	STATIC INVERTER
501-1453-01	76600-02113-103	OH	4	VERTICAL GYRO
501-1475-01		FN	1	PS-855A S.I. 115V
501-1568-17	AI330	OH	2	ATTITUDE INDICATOR
501-1845-01	AI-803CY	NE	3	HORIZON INDICATOR
501-1845-01	AI-803CY	OH	2	HORIZON INDICATOR
501580-401		AR	1	SEAT BELT
5018-753-00-00		SV	1	AUDIO AMP
502-1-50		SV	1	VIDEO SPC WITH ALAN I
502A15		SV	1	POWER ADAPTER UNIT
502-DP1-ST5	2102-070-1060-10010	NS	10	SPRING CLAMPS
503067-405-2255		NS	1	SEAT BELT
503067-407-4185		NS	3	SEAT BELT
503068-409-2862		SV	2	BELT ASSY
503-19-3		SV	1	G-SWITCH
503-22		NE	1	COCKPIT CONTROL PANEL
5035P2-P26P.100	5035P2-P26	OH	1	ENCODING ALTIMETER
50-380034-3	515-3	SV	1	TACHOMETER IND
50-384081-21	B326-1	OH	1	ENGINE GAGE
50-389091	22-280-026-1A	SV	1	TACH SYCHRO INDICATOR
504-0017-901	510-1A	OH	1	ATTITUDE GYRO
504-0017-901	510-1A15	OH	1	ARTIFICAL HORIZON
504-0017-908	510-1B	OH	1	ATTITUDE GYRO
504-0017-917	5108C	OH	1	ATTITUDE GYRO
504-0017-933		OH	2	ATTIT.GYRO (510-1P-15)
504-0035-905	520-2A	OH	1	GYRO
504-0045-902	510-35B	OH	1	ATT GYRO
504-0110-905	1100-14S(11)	OH	1	HORIZON GYRO
504-0111-902	1100-28(11)	OH	2	HORIZON GYRO
504-0111-903	1100-28L(20B)	OH	2	HORIZON GYRO
504-0111-904	1100-28(0)	OH	2	HORIZON GYRO
504-0111-905	1100-28L(0F)	OH	2	HORIZON GYRO
504-0111-906	1100-28(0)CES	OH	1	HORIZON GYRO
504-0111-907	1100-28LS(8F)	OH	2	HORIZON GYRO
504-0111-908	1100-28(5)	OH	2	HORIZON GYRO
504-0111-909	1100-28(8)	OH	2	HORIZON GYRO
504-0111-910	1100-28(12)	OH	2	HORIZON GYRO
504-0111-911	1100-28(14)	OH	2	HORIZON GYRO

504-0111-912	1100-28L(5F)	OH	2	HORIZON GYRO
504-0111-913	1100-28L(7F)	OH	2	HORIZON GYRO
504-0111-914	1100-28L(8F)	OH	2	HORIZON GYRO
504-0111-915	1100-28L(12F)	OH	2	HORIZON GYRO
504-0111-916	1100-28L(14F)	OH	2	HORIZON GYRO
504-0111-917	1100-28LS(0F)	OH	2	HORIZON GYRO
504-0111-918	1100-28LS(5F)	OH	2	HORIZON GYRO
504-0111-919	1100-28LS(12F)	OH	2	HORIZON GYRO
504-0111-920	1100-28LS(14F)	OH	2	HORIZON GYRO
504-0111-928	1100-28LS(7F)	OH	1	HORIZON GYRO
504-0111-929	1100-28L(15F)	OH	2	HORIZON GYRO
504-0111-930	1100-28LS(15F)	OH	1	HORIZON GYRO
504-0111-931	1100-28L(11F)	OH	2	HORIZON GYRO
504-0111-932	1100-28LS(11F)	OH	1	HORIZON GYRO
504-0111-933	1100-28L(15B)	OH	1	HORIZON GYRO
504-0111-934	1100-28L(10F)	OH	1	HORIZON GYRO
504-0111-935	1100-28LS(16F)	OH	1	HORIZON GYRO
504-0111-937	1100-28L(6F)	OH	1	HORIZON GYRO
504-0111-940	1100-28L(4F)	OH	1	HORIZON GYRO
504-0111-942	1100-28LS(14E)	OH	1	HORIZON GYRO
504-0111-943	1100-28LS(11B)	OH	1	HORIZON GYRO
504-0111-944	1100-28K(10)	OH	1	HORIZON GYRO
504-0122-902	1200-2RS(15D)	OH	2	AH3 HELI 28V FRONT W
504339-211-1028		NE	1	LAP BELT ASSY
505-0002-904	200DC(28)	OH	1	DIRECTIONAL GYRO
505-0002-917		OH	1	DIRECTIONAL GYRO
505-0010-902	200DCL	OH	1	DIRECTIONAL GYRO
505-0031-904		NE	1	DIRECTIONAL GYRO
50691-7	222-375-062-107	SV	2	MAST TORQUE SIGNAL CONDITIONER
50691-9	222-375-062-109	SV	1	MAST TORQUE SIGNAL CONDITIONER
507-220-101	2102-070-1060-10010	NS	10	CIRCUIT BREAKER SWITCH
5083-100		NE	1	RADOME ASSY
50C-0024-10		OH	1	INDICATOR
50C-0024-10		AR	2	INDICATOR
50C-0024-12		OH	2	INDICATOR
50C-0024-12		AR	2	INDICATOR
51008-0065		NE	4	IC
5110-1050-00		SV	1	BEVERAGE MAKER
513-18352-10	18352-10	SV	1	SDC MODULE
51522-000	222-375-060-103	SV	1	REGULATOR/CONTROLLER
51522-002	222-375-060-109	SV	1	REGULATOR/CONTROLLER
51530-006A	76550-09006-105	SV	1	D-C- GENERATOR CONTROL UNIT
51538-005A		NE	1	DC GENERATOR CONTROL UNIT
51538-005A		SV	2	DC GENERATOR CONTROL UNIT

51565-000R		SV	4	VOLTAGE REGULATOR
518-16007-161	16007-161	OH	1	ALTIMETER
518-16007-334	16007-334	SV	1	ENCODING ALTIMETER
51824-1	2602-070-6060-60060	NS	60	GREEN THERMASHIELD
5201-1		SV	1	ATC CONTROL PANEL
520-3150-003	HSI-315A	SV	1	STANDBY H.S.I.
520-3337-207	3337LB21C	SV	1	RADIO MAGNETIC INDICATOR
520-4150-007	HSI-415A	SV	1	STANDBY H-S-I-
520-7137-014		OH	1	RMI
520-8014-001	RVG-801E	NE	2	VERTICAL GYRO
520-9100-101		OH	1	DIRECTIONAL GYRO REMOTE
522-0240-003	350X-1	SV	6	RACK
522-0700-023	37P-5	SV	1	GLIDE SLOPE ANTENNA
522-1658-000		SV	1	MOUNTING TRAY
522-1660-000	618T3	SV	1	HF TRANSCEIVER
522-2357-019	614L8	SV	1	ADF CTL
522-2447-560		SV	1	NAV CONTROLLER
522-2449-000		SV	1	VHF CONTROLLER
522-2644-00		OH	1	SLAVING ACCESSORY UNIT
522-2644-011		OH	1	SLAVING ACCESSORY UNIT
522-2788-015		SV	1	MONITOR, COMPARATOR WARN
522-3443-000	490T1	SV	1	ANTENNA COUPLER
522-3616-204	313N4D	SV	1	CONTROL UNIT , NAV
522-3617-003		SV	1	CONTROL UNIT , VHF
522-3761-001	137A6A	SV	1	ADF ANTENNA
522-3918-001		SV	1	CONTROL IND
522-3918-004		SV	1	COMPARATOR MONITOR IND
522-3948-001	54W1C	SV	1	MONITOR COMPARATOR WARN
522-4114-003		OH	1	RAD ALT INDICATOR
522-4140-007	437X1	SV	1	ANTENNA
522-4853-001	5985-00-617-7123	OH	2	ANTENNA
522-4945-001	323A2G	SV	1	FLUX VALVE
5232C		SV	1	INTERFACE ADAPTOR
52347-100BCL	262-070-660-606	NS	10	NUT
52347-100BCL		NE	20	NUT
52355FBD050N	2112-070-1160-11011	NS	11	FASTENER
528401-5		SV	1	EATON RUDDER TRIM CTL
52D67M	700-3CF	OH	1	ATTITUDE GYRO
5306-155-00-10	704A37-641-008	OH	2	OIL PRESSURE IND
5306-155-00-10		OH	1	ENGINE OIL PRESSURE IND
5306-160-00-11		OH	1	MGB OIL PRESSURE IND
5306-168-00-10		OH	1	OIL PRESSURE IND
5306-255-00-11	704A37-633-008	OH	1	OIL TEMP IND
5309-155-00-11		OH	2	FUEL PRESSURE IND

53114-24ADL		NS	1	WASHER
53114-24ADL		NE	1	WASHER
53114-24ADL		NE	1	WASHER
53-1784-503-00		SV	1	PANEL
540-011-118-001	540-011-118-1	NE	1	BARREL
540-011-123-001	540-011-123-1	OH	5	PINS
540-012-125-005	3120-01-026-6942	FN	16	SLEEVE
540-012-125-007	3120-01-026-6943	FN	9	SLEEVE
540-012-125-5	3120-01-026-6942	FN	16	SPACER
540-012-125-7	3120-01-026-6943	FN	9	SPACER
540-23989-011	23989-011	OH	2	ALTITUDE SELECT
542-1037-08		NE	1	DUAL SWITCH MODULE
5448-706-91-10		OH	2	N1 INDICATOR
5448-709-91-11	117-902101	SV	1	N1 INDICATOR
5448-709-91-11	117-902101-A	SV	1	N1 INDICATOR
5448-712-91-10		OH	2	N1 INDICATOR
5485-054-K		SV	1	ACTUATOR
549-4800-000		NS	1	SWITCH
5500-01		SV	1	LED READ LIGHT
5501-04		NS	14	READING LIGHT
5501-05		NS	9	READING LIGHT
550-18013B-012	18013B-012	OH	1	VSI
550-18013B-954	18013B-954	OH	1	VSI
5506L-S		OH	2	ALTITUDE ALTERTER
5506L-SL14		OH	1	ALTITUDE ALTERTER
5506-S		OH	1	SERVOED ENCODING ALTIMETER
5506-S5		OH	1	SERVOED ENCODING ALTIMETER
5506-S5-Y		OH	1	SERVOED ENCODING ALTIMETER
5506-SG		OH	1	SERVOED ENCODING ALTIMETER
5506-SG5		OH	1	SERVOED ENCODING ALTIMETER
5506-SG5Y		OH	1	SERVOED ENCODING ALTIMETER
5506S-S-39		OH	1	SERVOED ENCODING ALTIMETER
55100-010		NE	1	YOKE FOR PULLER
55132-102	2142-070-1460-14014	NS	14	PIN
55134-202		NS	5	RECEPTACLE
55216-092-112		NS	1	CLAMP
5550-101-07	FLIGHT VISIONS	SV	2	HEADS UP DISPLAY PDU
5550-8340N5L		OH	2	2 INCH TURN AND SLIP
5550-9235N1L	222-375-072-101	SV	2	TURN & BANK IND-
5560-8165N1L	222-375-028-101	SV	2	TURN & BANK IND-
5600-S938	209-075-372-1	SV	2	RELAY, TIME DELAY
5601-036		SV	2	ROSEN MONITOR
5601-130		SV	1	ROSEN MONITOR
5601-160		SV	2	ROSEN MONITOR

56056-0101A	56056-0101	SV	1	SATCOM FAX APAPTER
5617-355-91-11	704A47-660-012	OH	1	INDICATOR, OIL TEMP & PRESS
5622103A		NE	2	IFF MOUNT MTR401
5626-555-00-11	704A47-632-038	OH	1	TEMP IND
5633-619-00-12	704A47612123	OH	1	INDICATOR DELTA NG
566-1814-04		NS	1	CLAMP MOUNTING IND
5677-752-00-12	704A47621125	OH	1	INDICATOR TORQUEMETER
5678-553-80-12		OH	2	ITT IND
5678-710-80-12		OH	1	PROPELLER SPEED IND
568A0000-01		SV	2	SOLENOID VALVE
570-24929-053		OH	1	ENCODING ALTIMETER
571-2	222-375-009-103	OH	1	DETECTOR, RPM LIMIT
5713-20-10-C2C		NE	24	STUD, TURNLOCK FASTENER
5718-A3-ACNC		NE	6	TURNLOCK FASTENER
574-1220-01		NS	1	HARNESS
574-3		SV	1	WINDSHIELD TEMP CONTROL
575-31500-436		SV	1	AIRSPEED IND-
5800-465-80-14	704A47270025	OH	1	INDICATOR 14 INFOS
5800-473-80-10	704A47270129	OH	1	INDICATOR 14 INFOS
5800-483-80-10	704A47270136	OH	2	INDICATOR MFD
5802-1006		OH	1	AIRSPEED INDICATOR
58057-12	461-00272-101	OH	3	GYRO
58057-42	461-00272-101	OH	1	DIR GYRO
5821-01-135-6056	RT-1168C/ARC164V	SV	1	RCVR/TRANS
5821-01-137-6300	RT-1168B/ARC164V	SV	1	RCVR/TRANS
582-507-11		SV	1	TCAS IND
586BK-0142		OH	1	AIRSPEED IND
58960-4088630-901	4088630-901	NS	12	CONNECTOR ASSY
5909244-4		SV	1	INDICATOR
59140-010		NS	1	PROXIMITY SENSOR
5916-46A-1-B		OH	1	INDICATOR AUTOSYN
5934A-1		OH	1	ALTIMETER
5934PAD-3		AR	1	ALTIMETER
59-52.02-41-70		NS	2	CLAW RING WASHER SET
5952-CW-6	5952-CW-6 REV C	NE	1	LUMINATOR
597-1987-003	51RV-4DF	SV	1	NAV RCVR
5A16.32.18K.28.4.DT		NE	8	AIRSPEED INDICATOR
5A16.32.30K.00.0.BK		SV	1	Airspeed Indicator
5A16-13-27K-00-0A		OH	1	AIRSPEED INDICATOR
5A58-42-45K-05-1-DH		OH	1	AIRSPEED IND
5-AS350-19		OH	1	COMPRESSOR ASSY
6004061-10		SV	1	BRAKE CONTROL SYSTEM
600-52262-1		NE	1	PLACARD
600-52262-2		NS	1	PLACARD

600-52267-6		NE	1	PLACARD
600-52267-6		NE	1	PLACARD
6007-61B-7B		OH	1	INDICATOR OIL QUANTITY
60-1431-3		SV	1	GRIMES STROBE LIGHT PWR SUPPLY
60-1592-5		SV	1	STROBE LIGHT POWER SUPPLY
60-1755-1		SV	1	STROBE LIGHT POWER SUPPLY
601A50922-11		NE	4	BEZEL
601A50923-7		SV	1	LIGHT PANEL
60225S0CN8044286		SV	1	CURSOR CONTROL DEVICE
602667-1		SV	1	POWER SUPPLY
602-7664		SV	1	HAND MIC
60-2885-1	60-2885-1REVD	SV	1	STROBE LIGHT PWR SUPPLY
60-2915-1		SV	1	FILTER ASSY
603-32-0		NS	3	TIMER
60344-103		NE	1	PUMP
60-3474-3		SV	3	POWER SUPPLY
6038T62P13	763700-13	SV	1	H-M-U-
6041H190		SV	1	RELAY 200 AMP SPST
6041H255	369A4658	NS	2	DC AIRPLANE CONTACTOR
6073-102		SV	1	MOUNTING TRAY
608-9419-003	5821-01-023-9318	OH	1	GUARD RCVR
608-9420-003	5996-01-248-0614	SV	2	AMPLIFIER,INTERMEDIATE FREQ
609-4009-001		NE	2	KNOB
6097768-200		SV	1	AIR TRANSPONDER
6103-1004		OH	1	ALTIMETER
610C-001		SV	1	ENGINE MONITOR
611-016		NE	2	AURAL WARNING GENERATOR
61148-110		OH	1	CONTROL BOX
61148-110		NE	4	CONTROL BOX
61-21-3		NE	1	BALLAST FLUORESCENT LAMP
612-1-52885-001		SV	1	BLADE TRACKER
61474-130-1		OH	1	INDICATOR,NR-NTL1-NTL2
61474-130-2	704A-47-616-023	OH	1	INDICATOR,NR-NTL1-NTL2
61476-402-1	704A47610065	OH	1	INDICATOR NR-NTL
61533-107-1		OH	2	TEMP IND
61595-0101		NE	2	KIT
616-ECU-01		SV	2	AMPLIFIER
616-ECU-01		AR	2	AMPLIFIER
617-6195-103		NS	1	RACK ASSY
617-8759-002		SV	5	RECEIVER BOARD
617-9618-001	5821-00-180-8250	SV	1	SYNTHESIZER, FREQUENCY
618-5054-002		NE	1	PLATE
618-5057-002		NE	1	PLATE
618-5078-005		NE	1	PLATE

618-5079-002		NE	1	PLATE
618-5080-001		NE	1	PLATE
620317-2REVE	620317-2	SV	3	DUPLEXER
621-0450-001		OH	3	618M3 SUBASSY
621-0451-001		OH	1	618M3 SUBASSY
621-0451-002		OH	2	618M3 SUBASSY
621-0452-001		OH	1	618M3 SUBASSY
621-0452-005		OH	2	618M3 SUBASSY
621-0453-003		OH	2	618M3 SUBASSY
622-0142-003		SV	1	SELECTOR, REMOTE
622-0171-002	339H3	OH	1	RAD ALT IND
622-0193-001	641D1	SV	2	CAPACITOR
6220-300-01	FLIGHT VISIONS	SV	1	HEADS UP DISPLAY GRID AMP
62-2040	9900BX	FN	2	XPDR COUPLER KIT
622-0629-002	913F2	SV	1	CONTROL, RADIO SET
622-0876-001	VIR30A	AR	2	NAV RCVR
622-0876-011	VIR30A	SV	5	NAV RCVR
622-0876-012	VIR30A	AR	2	NAV RCVR
622-0876-201	VIR30A	AR	1	NAV RCVR
622-0876-211	VIR30A	SV	5	NAV RCVR
622-0876-212	VIR30A	SV	1	NAV RCVR
622-0950-001		SV	1	MODE SELECTOR
622-1032-001	699Z1	SV	10	RMI ADAPTER
622-1036-001	161H1	SV	1	PROGRAMMER
622-1204-002	339H4	OH	2	RAD ALT IND
622-1204-003	339H4	OH	2	RAD ALT IND
622-1204-004	339H4	OH	2	RAD ALT IND
622-1205-001	339H4A	OH	1	RAD ALT IND
622-1205-002	339H4A	OH	1	RAD ALT IND
622-1205-003	339H4A	OH	1	RAD ALT IND
622-1205-004	339H4A	OH	1	RAD ALT IND
622-1239-201	VIR31A	SV	2	RCVR, VOR/LOC/GS/MB
622-1270-001	TDR90	AR	5	TRANSPONDER R/T
622-1334-002	VHF20B	AR	2	VHF COMM TRANSCEIVER
622-1391-003	5895-00-567-4548	SV	2	CONTROL RCVR TRANS
622-1391-004	5895-01-513-5529	OH	1	CONTROL RCVR TRANS
622-1738-002	913Y1	SV	1	MODE SELECT UNIT
622-1742-003	990C3D	SV	1	MOUNTING TRAY
622-1783-001	MT4682A	OH	2	MOUNTING BASE
622-1879-001	VHF20A	AR	8	COMM TRANSCEIVER
622-1879-002	VHF20A	AR	8	COMM TRANSCEIVER
622-1879-002	VHF20A	OH	8	COMM TRANSCEIVER
622-1945-011	339R7	SV	4	REMOTE READOUT UNIT
622-1947-011		SV	1	REMOTE READOUT UNIT

622-2041-001	MT-4915A	OH	3	MOUNTING BASE
622-2080-011	VIR351	AR	2	NAV
622-2091-000		SV	1	RCVR
622-2091-001		SV	1	RCVR
622-2093-001		SV	1	POWER CONVERTER PWC-150
622-2313-058		SV	1	FLIGHT GUIDANCE PANEL
622-2362-001	ADF60A	SV	4	ADF RCVR
622-2506-002	RMI-36	SV	1	RMI
622-2506-004	RMI36	SV	2	RMI
622-2883-001	PWR200	OH	1	HF POWER AMPLIFIER
622-2913-001		SV	1	RELAY UNIT
622-2921-001		OH	1	860E5 DME TRANSCEIVER
622-2921-001	860E5	OH	1	DME TRANSCEIVER
622-2923-004	PRE80A	AR	1	ALTITUDE ALERTER
622-2937-004	ALI55	OH	1	RAD ALT INDICATOR
622-2937-009	ALI55	OH	1	RAD ALT INDICATOR
622-2938-001	ALI55A	OH	1	RADIO ALT INDICATOR
622-2938-002	ALI55A	OH	1	RADIO ALT INDICATOR
6222M87		SV	2	ACCELEROMETER
622-3015-001	SVO80A	AR	1	PRIMARY SERVO
622-3374-002	ADI55V	OH	3	ATTITUDE DIRECTION INDICATOR
622-3670-001	TCR451	SV	1	DME
622-3915-001	IND40	SV	1	DME IND
622-3920-001	IND41B	OH	1	DME IND
622-3922-002	990C12	OH	1	HF COUPLER RACK
622-4038-001	RT-1300/ARC-186V	SV	1	RECEIVER TRANSMITTER
622-4160-015	DRI55	OH	1	RAD ALT INDICATOR
622-4298-001	HSI45	OH	3	HORIZONTAL SITUATION IND
622-4523-015	CTL20	AR	3	COMM CTL
622-4524-087	CTL30	AR	1	NAV CONTROL
622-4526-015	CTL60	SV	2	ADF CONTROL
622-4527-015	CTL90	SV	1	TRANSPONDER CONTROL
622-4730-002	FPA80	SV	3	FLIGHT PROFILE ADV
622-4782-001	VSI-80A	OH	1	INDICATOR, VERTICAL SPEED
622-4782-004	VSI80A	SV	1	INDICATOR, VERTICAL SPEED
622-4938-007	RMI30	AR	2	INDICATOR, RADIO MAG
622-5369-002	993S1	SV	2	MOUNTING BASE, ELEC EQUIPMENT
622-5462-004	728U-2	SV	1	HF R/T
622-5612-007	RTU-90	AR	1	RADIO TUNE UNIT
622-5612-036	RTU-90	SV	1	RADIO TUNE UNIT
622-5656-001	PAC200	SV	1	HF COUPLER
622-6019-001	SSS-65	SV	1	SLIP SKID SENSOR
622-6137-001	VIR32	OH	4	RCVR, VOR/LOC/GS/MB
622-6152-001	VHF22A	AR	6	TRANSCEIVER, VHF COMM

622-6152-011	VHF22A	OH	2	TRANSCEIVER, VHF COMM
622-6152-031	VHF22A	OH	2	TRANSCEIVER, VHF COMM
622-6174-001	RCP-65	SV	2	REMOTE COMPENSATION UNIT
622-6199-001	HPU74A	AR	1	H-S-I- PROCESSOR UNIT
622-6200-002	HCP-74	SV	1	H-S-I- CONTROL PANEL
622-6212-003	UMT12	NE	1	RACK
622-6321-001	RT-1250A	SV	4	ARC-182 COMM UNIT
622-6521-014	CTL32	AR	1	NAV CTL
622-6523-005	CTL92	AR	1	TRANSPONDER CONTROL
622-6557-001	TCR230	AR	2	HF TRANSCEIVER
622-6590-001	CAD62	AR	5	CONTROL ADAPTER
622-6590-002	CAD62	AR	2	ADF/TRANS ADAPTER
622-6590-002	CAD62	NE	1	ADF/TRANS ADAPTER
622-6590-002	CAD62	SV	2	CONTROL ADAPTER
622-6614-022	CTL230	AR	1	HF CONTROL
622-7139-002	PAC230	SV	1	HF PROBE COUPLER
622-7154-002		AR	2	FAN MONITOR MODULE
622-7292-101	VHF-422A	AR	1	VHF COMM TRANSCEIVER
622-7382-101	ADF462	AR	1	ADF RECEIVER
622-7667-001	DDA-42	SV	3	ADAPTER, DME DIGITAL DISTANCE
622-7695-001	CAD-870G	AR	4	TRANSPONDER CTL ADAPTER
622-7695-002	CAD-870G	AR	4	TRANSPONDER CTL ADAPTER
622-7824-001	790S11	SV	1	MOUNTING BASE, ELEC EQUIPMENT
622-8332-002	CAD31	SV	2	CONTROL ADAPTER
622-8365-003	PWR851A	SV	4	IAPS POWER SUPPLY
622-9116-014		AR	1	DISPLAY SELECT PANEL
622-9210-108	TDR94D	SV	3	TRANSPONDER
622-9301-003	RTA-852	SV	2	RECEIVER TRANSMITTER ANTENNA
622-9313-004	C-12019A	SV	4	ARC-182 CONTROL UNIT
622-9353-415		NS	1	TVI-920D ACAS Display
622-9405-001		SV	2	HF-9042 HF Coupler
622-9462-004	PRE-80C	OH	1	PRESELECTOR/ALERTER
622-9462-025	PRE-80C	SV	1	PRESELECTOR/ALERTER
622-9728-115	TVI-920D	SV	2	TCAS INDICATOR (LOOKS NEW)
622-9728-415		FN	1	TVI-920D TCAS VSI
625614-1-1		SV	1	CONTROL SENSOR TEMP
628-6492-001		SV	1	HF 230 RACK
628-6492-003		SV	1	RACK
628-8657-001		SV	1	RACK ASSY
629-7941-026		SV	1	BEECH 200 MOD FOR PN 622-3167-099
62980-2		NS	1	STRIKER
629-9503-001		SV	1	FLAT PLATE 12IN
6302-101	S0085-109	SV	1	MOUNTING TRAY
63-211378-003	890119-940	SV	2	INCLINOMETER PANEL

634-0333-001		SV	1	MOUNTING TRAY
634-1081-003		NE	1	PIGGYBACK BRACKET
634-1103-003		NE	4	ADAPTOR KIT, DUAL (UMT-12)
634-1104-003		NS	1	PIGGYBACK KIT
634-1112-001		NE	1	CONNECTOR KIT
634-1130-012		NE	1	CONNECTOR PLATE
634-1898-003		NE	4	CONNECTOR KIT
63700-025		NE	5	HEADSET
637-1981-001	637-1472-001	SV	1	HF CTL SELECTOR
637-6500-001	5821-01-077-3397	OH	1	PANEL ASSY
637R		SV	1	WHEATSTONE BRIDGE
638-6378-002	5998-01-251-6833	SV	2	CIRCUIT CARD ASSEMBLY
638-6378-003	5998-01-318-0299	OH	1	CIRCUIT CARD ASSEMBLY
638-8270-002	5998-01-100-6095	OH	2	CIRCUIT CARD ASSEMBLY
638-8273-002	5998-01-100-6089	OH	2	CIRCUIT CARD ASSEMBLY
64/55980		SV	4	SERVO ACTUATOR
6402-11001-01		AR	1	MFD-640, No DSP or AUX, Gray
6402-11001-01		SV	1	MFD-640, No DSP or AUX, Gray
6402-11011-01	MFD-640	OH	1	FLAT PANEL INTEGRATED DISPLAY
64050-228-1		SV	1	AIRSPEED INDICATOR
64142-720-1		SV	1	ALTIMETER
64210-002-1		SV	1	FUEL PRESSURE TRANSMITTER
6430-91015-102	2995-00-992-9399	SV	4	BLOWER,AIR INLET SE
64435B-103		SV	1	MOUNTING TRAY
64514-203-1	704A-37-616-003	OH	2	TACHOMETER IND
64514-208-1	704A47616009	OH	2	TACHOMETER IND
64530-068-4	704A47612044	OH	1	TACHOMETER IND
64536-500-1	704A37612012	OH	1	TACHOMETER IND, ROTOR
64538-305-1	704A47612092	OH	1	NG INDICATOR
64538-308-1		OH	1	TACHOMETER IND
64-55980		SV	1	SERVO ACTUATOR
64-55990		NE	1	SERVO ACTUATOR FAS/20/MB/11C/P
6461-1		SV	1	ADF CONTROL
646-5410-001	5998-01-251-4580	SV	1	CIRCUIT CARD ASSEMBLY
64807-605-1		OH	1	INDICATOR, OIL TEMP MGB
64809-417-1		OH	1	INDICATOR, OIL MGB
64809-421-1	704A47-641-028	OH	1	INDICATOR, HYD PRESS MAIN
64809-617-1	704A47641085	OH	1	OIL PRESS INDICATOR MGB
64838-006-1		OH	1	PRESS IND
64905-005-1	704A47-730-007	OH	1	INDICATOR, PITCH
64905-006-1	704A47-730-008	OH	1	INDICATOR, PITCH
6490-60220-012		SV	1	FIRE WARN TEST
64975-020-1	704A47-612-070	OH	1	INDICATOR, NR
6500-037		SV	4	DISPLAY

65008-D02		NE	2	CONNECTOR RAIL
65008-D04		NE	3	CONNECTOR RAIL
65009-004-513		NS	1	CONN KIT
6501-1051	105-90845	NE	2	RPM INDICATOR
6501-1056		OH	1	TACHOMETER
6502-3030	206-070-265-7	OH	1	INDICATOR, DUAL TACHOMETER
6503A-1058	704A-47-612-042	SV	1	TACHOMETER
65053-208		NS	5	CONN KIT
6505A-3061	117-902011-1	OH	1	TRIPLE TACH-
6505A-3068		SV	1	TRIPLE TACHOMETER
65-0648-1	209-075-325-011	SV	1	INDICATOR, RPM
65-0911-5		SV	1	LIGHT ANNUNCIATOR PANEL
65-0911-7		SV	1	LIGHT ANNUNCIATOR PANEL
65-10051		NS	1	LIGHT
65-1005-1		SV	1	AOA INDEXER
653-1-50		SV	1	AAU SPC
65550-04023-103	30-326E-7	SV	1	AMP, SMOKE DETECTOR
660-0001-001		SV	1	MONITOR
6600156-032	19710/2R6205B	NS	4	RUDDER TRIM ROTARY ACTUATOR
6600156-032	2R6205B	NS	1	RUDDER TRIM ROTARY ACTUATOR
6601-1004		SV	1	RATE OF CLIMB IND
6601-1004		SV	1	VERTICAL SPEED INDICATOR
6607-1-90A		NE	6	OIL PRESSURE WARNING SWITCH
66084416-7		SV	1	WARNING LIGHT CONTROL UNIT
6620-01-594-9063	9813-25-21	OH	2	DUAL TORQUE IND
66503ASSY213778		SV	1	ENGINE SYNC
66969-04		SV	1	TCAS
6700-1225-900		NE	1	REGULATOR VACUUM LIFEPORT
6700-1225-900		NE	1	REGULATOR VACUUM LIFEPORT
673529-02		NE	1	INU PLENUM
674-0004-000		NE	1	TRANSFORMER, PWR
680-6D		NE	4	FITTING HOSE 90 DEG
682-112-45-000		SV	1	NAV CONTROL
6895173-B		SV	1	FILTER
6895D1-6-5-5		SV	1	IMPACT SWITCH
6900020-000		SV	1	POWER SUPPLY
6900053-001		OH	1	POWER SUPPLY
6CL6		NS	10	TUBE
6M-40U		SV	4	DISPLAY
700-00159-001		SV	1	SATELLITE RADIO RECEIVER
7000299-901	PC702	OH	1	HELIPILOT CONTROLLER
7000299-903	PC702	OH	1	HELIPILOT CONTROLLER
7000299-907	PC702	OH	1	HELIPILOT CONTROLLER
7000300-901	AS-702	OH	1	AIRSPEED SENSOR

7000466-914	AD650H	OH	3	ADI
7000466-915	AD650H	OH	2	ADI
7000466-925	AD650H	OH	1	ADI
7000466-935	AD650H	OH	1	ADI
7000469-902	RD650A	AR	1	H-S-I-
7000469-903	RD650B	OH	1	H-S-I-
7000469-909	RD650A	OH	1	HORIZON SITUATION IND
7000605-902	MS702	OH	2	MODE SELECTOR
7000789-901	ZC301	AR	4	FLT COMP
7000836-911	AD500C	OH	1	ADI
7000836-912	AD500C	OH	1	ADI
7000839-901	RA315	OH	2	RADIO ALTIMETER INDICATOR
7000850-571	GH222	OH	2	INDICATOR, ATT DIRECTOR
7000850-771		OH	1	INDICATOR, ATT DIRECTOR
70-009H000A265A		NS	1	HOSE ASSY
7001179-966	RD550	SV	1	H.S.I.
7001182-902	AD-550A	OH	1	ATTITUDE DIRECTION IND
7001182-904	AD-550B	OH	1	ATTITUDE DIRECTION IND
7001237-6		SV	1	ANNUNCIATOR PANEL
7001305-901	AN700	OH	1	ACTUATOR POSITION IND
7001410-901	SM410	OH	2	ROD END, ACUATOR ASSY
7001410-902	SM410	OH	2	ROD END, ACUATOR ASSY
7001410-903	SM410	OH	2	ROD END, ACUATOR ASSY
7001410-904	SM410	OH	2	ROD END, ACUATOR ASSY
70-0158-1	76550-01008-101	SV	1	DIMMER CONTROL
70-0158-5		SV	1	DIMMER CONTROL
700-1710-001		SV	1	CONFIG MODULE
7001840-901		SV	1	RT-300 RAD ALT R/T
7002-060		SV	6	7IN LCD MONITOR
7002-061		SV	6	7IN LCD MONITOR
7002353-901	AZ649	OH	1	AIR DATA SENSOR
7002353-902	AZ649	OH	2	AIR DATA SENSOR
7002353-913	AZ649	OH	8	AIR DATA SENSOR
7002353-913	AZ649	NE	5	AIR DATA SENSOR
7002412-902		SV	2	AL-200 AIR DATA PRESELECT CONTROLL
7002412-904	AL300	SV	2	ALTITUDE PRESELECT CONTROLLER
7002800-801	SM725	OH	2	ACTUATOR
7002800-804	SM725	OH	2	ACTUATOR
7002800-901	SM725	OH	2	ACTUATOR
7002800-912	SM725	OH	2	ACTUATOR
7002800-914	SM725	OH	2	ACTUATOR
7002860-903	SI-225A	OH	1	MACH AIRSPEED INDICATOR
7002860-908	SI-285	OH	1	AIRSPEED IND
7003180-901		SV	1	SZ-400 STABILITY AUG COMPUTER

7003183-904		SV	2	FLIGHT COMPUTER
7003183-932	FZ-700	SV	1	FLIGHT COMPUTER
7004110-901	SM510	OH	2	CONTROL ROD ASSEMBLY
7004123-313	SC800	SV	1	SENSOR SOURCE CONTROL
7004402-978	NZ920	AR	1	NAVIGATION COMPUTER
7004402-997	NZ920	AR	1	NAVIGATION COMPUTER
7004577-902	VN801	SV	1	VNAV CTL
7005383-911	TM410	OH	1	TRIM SERVO
7005383-911	TM-410	AR	1	TRIM SERVO ASSY
700700-047		SV	1	COMPUTER
7007062-932	MC800	SV	1	MODE CONTROLLER
7007062-941	MC-800	SV	1	MFD CONTROLLER
7007689-905	IU-410	SV	1	RADAR - PARALLEL EFIS INTERFACE
7007700-201		FN	2	Radar Indicator
7007700-803		AR	1	Weather Radar Indicator
7007990-902	PC880	SV	1	TURN PITCH CONTROL
7008138-903		SV	3	DIGITAL FLIGHT CONTROL COMPUTER
7008470-822		AR	1	WU-650 RADAR R.T.A.
7008470-914		US	1	WU-650 RADAR R.T.A.
7008470-924		OH	1	WU-450 RADAR R.T.A.
7008471-7418		FN	1	Wx Controller for RDR-7000
7008471-7710		FN	1	WC-7000 RADAR CONTROLLER
7008471-7712		FN	1	WC-7000 RADAR CONTROLLER
7009289-804	MG820	SV	1	SYMBOL GENERATOR
700-D36115A-004		SV	1	MARKER CONTROL HEAD
700-D36407A-006		SV	1	COMM CTL
700-D36409A-004		SV	1	NAV CONTROL HEAD
700-D36409A-005		SV	1	NAV CONTROL HEAD
700-D36411A-004		SV	1	ADF CONTROL HEAD
700-D36411A-005		SV	1	ADF CONTROL HEAD
700-D36415A-003		SV	1	MKR PANEL
700-D36415A-004		SV	1	MKR PANEL
700Y17-1835B7		NS	1	FREQ SELECT
7011672-606	SG-605	SV	1	SYMBOL GENERATOR
7011673-661		SV	1	MFD SYMBOL GENERATOR
7011673-667	MG-605	SV	1	MFD SYMBOL GENERATOR EFIS
7012100-821	RM850	SV	1	RADIO MANAGEMENT UNIT
7012100-825		AR	4	RM-850 RMU, CRT, 8.33 kHz, TCAS
7012409-901	SM512	OH	1	PITCH ACTUATOR ASSY
7012640-901	WU870	SV	2	RADAR R.T.A.
7012640-901		AR	1	WU-870 Radar Antenna
7012693-901		SV	3	SERVO MONITOR
7012977-707		AR	1	DISPLAY CONTROL
7012977-772		AR	1	DISPLAY CONTROL

7013348-921	DA800	AR	1	DATA ACQUISITION UNIT
7013512-912		SV	1	CONTROLLER, BEACON
7014700-601		AR	2	AZ-850 MICRO AIR DATA COMPUTER
7014803-901		SV	1	RACK
7014940-801		SV	1	INSTALLATION MODULE
7016600-901	DL-900	SV	2	DATA LOADER
7016600-902	DL-900	SV	3	DATA LOADER
7016986-723	DC-550	SV	1	DISPLAY CONTROL
7018352-6		NS	1	CONNECTOR
70219-01041-044		SV	1	ABSORBER
70-2420-8TAS600	9900BX	SV	1	TRAFFIC ADVISORY SYSTEM
70-2420-8TAS620		SV	1	TCAD PROCESSOR
70250-01004-101	9059-1	SV	4	PARKING BRAKE VALVE
70251N02D04		SV	1	ALTIMETER
7025-21-258-0587		SV	2	DATA ACQUISTION UNIT
7025891-901		SV	1	PROTECTIVE DEVICE
70265N02D01		OH	1	BAROMETRIC ALTIMETER (BLACK)
7028432-1902		FN	2	Actuator I/O Proc (AIOP) Modu
7029782-1912		FN	2	MAU-12L Modular Avionics Unit 12 slot
7030-C27	7030	SV	1	VSI
7030-C29	7030	SV	1	VSI
7036333-1906		FN	2	CIO-AP2 Dual Chan Generic CIO Module
7036410-1904		NE	2	MAU ADVANCED GRAPHICS
7036410-1904		FN	4	MAU advanced grap. Module
7038231-1801		FN	4	NIC-210 Network Interface Card (NIC)
7038248-1901		FN	4	PWR-200 Power Supply Module
703A53-0000-04		SV	1	OIL TANK
704A31-211-020		NS	10	FLEXIBLE MONTING
704A34410035		NS	1	PIPE
704A35333053	5985-14-534-7649	NE	1	MOBILE ANTENNA
704A37641095		SV	1	HYD PRESSURE EMERG IND
704A37643002		SV	1	FUEL PRESSURE TRANSMITTER
704A44820006		OH	1	RELAY, BREAKING CURCUIT
704A45751263	7900100-10M10.0W10.0	SV	1	VIDEO RADAR UNIT
704A45751263	7900100-10M10.0W10.0	NE	1	VIDEO RADAR UNIT
704A46580088		SV	1	DERATING BOX
704A47310017		OH	1	SYSTEM UNIT, AIR DATA
704A47-315-011		NE	1	CONTROL UNIT, EGPWS
704A47621089		OH	1	INDICATOR, TORQUEMETER
7050A4252012		SV	1	PILOT SEAT
7050A4316017		SV	1	VEMD
705906-801	RT1168/ARC164V	OH	1	TRANSCEIVER
705906-802	RT1168/ARC164V	OH	1	TRANSCEIVER
705906-803	RT1168/ARC164V	OH	1	TRANSCEIVER

705906-804	RT1168/ARC164V	OH	1	TRANSCIEVER
706077-801	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706077-802	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706077-803	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706077-804	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706077-805	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706177-801	ARC-164	SV	6	TXR MOUNT
7064-4656	MS24178-D1	SV	2	LEACH RELAY 55 AMP
706567-801	C-10116	OH	2	CONTROL BOX, ELECTRICAL
706-786-3	704A47652008	SV	1	AMPLIFIER FUEL GAUGE
706A31213063		SV	1	ECLAIRAGE PANNEAU PLAFOND
706A37-721-001		SV	4	TRANSDUCER, GLYCOL PRESS
707074-801	RT1168B/ARC164V	SV	4	TRANSCIEVER
707074-802	RT1168B/ARC164V	SV	4	TRANSCIEVER
707074-805	RT1168B/ARC164V	SV	2	TRANSCIEVER
707074-815	RT-1168B/ARC-164V	SV	1	UHF TRANSCIEVER
707648-801	RT1505/ARC164V	SV	1	TRANSCIEVER
707648-802	RT1505/ARC164V	SV	1	TRANSCIEVER
707648-803	RT1505/ARC164V	SV	1	TRANSCIEVER
707648-804	RT1505/ARC164V	SV	1	TRANSCIEVER
709-0104-01-101		SV	1	BLADE ASSY MAIN ROTOR
709-0160-48-101		AR	1	TR BLADE ASSY
709-0160-55-101A1		NE	4	BUSHING OVERSIZE
70-907		NS	3	CONTACTOR
709149-801	5821-00-078-1342	SV	1	RCVR TRANS RADIO
70EM016100		OH	1	MODULE REDUCTION GEAR ARRIUS 2K1
70HF10		NS	8	DIODE / RECTIFIER
710696-100		SV	4	CABLE
71-2480		SV	1	TAS SYSTEM W/O DISPLAY
714042-9005		SV	3	PRINTER
7160C130		OH	2	VSI
716-686		SV	1	FUEL QTY IND
716-760-3		OH	1	INDICATOR PANEL, FUEL KG
716-760-4	704A47-653-057	OH	1	INDICATOR PANEL, FUEL
716-879	704A47-650-078	SV	1	INDICATOR, FUEL QUANTITY
7185-15	206-062-721-15	SV	1	LINEAR ACTUATOR
7200-0500-001		AR	1	ENGINE MONITOR
720-7719		SV	1	WHEEL
7217-28-01		SV	1	NR PANEL
7220-3	204-070-483-003	NE	1	AIR OUTLET
7236-1-150		NS	1	SENSOR CONTROL
724855-801	C-2000	SV	1	MAGNASTAR ARTU
724855-802	C-2000	AR	3	MAGNASTAR ARTU
724855-803	C-2000	SV	1	MAGNASTAR ARTU

724866-805WH	724866-805	SV	1	HANDSET
724866-807WH	724866-807	SV	1	HANDSET
724866-808PD	724866-808	SV	1	HANDSET
724868-802	724868	SV	1	MOUNTING TRAY
724986-801		SV	5	AIU
724986-802		NE	1	AIU
725058-801		SV	1	COCKPIT PHONE
725729-802WH	725729-802	SV	2	CONFERENCE TABLE HANDSET
725729-807BK		SV	1	HANDSET
725729-807BK	725729-807	SV	2	HANDSET WITH RETRACT CORD
725729-807WH	725729-807	SV	5	HANDSET WITH RETRACT CORD
725729-815BK	725788-802BK	SV	1	HANDSET WITH RETRACT CORD
725729-815WH		SV	3	HANDSET WITH RETRACT CORD
7260151-415		NS	5	SEAT BELT
7-26-4W		SV	1	INDICATOR
729-1201-001		NE	1	INSTL PILOT ISO BARRIER II
730152760A		SV	1	EXHAUST PIPE, EXTENDED
730152760A		SV	1	EXHAUST PIPE, EXTENDED
730152760C		SV	1	EXHAUST PIPE, EXTENDED
7315-0050-1		SV	1	ADAPTER
732-8101		SV	1	CONTROL STICK TRIGGER ASSY
73415-1460		NS	1	CONNECTOR KIT
736-3652	CU-3001-A	NS	1	MINIBOX
739CX-4-023		SV	1	AIRSPEED
741C0000-03		SV	1	ACTUATOR TAIL ROTOR
743425-801	1LZU1-743425-801	NE	1	CONNECTOR KIT
744-082-3	704A47-671-031	SV	1	INDICATOR, FLOWMETER
747-1000-001		NE	1	SUB ASSY MEDICAL MOUNT
75-0341-27		SV	1	LIGHT ASSY ANNUNCIATOR
75-0341-7		SV	1	LIGHT ASSY ANNUNCIATOR
7510100-711	RNZ850	SV	1	INTEGRATED NAV UNIT
7510100-713	RNZ-850B	SV	2	UNIT, INTEGRATED NAVIGATION
7510100-733	RNZ-850	SV	1	UNIT, INTEGRATED NAVIGATION
7510124-920	MT-851	AR	1	MOUNT ASSY
7510700-764	RCZ-833K	SV	2	COM UNIT, 25/8.33 KHZ, DIVERSITY
7510700-765	RCZ-833K	SV	2	COM UNIT, 25/8.33 KHZ, DIVERSITY
7510700-766	RCZ-833E	SV	3	INTEGRATED COMM UNIT
7510700-901	RCZ850	SV	2	INTEGRATED COMM UNIT
7510700-951	RCZ852	SV	4	MODE S DIVERSITY XPDR
7511001-915	AV850A	SV	3	AUDIO CONTROL PANEL
751-2417-001		NS	2	CABLE
751-2417-002		NS	1	CABLE
7513006-911	DI851	SV	2	DME IND
7517455-902		SV	1	MOUNTING TRAY

7517943-22		NS 200 CONTACT
7517943-9		NS 1 CONNECTOR
7519248-911		NS 4 CABLE ASSY
7519248-913		NS 4 CABLE ASSY
7519349-3		NE 1 SPLITTER, RF
75-258V2M1		SV 1 COMPUTER
75-270M2	75-270	SV 1 SFENA COMPUTER
754-0073-005	5826-01-065-9996	NE 1 PANEL LIGHTING
756-0115-300-101	MT-3317-101	NE 3 DFDAU TRAY ASSY (G200)
756-122		OH 1 ENGINE STARTER
76088-61043-050		SV 2 PILOT BEARING & HS I SWITCH
76088-61043-051		SV 2 CO-PILOT BEARING & HS I SWITCH
76089-60276-041		SV 1 FUSE BOX
761110-4	76900-01807-104	SV 1 AFCS AMPLIFIER ASSY
761111-3		SV 2 SLICE AMP
761112-3		SV 2 SLICE AMP
761240-1		SV 1 AFCS CONTROL PANEL
761272-3	76900-01804-103	OH 4 AFCS INDICATOR
761-6205-001	5930-00-911-1794	NE 1 SWITCH
761-7226-001		NS 2 SWITCH
7-627TG		SV 1 INDICATOR FEED UNIT
76378-200	KIT- 76378-200	SV 2 WINCH AGGREGATE
76378-300		AR 2 WINCH
76403-01104-041		SV 1 ADJUSTER ASSY, PEDAL
76450-00907-102		OH 1 INDICATOR
76450-01015-046		SV 1 PANEL ASSY
76450-01041-041		SV 1 HEATER CONTROL
76450-01072-109		OH 1 TORQUE IND-
76450-01076-102		OH 1 T-5 IND-
76550-01001-103		SV 1 MASTER CAUTION PANEL
76550-01001-104	843766	SV 1 MASTER CAUTION PANEL
76550-02001-063		SV 1 COCKPIT FLOODLIGHT
76550-02014-042		SV 1 PANEL
76550-09005-102	PC00401C	SV 1 TRANSFORMER
76550-09005-104		SV 1 GENERATOR CONTROL UNIT
76600-02014-046		SV 1 RELAY
76600-04162-045		NE 1 HOLD DOWN/HF ANTENNA
76650-01802-102		OH 1 VTA ACTUATOR
76650-02802-103		OH 1 CONTROL VALV
7-676-10		NS 4 HOMING ADAPTOR
768-10		SV 1 NARDA ATTENUATOR
768-128		SV 1 TRANSMITTER, FUEL GAUGER
768-129		SV 1 TRANSMITTER, FUEL GAUGER
768-20		SV 2 NARDA ATTENUATOR

76900-01803-101		OH	1	CONTROL PANEL
76900-01805-102		SV	1	SWITCH
76900-01810-103	76900-01810-103B	SV	1	PEDAL DAMPER
76900-01851-042		SV	2	VTA AMP
771523-2		SV	1	AMP SLICE
772-0738-001	680T1	SV	1	HF SLICE
772-5132-001		SV	1	MODE COUPLER
777-1029-002	714E3D	OH	1	CONTROL
777-1034-001	345A7A	SV	1	SENSOR, RATE OF TURN
777-1061-001	334C6	OH	1	PRIMARY SERVO
777-1061-001	334C6	AR	1	PRIMARY SERVO
777-1062-001	251B6	OH	1	MOUNTING SERVO
777-1062-001	251B6	AR	1	MOUNTING SERVO
7801-13000		SV	1	FUEL FLOW TRANSMITTER
780926-1	76900-01826-101	SV	1	AMPLIFIER
78200000-07	HAI-222-070-105	OH	1	INDICATOR
78200000-08	222-375-021-113	OH	1	TRIPLE TACH INDICATOR
78300000-03		OH	1	INDICATOR
78300000-09	222-375-071-107	OH	2	INDICATOR, TRIPLE TORQUEMETER
78340MK4C		SV	5	SARBE BEACON MK4C
785340-5-024	3117090-05	SV	1	CTRL UNIT ENGINE ELECTRONIC
787-6173-217	ADI-84	OH	1	FLIGHT DIRECTOR INDICATOR
787-6366-006		SV	2	CONTROL BOX, ADF
78-8051-9160-4	WX1000	AR	1	PROCESSOR
78-8051-9170-3	WX-1000	SV	1	STORMSCOPE DISPLAY
78-8051-9200-8	WX1000	SV	1	ANTENNA
78-8060-5900-9		AR	1	DISPLAY
7892740-051		AR	1	CAROSEL SIX CTL UNIT
78CF9919		OH	1	FLEXBALL CONTROL
79000660-1		SV	1	KPA900 KIT
7900100-10	7900100-10M10.0W10.0	SV	1	VIDEO RADAR UNIT
7900100-10	7900100-10M10.0W10.0	NE	1	VIDEO RADAR UNIT
792-6091-009	331A9G	OH	1	H.S.I. INDICATOR
792-6091-011	331A9G	OH	1	H.S.I. INDICATOR
792-6091-019	331A9G	OH	1	H.S.I. INDICATOR
792-6216-001	51Y7A	OH	1	ADF RCVR
792-6275-001	614L13	SV	1	ADF CONTROL
792-6275-002	614L13	SV	1	ADF CONTROL
792-6672-002		OH	1	ADC
792-6784-001	351B6A	OH	1	MOUNTING SERVO
792-6784-001	351B6A	AR	4	MOUNTING SERVO
793-20		AR	1	AUDIO CONTROL PANEL
794-165		SV	1	PROBE, FUEL GUAGE
794-166		SV	1	PROBE, FUEL GAUGE

7G304		SV	1	SWITCH
800006-1A		NE	1	RACK
800-010655-1		SV	1	PANEL
80-0093-1		SV	1	MASTER WARN PANEL
80-0093-5		SV	1	MASTER WARNING PANEL
800496-E	800496	SV	1	BATT TEMP
80-0500-33	222-375-010-149	SV	1	ANNUNCIATOR PANEL
80-0533-3		NE	1	PANEL ANNUNCIATOR
800-G-5392L	G5392L	SV	1	DUAL COMM CONTROL
800-G-5868C	G5868C	SV	1	DUAL COMM CONTROL
800J8J4AH19		SV	1	METER
80-1-026/H402A		SV	1	SWITCH PANEL
801-40011		SV	1	ENG-RPM-SENSOR
802-10-0006	HLD-7260	SV	1	SWIFT BROAD BAND DUPLEXER
802-10-0016	SDU-7310	SV	1	SWIFT BROAD BAND SDU
80265-00-0311	TNL-3100	SV	1	GPS
80265-01-0210	TNL2100	SV	1	GPS
80265-01-0234		SV	2	GPS SENSOR
802GC01		NS	1	CIRCUIT BOARD
8032-1	704A44831118	SV	1	SERVOCONTROL,MAIN ROTOR
8033-3000	ACU-810	SV	1	AMPLIFIER COUPLER
804-001		SV	3	KING AIR SWITCH PANEL
804-10-0011	5895-01-538-5542	SV	4	DIPLEXER/LNA DAU-7050
8047-20		OH	1	STANDBY ALTIMETER
805-001		SV	2	KING AIR SWITCH PANEL
80-500-1		SV	1	ANNUNCIATOR PANEL
805-10024-001		SV	1	MOUNTING TRAY
80654B5W		SV	1	HOVERMETER
80790A01		SV	1	RECEIVER DECCA MK 3
80792A03S303		SV	1	NAVIGATION COMPUTER UNIT
80792J40T090050		SV	1	COMPUTER RNAV2 S76A+
80794ES003		SV	1	CONTROL DISPLAY UNIT
80794NS301	80794	SV	1	CDU
80822-00-0235		SV	1	GPS
80822-10-0224		SV	1	GPS
8095361-2404	CC2024F	SV	1	CONTROL
8095444-4103		SV	1	NAV CONTROL CD413B
809908-3-2		SV	2	TRANSDUCER CABIN PRESSURE
8114-110-00-00	704A47-643-014	OH	1	TRANSMITTER FUEL PRESSURE
81170753-4		NS	2	CARTRIDGE
811B		SV	3	CLOCK
811B-1		OH	1	CLOCK
8125-20		SV	1	VALVE
8136-AB-08	901F	SV	1	INDICATOR TACHYMETRIQUE

8136-BA	901F	SV	1	INDICATOR TACHYMETRIQUE
81438-00-0237	TNL2101	SV	2	GPS
81438-02-240D	TNL2101	SV	2	GPS
81439-00-0237	TNL2101	SV	2	GPS
81439-02-240B	TNL2101	SV	2	GPS
81439-02-240M	TNL2101	SV	2	GPS
81439-02-240P	TNL2101	SV	2	GPS
81439-32-240M	TNL2101	SV	1	GPS
81439-32-240N	TNL2101	SV	1	GPS
81439-32-240P	TNL2101	SV	1	GPS
81439-32-241P	TNL2101	SV	1	GPS
81440-00-0229		SV	3	GPS
81440-00-0233	TNL2101	SV	1	GPS
81440-00-0233		SV	2	GPS RECEIVER
81440-00-0238	TNL2101	SV	1	GPS
81440-00-0243M	TNL2101	SV	1	GPS
81440-00-0243N	TNL2101	SV	1	GPS
81440-00-0243P	TNL2101	SV	1	GPS
81440-01-0238	TNL2101	SV	1	GPS
81440-02-0241J	TNL2101	SV	1	GPS
81440-02-0241M	TNL2101	SV	1	GPS
81440-02-0241N	TNL2101	SV	1	GPS
81440-02-0241P	TNL2101	SV	1	GPS
81440-02-0241Q	TNL2101	SV	1	GPS
81440-12-0241E		SV	1	GPS
81440-12-0241M		SV	1	RECEIVER GPS
81440-42-241J		SV	1	RECEIVER, GPS 2101/I/O APP+, NV
81440-42-241M		SV	1	RECEIVER, GPS 2101/I/O APP+, NV
81440-42-241N		SV	1	RECEIVER, GPS 2101/I/O APP+, NV
81440-42-241P		SV	1	RECEIVER, GPS 2101/I/O
81440-42-241Q		SV	1	RECEIVER, GPS 2101/I/O
81448-21		NE	1	2101 I/O INSTALL KIT
81567A04A102020		SV	1	SATELLITE DATA UNIT
817-10009-001		NE	1	KIT INSTALL L-BAND ANT 40IN
81821/20		SV	1	DIPLEXER/LNA
81821/AA	81821/ACA	SV	2	TWO AXIS STAB PLATFORM
81821/F01A001	81821CGA001	SV	1	TASP/ACU ASSY
81821B01A001004	81821B01A001	SV	1	SATCOM ANTENNA ASSY
81821G01A001004	81821G01A001	SV	2	SATCOM ANTENNA ASSY
81B		SV	1	COAXIAL RESISTOR
81F09GX10-30		NE	1	FILTER
81N2581		NS	10	SOCKET, BAYONET
8210-002-01		SV	1	PROP GOVERNOR
8210-007-01		AR	1	PROP GOVERNOR

822-1109-011	ADC3000	SV	3	AIR DATA COMPUTER
822-1-17		SV	2	COMM CONTROL
822-1349-001	SRT-2000	SV	1	SATELLITE DATA UNIT
822-1484-201		SV	2	OCM-3100 OPTIONS CONTROL MODUE
822-1484-241		SV	2	OCM 3100
822-2175-001		FN	7	CTL-22D
822-2182-107	CTL93T	SV	1	TCAS CONTROL
822-2215-302	DBU-5000	SV	1	DATA BASE UNIT AFIS
822-2576-050		NS	1	DIU-3110 Display Interface Unit
822-2576-051		FN	1	DIU-3110 Display Interface Unit
822-2576-051		SV	1	DIU-3110 Display Interface Unit
822835-5-105		SV	1	ELECTRONIC ENGINE CONTROL
822835-5-106		SV	1	ELECTRONIC ENGINE CONTROL
822835-5-107		SV	1	ELECTRONIC ENGINE CONTROL
8230B528	8230	OH	1	MAX ALLOWABLE AIRSPEED IND
82821CGA001	82821CGA	SV	1	TASP/ACU ASSY
8330450100-1		NS	1	VACUUM OUTLET
834610-00-002		SV	1	TUBE, PITOT ELEC HEATED
8350-0262-03	AHRS500GA	SV	1	AHRS
8383AU		OH	1	INDICATOR PYROMETRIQUE
84303-210DEB		NS	1	PLUG
84327-50-XXXX		FN	2	1203C GPS/SBAS RECEIVER
8-436-10		OH	1	TACH INDICATOR
843-67-6	109-0729-33-1	OH	2	INDICATOR, VERTICAL SPEED
843-67-6-R	446000275	OH	1	INDICATOR, VERTICAL SPEED
8436-BA	901F	SV	1	INDICATOR TACHYMETRIQUE
843772-149	76550-01001-149	SV	2	MASTER CAUTION/ADVISORY PANEL
8444-19477-30201		SV	1	RACK ASSY RNAV 2 MODIFIED
8502-600-1	1159SCAV408-1	SV	1	0-400 KTS MACH AIRSPEED
8502C-S20LW		OH	1	AIRSPEED INDICATOR
85-03-12369-04		NE	1	MICROPHONE
8503S20LW-MB5V-ES		OH	1	BAROMETRIC ALTIMETER
85097-02	85097	NE	1	HOBBS HOUR METER
85-41320-1340		NS	3	PRINTED CIRCUIT BOARD ASSY
8590A	HP8590A	SV	1	SPECTRUM ANALYZER
8595-03	704A47152004	OH	1	VERTICAL GYRO
85A30-C24-AA0495	74-00040-002	NS	1	RESISTOR
85AP-105		NE	1	8500C+APPLIC KIT B0105
85AP-135		NE	1	8500C+APPLIC KIT EC135
85AP-135DS		NE	3	8500C+APPLIC KIT EC135DS
85B-ECD		NE	1	8500C(+)T&B KIT, BASIC, ECD
85B-FA		NE	1	FASTRACK ASSY BASIC
85B-FA		NE	1	FASTRACK ASSY, BASIC
85B-SA		NE	1	STROBEX ASSY, BASIC

8-6137-1A		NS	4	CAM
875A0000-02		SV	4	TAIL ROTOR SERVO ACTUATOR
875A0000-02		NE	4	TAIL ROTOR SERVO ACTUATOR
87F2959		NS	100	PLUG
8800-T		SV	1	ALTITUDE SENSOR
885-2142		NS	1	TEST JACK
890114-940	3AA78/63-211397-001	AR	2	LASERCAM BRACKET
89095-0031		SV	2	COCKPIT VOICE RECORDER
8948710G001	8948710G1	SV	1	COIL
894TS05NY		SV	1	SWITCH LANDING GEAR
8A584-001	206-040-555-001	NE	1	THERMOSTAT
8DJ120WAA1	206-070-265-7	OH	1	INDICATOR, TACHOMETER
8DJ278WAD1		OH	1	INDICATOR, ROTOR SPEED
8DJ81LZE4		SV	1	TACH IND
8DJ81LZF4		SV	2	TACH IND
8DJ81WB84		SV	1	INDICATOR
8ES003417-00	704A46830026	SV	1	POWER SUPPLY UNIT, STROBE
8TW003-491-00		NE	10	PUMP
900-000-05		NE	14	RING ALUMINUM
900002-2		AR	1	TELEPHONE TRANSCEIVER
90004-00311111009	90004	SV	1	AIR DATA COMPUTER
90004-00311131000	90004	SV	1	AIR DATA COMPUTER
90004-00321111000	90004	SV	1	AIR DATA COMPUTER
90004-00321111009		SV	1	AIR DATA COMPUTER
90004-00321111009		FN	5	Air Data Computer
90004-00321111051	90004	SV	1	AIR DATA COMPUTER
90004-00342111038		SV	1	AIR DATA COMPUTER
90004-00343111061	90004	SV	1	AIR DATA COMPUTER
90004-00348111011		SV	1	AIR DATA COMPUTER
900101-806	RT-1505A/ARC164V	SV	1	UHF AIRBORNE RADIO
900101-807	RT-1505A/ARC164V	SV	1	UHF AIRBORNE RADIO
900-4345		NE	1	BRACKET, RELOC STROBE POWER
900-700-036-72		OH	1	OXYGEN REGULATOR
9007000-57001		SV	1	MST-70B ADS-B Out Xpdr
900-8171-001		NE	4	HEAD CROSS BRACE
900-8348		NE	4	BULKHEAD PLATE
9009-3004	206-075-188-001	OH	1	OIL TEMP PRESS IND
900D51508	D51508	SV	1	RECORDER, CVFDR
900E2752137-101		SV	1	PANEL
901002-11	706-11	OH	1	GYRO DISPLACEMENT
9011-100-2013	16020-3001	NE	12	RF FILTER
901-12631		SV	1	UNIT, 139 VXP,POWER SUPPLY
90153-5	222-375-025-111	OH	2	INDICATOR, DUAL AMMETER
9020-3026		SV	1	PRESSURE SWITCH

9020-3042	222-375-025-111	OH	2	DUAL AMMETER IND
902205-804		NE	1	MAGNASTAR ISDN TERM ADPT
90245A012		NS	1	THREAD REPAIR KIT
9030-1017		NE	1	PREESURE INDICATOR
9030-1017		SV	1	PRESSURE INDICATOR
9030-3046	260-2351-1	OH	1	IND-, DUAL FUEL PRESSURE
9036-3010	109-0729-27-1	SV	1	OIL/TEMP PRESSURE IND
90-380037-1		SV	1	INDICATOR CONDITIONER UNIT
903BDV5		OH	3	ARTIFICAL HORIZON
906-16789		SV	1	ACCELEROMETER,ICP W/ D38999
90F8554		NS	2	SENSOR
90G196-2		SV	1	PRESSURE SWITCH
910020-238	AIRSHOW	SV	1	AIRSHOW DIU
911010-1		NE	1	TTD CONTROLLER
911010-1		SV	1	TTD CONTROLLER
911010-2		NE	1	AIRSHOW TTD CONTROLLER
911010-2		AR	2	AIRSHOW TTD CONTROLLER
9120-1000-21		SV	1	UNIT
913210-3-1-2-2-X-2	913200AR-3-1-2-2-X-2	SV	1	ENGINE TREND MONITOR
9-138-15		SV	1	FUEL SV IND
914095-100		SV	1	AERA DISTRUBUTION BOX
917-1208-000		NE	7	CAPACITOR, VARIABLE
919C70200		NE	3	RF SWITCH
9200-18000-02		FN	1	Camera IRIS "180" degree
9203CF		SV	4	ANTENNA, DECCA
92070-55017-041		SV	1	PANEL ASSEMBLY, NO-3 RELAY
92070-55017-042		SV	4	PANEL ASSEMBLY, NO-4 RELAY
92070-55039-011		SV	1	MOD KIT, WIRING PUMP SENSOR
92101-11003-102		SV	1	BARREL ASSEMBLY, TR PITCH ROD
921012-1	TFM-138B	SV	1	VHF FM TRANSCEIVER
9222-0130-002		SV	1	ROSEN AVIATION
92382LR008-02		NE	6	OUTER SLEEVE
923V11		SV	1	HORIZON GYRO
92410-04830-106		AR	1	TRIM SERVO ROLL
92410-04830-106	DR3840M23-2	SV	1	TRIM SERVO ROLL
92550-01817-101	0230636-006	NE	1	SEARCHLIGHT
92550-02813-104		SV	1	CONTROLLER, RIPS
92602-21400-049	21400-049	NE	4	RAD ALT XMT
926125-10-1	214000-049	NE	4	RAD ALT HARNESS
9290K98		SV	5	SPRING
930121-7		NS	1	CABLE ASSY
930-500-25-1		SV	1	SEARCH LIGHT
930-500-50-1		SV	3	DUAL SEARCH LIGHT
932810-01		NE	1	BARO CONVERTER

933612-02	
933810-01	6220-01-232-7723
93921-1	13636-93921-1
93-A055-95	
93-A151-20	A151B
93-A151-30	
93-A152-70	
941063-1	TAC200
94290701-01	HAI-222-070-145
94290703-01	HAI-222-070-135
943210/943200-3	943200-3
9506-0-0	
9507-0-0	
9507-0-0-3X21310	
9507-0-0-XXXX3XX	
95-210	MODEL95-210
95-220-1G	
95-40-17-D6-56911	
95-40-18-B6-64235	
9543705-1	
95-46-11-S2-70583	
9550BN577	9550B
9599-607-12305	9599-
9599607-14169	
9599-607-14191	IND 821A
9599-607-4535	
95-XX-17-H6-50624	
95-XX-18-B6-64438	95-XX
95-XX-18-B6-64439	95-XX
95-XXX-6D1-19552	
9601-2	
9603-560-L5	
9603-560-R5	
9603-570-L5	
9603-570-R5	
9603A	704A46860001
960453-1	7515
9606-10-03-3X21910R	
9609-505-RX	
9609-505-RX	
96-10-500-50	
96-10-500-50	
96202(B)	96202
962820-1	

SV	1	SERIAL CONVERTER
SV	2	IRS/FMS ADAPTER
NE	1	MOUNTING TRAY
SV	1	AREA MIC
SV	1	CVR CONTROL
OH	1	CVR CONTROL UNIT
SV	1	CVR CONTROL
SV	1	DUAL AUDIO CONTROLLER
SV	1	INDICATOR, TOT
SV	1	INDICATOR, TACH
SV	1	KEY AND DISPLAY PANEL
NE	2	CREW SEAT 230/260
NE	3	PASSENGER SEAT
OH	1	PASSENGER SEAT LH
NE	1	PASSENGER SEAT
AR	1	NAT PANEL
NS	1	BLOWER
NS	1	INDICATOR
NS	1	SWITCH ASSY
OH	1	NOSE WHEEL ASSY
OH	1	SWITCH ASSY
OH	1	TURN AND SLIP
SV	2	RAD ALT ANTENNA
SV	1	RADIO ALTIMETER INDICATOR
SV	1	RAD ALT INDICATOR
SV	1	RADIO ALTIMETER TRANSMITER
NE	3	CIRCUIT BREAKER
NS	1	CAP ASSY
NS	1	CAP ASSY
NS	2	CAP ASSY
SV	2	SEAT BELT
NE	1	FRONT SUPPORT BAR LH
NE	1	FRONT SUPPORT BAR RH
NE	1	REAR SUPPORT BAR LH
NE	1	REAR SUPPORT BAR RH
SV	1	PANEL, FAILURE ADVISORY
SV	1	RESERVOIR ASSY HYDRAULIC 375CUIN
OH	1	PILOTSEAT HEIGHT ADJ
NE	1	REAR MEDIUM SUPPORT BAR
NE	1	REAR MEDIUM SUPPORT BAR
NS	3	FASTNER
NE	3	FASTENER
FN	2	LAP JACKET
SV	1	FUEL/AIR DATA COMPUTER

962820-2		SV	1	AIR DATA COMPUTER
962830A-1-S-8	ADC2000	SV	1	FUEL AIR DATA COMPUTER
962830AR-3-X		SV	1	FUEL/AIRDATA COMPUTER
962831A-3-S-8	ADC2000	SV	1	FUEL AIR DATA COMPUTER
963001-103		SV	3	ENCODER DIGITAL INTERFACE BOX
963405-100-015		NE	1	CABLE ASSY
964-0421-001	2940	OH	1	8300 AIR DATA SENSOR
965-0676-006	MKV	SV	1	GPWS COMPUTER
965-0686-001	MKVI	SV	2	MARK VI GPWS
965-0686-020	MKVI	SV	2	MARK VI GPWS
965-1198-005		AR	1	EGPWS
965-1227-005		AR	1	EGPWS
965-1595-020		SV	1	EGPWS PROCESSOR
96774-18-1842-7	96774-412-075-205-101	OH	3	PRESSURE TORQUE TRANSMITTER
96774-412-075-205-101	96774-18-1842-7	OH	2	PRESSURE TORQUE TRANSDUCER
9701-500-5		NE	2	HIGH SUPPORT FRAME ALU
97-3057-10		NS	1	CONNECTOR
97-389002		SV	1	TRANSMITTER TORQUE PRESS
97499-18-1842-7	97499-412-075-205-101	OH	1	TORQUE PRESSURE TRANSMITTER
97536-02	2330B	OH	1	INDICATOR
9768-03	NDN9768	SV	1	FLT PATH CTL COMPUTER
978F-1D		SV	1	INSTRUMENT TEST SET
979-0223-001		SV	1	BIAXIAL ACCELEROMETER, LINEAR
979142-1-1		NE	1	VALVE OUTLINE
980-6020-011		SV	1	SSCVR
9809-0-0		NE	2	PASSENGER SEAT
981087-1	TDFM-136	SV	1	VHF FM TRANSCEIVER
981-24C28		SV	2	NAV SWITCH RELAY
983403-1	0401907-G1	OH	1	ANTENNA
98571/843766	76550-01001-104	SV	2	MASTER CAUTION/WARNING PANEL
98571/843772	76550-01001-103	SV	1	MASTER CAUTION/ADVISORY PANEL
987-6038-001		SV	10	DATA PORT INTERFACE
990-2993-001	M7852	NE	8	AUDIO AMPLIFIER
990-3250-001	M1084PS	SV	1	AUDIO AMPLIFIER
990-3273-002	M1081PS	SV	1	AUDIO AMPLIFIER
990-3307-002	S4000-2	SV	1	PASSENGER BRIEFING SYSTEM
990-3333-069	B1045-F356-HMD3	SV	1	AUDIO CONTROL SYSTEM
990-3334-112	B1035-J290-HWZ5	SV	2	AUDIO CONTROL SYSTEM
990-3338-000		SV	1	AUDIO AMP SUMMING
990-3342-028		SV	1	PANEL, AUDIO SELECTOR
990-3392-001	M1086	SV	3	AUDIO AMP
990-3392-002	M1086H	SV	1	AUDIO AMP
990-3393-001		SV	2	M1084 AUDIO AMP
990-4063-002	LF91	NE	4	SPEAKER

990-4074-002		SV	1	AUDIO AMP
990-4099-001	VDA600	SV	1	VIDEO DISTRIBUTION AMP
990-4140-005		SV	1	DISPLAY
990-4144-001		SV	2	DISPLAY
990-4150-002	HB1500AAB	SV	1	MONITOR DISPLAY
990-4152-027		SV	2	CABIN MANAGEMENT SYSTEM
990-4300-001	AS200	SV	1	AUDIO SYSTEM
990-4500-001		SV	1	CABIN MANAGEMENT SYSTEM
990-5734-100		NE	1	XM CONTROL HEAD
990-6000-000	M4010	SV	1	DIGITAL BRIEFING SYSTEM
990-6820-001		SV	1	CABIN MANAGEMENT SYSTEM
990-9104-036		SV	1	CABIN MANAGEMENT SYSTEM
990-9104-037		SV	1	CABIN MANAGEMENT SYSTEM
990-9700-004		SV	1	CABIN LAN
990-E1900-002	1901-102H	NE	4	19IN HD MONITOR
990-G7104-004		SV	1	CABIN MANAGEMENT SYSTEM
99-230-1B1-19640	A0164	NS	1	IND- LIGHT
996-G7000-002		SV	4	C-SERIES OLED
996-G7000-224		SV	6	OLED DISPLAY
996-G7002-140		SV	1	CABIN MANAGEMENT SYSTEM
996-G7004-012		SV	1	COCKPIT SWITCH
996-G7100-004		SV	2	SWITCH PANEL
996-G7100-144		SV	1	SWITCH PANEL
996-G7101-004		SV	1	SWITCH PANEL
999-0057-27-619		NE	7	SHIM
999-0300-55-102		NE	1	ELBOW FITTING
999-1000-04-103		NE	2	SPRING HELICAL TENSION
9A2043		SV	8	HOUSING
9B-81040-15		SV	1	ANALOG INTERFACE UNIT
9B-81040-26		SV	1	ANALOG INTERFACE UNIT
9D0271-101T	CB4020V3N6-750	NS	10	RIGHT ANGLE MOUNT
A0164BC050014LT	A1077	NS	3	SCREW
A1077F	76550-00902-103	SV	1	RELAY
A119-5010-T7		NE	2	AC TUBE
A119-6014-1		NE	1	AIR BOX ASSY
A119-6018-2		NE	2	RESISTOR PLATE ASSY
A119-6020-2		NE	9	EVAPORATOR AIRCOMM
A119-8422-3		NE	1	ASSY RELAY PANEL
A121B	A1280	SV	4	ACCELEROMETER
A1280-1	A1301	NS	1	LENS
A13018-5	A15-L	SV	1	INERTIA, CVFDR
A14.3	A14.05	NS	2	SEAT BELT
A146A2209DW		NE	8	SEAL MATERIAL
A1500		NS	2	CIRCUIT BOARD

A153A2312RB		NE	10	EXTD RUBBER SILICONE
A1600		SV	1	INDICATOR, TURN & SLIP
A232A001BB		NE	2	EXTD RUBBER SYNTHETIC FOAMED
A24081-1	2995-00-992-9399	SV	3	BLOWER, AIR INLET
A2455		SV	1	SWITCH PANEL, WINDOW SHADE
A2475		SV	1	SWITCH PANEL
A24A9430-1		SV	1	WINDOW TEMP CONTROL
A2928710001	A29287	OH	2	INDICATOR SLAVE TRUE AIRSPEED
A301-61ACVR	A301C	SV	2	ICS CONTROL
A301CM222	A3374	NE	1	GAUGE
A33747	A3392	NS	1	LINER
A33925	A-35-	AR	1	HEAT SHIELD
A41322-10-003		OH	2	ALTIMETER
A413A,HAD-CF-14/28	A413A	SV	2	POWER SUPPLY
A413A,HAD-CF-14/28	HAD-CF-14/28	SV	1	POWER SUPPLY
A414371066	A4442	SV	2	MACH AIRSPEED
A4442000002		SV	2	PITOT TUBE
A490ATSCF	01-0770062-03	SV	1	POWER SUPPLY
A490ATSCF14/28	A490A	SV	3	POWER SUPPLY
A490ATSDF14/28	01-0285055-18	SV	3	POWER SUPPLY
A596A07		NE	2	JUNCTION
A691-2		SV	1	AUDIO AMP-
A6912-1	A692-	SV	1	AMPLIFIER SUMMING, HUMS
A692-1	SGB-A692-1	SV	1	AUDIO AMP-
A-700AAP	205-075-642-1	SV	1	CUTOUT RELAY GENERATOR
A-700ZC-7	205-075-642-1	SV	1	CUTOUT RELAY GENERATOR
A-700ZG		SV	1	VOLT REGULATOR
A-703G		SV	1	VOLT REGULATOR
A-772XTA		SV	1	RELAY
A81-59	5831-00-539-1471	SV	1	CONTROL PANEL
A825F	AA20-	SV	1	GENERATOR CONTRL
A864A1308E022F		NE	16	SHIM
AA20-IKC	AA31-	NS	2	P-A- CONTROL INSTALL KIT
AA31-002	AA32-	SV	1	AUDIO INTERFACE
AA31-006		SV	1	NAT AUDIO CONTROL
AA31-006		AR	1	NAT AUDIO CONTROL
AA32-001	AA34-	NE	1	AUDIO INTERFACE
AA34-001		SV	1	NAT MODULE
AA34-105		SV	1	NAT MODULE
AA34-200	AA82-	SV	3	AUDIO INTERFACE
AA3701-2		SV	3	ADF RCVR
AA82-060		SV	1	6 PLACE STEREO INTERCOM
AA83-001		SV	2	PLT/COPLT STEREO INTERFACE
AA95-210	AA95-	SV	2	AUDIO BOX

AA95-465		SV	1	AUDIO PANEL
AA95-488	AA95	SV	2	STATION BOX
AA95-745		AR	1	ICS PANEL
AA95-745		SV	3	ICS PANEL
AA95-748		SV	1	AUDIO PANEL
AA95-763		SV	1	AUDIO PANEL
AA95-781		SV	1	AUDIO PANEL
AA95-861		SV	1	AUDIO PANEL
AA95-894		SV	2	AUDIO CONTROL PANEL
AA95-894		NE	1	AUDIO CONTROL PANEL
AAC-4483A		SV	1	CONTROL BOX
AAC4616		SV	1	NAV HEAD CONTROL
AB44-12	AB5-5	SV	1	RELIEF VALVE
AB5-5	ABD21	SV	1	SEAT BELT
ABD211-01		SV	1	ANTENNA
ABD211-03		SV	1	ANTENNA
ABU-5/A	86000-1107	OH	1	CLOCK ACFT MECH
AC131	AC-16	SV	1	AIRSPED INDICATOR
AC7-13280B	AC899	SV	1	CONTROLLER
ACA103		SV	1	RPM SIGNAL TX
ACA109		SV	1	RPM SIGNAL TX
ACA-AS117-02-00		SV	1	ABSORBER ASSY
ACA-AS117-03.00		NE	1	VIBRATION ABSORBER
ACS-1278	ACU61	SV	1	AUDIO MIXER PANEL
ACS-2080	ACS-2080-300	SV	3	AIR COMM AUDIO MIXER
ACT-01-001		SV	1	AC TRANZORB ASSY
ACT-01-001		SV	1	AC TRANZORB ASSY
AD.32.32.35F.28.1.EA		FN	1	Air Data Display >CONFIG 8104<
AD1007TD1527	AD1007	NS	1	CODE GENERATOR
AD43011-01C	013-1909-010	SV	1	RAD ALT ANTENNA
ADS43010-1AC	ADS43010	NE	2	ANTENNA
AE6100E0360-180	AE702	NS	1	HOSE ASSY
AE70280084-180	AE981	NS	1	HOSE ASSY
AE705780-3		NE	1	HOSE ASSY
AE705827-2		NE	1	HOSE ASSY NG12
AE706292-4		SV	1	HOSE ASSY
AE706292-5		SV	1	HOSE ASSY
AE85692P		NE	1	FITTING FRANGIBLE
AE98148N	AFD50	NS	1	ADAPTER ASSY
AFD50-24-108SN-6094	80937363	NS	2	CONNECTOR
AFG013176		AR	1	INERTIA REEL MOUNT
AFG0391653	AI-16	SV	1	STRAP BLOCKING
AFG0424879		NE	6	INERTIA REEL MOUNT
AFG763300-02		NE	4	FUEL INDICATOR

AG34		AR	1	TACH
AHA1121M0D1-2-3-4-5		SV	2	BRAKE HAND ASSY
AI-1611-1G	AI-36	SV	1	SAT TV ANTENNA
AI-360		OH	1	ATTITUDE GYRO
AI-BSE65-01-2		SV	4	MONITOR RECEPTICLE
AI-EQ1	A1-EQ1	SV	1	AUDIO INTL MODULE
AI-LCD65-01-SWL		SV	2	MONITOR DISPLAY
AIM500E		OH	1	HORIZON REF IND
AIR-AP1220B-A-K9		SV	1	WIRELESS ACCESS POINT
AIRCOM55	AIS20	SV	1	CONTROL PANEL
AIS200-35		SV	1	REMOTE SWITCH UNIT
AIS80-1		SV	1	CDI SWITCH UNIT
AIS80-1		NE	2	CDI SWITCH UNIT
AI-STR-01A		SV	1	AUDIO INTL INTERFACE MODULE
AJ6-60		NS	4	DZUS STUD
AK-551-9M		NE	2	POWER CONVERTER
AK-950-KLN89B	AK950	SV	1	GPS/NAV SWITCHING ANNUC
AK950TNL2000-28V	AL-05	NE	9	ANNUNCIATOR
AL15-8005	AL-16	SV	1	CVR CONTROL
AL-1611-1G	1302168-001	SV	1	ORBIT TECH POSITIONER
AL-21SG	AL-215G	NS	6	FILTER
AL-2600-3	AL-26	NS	7	ANTENNA CONTROL UNIT
AL-2600-SRR	1302167-001	SV	1	ORBIT TECH S-R-R-
AL-5117		NE	1	PROTECTED POWER SUPPLY
AM1779/ARA48	5996-00-617-1676	OH	2	AMPLIFIER, ELECTRONIC CONTROL
AM-1964F/AIC	5996-00-777-0173	SV	1	AMPLIFIER, AUDIO FREQ
AM-1965B/AIC	5831-00-952-3453	NE	2	AMPLIFIER, AUDIO FREQ
AM-3209/ASN		SV	1	AMPLIFIER ELECTRONIC CONTROL
AN161-8RS	AN302	NS	1	TURNBUCKLE, FORK
AN3025-100	A-718AP	OH	3	CUTOUT RELAY, AIRCRAFT
AN310-8	AN3H4	NS	5	NUT
AN3C46A		NE	13	BOLT HEX
AN46-17A	AN4H6	NS	2	EYEBOLT
AN4-7		NE	13	BOLT
AN5544-3		SV	1	TACH GENERATOR
AN565F1032H9		NE	13	SET SCREW
AN5760L2	671CKL-010	OH	1	ALTIMETER
AN5770-1A		AR	1	MANIFOLD PRESSURE IND
AN5795-6	10499-A	OH	1	DUAL OIL TEMP INDICATOR
AN814-3DL		NE	5	PLUG BLEED
AN8516-2		SV	1	HANDLE, SPANNER WRENCH
AN913-6D	AN937	NS	6	FITTING
AN924-12D		NE	5	NUT
ANV142SZ		SV	2	VHF ANTENNA

AOA5001		NE	1	CONTROL BOX RG FUEL TANK
AP05VC-032-01		SV	2	HYDRAULIC PUMP
AP2034C	AP2034A	SV	1	TEAM
APS1979A		OH	1	AUDIO FREQ AMPLIFIER
APT-100-1000-2030SG	APT-100-1000-2030	OH	1	PRESSURE TRANSDUCER
APT-100-1000-2030SG	APT-100-1000-2030	AR	3	PRESSURE TRANSDUCER
APTE51C-70D		AR	1	TRANSDUCER
AR2010/15		SV	1	COMM 2000 SYSTEM
AR2010/25		SV	1	COMM 2000 SYSTEM
AR209-11		OH	3	FLOW RATE IND
AR-209-11		OH	3	RATE INDICATOR
AR-209-6		OH	1	RATE INDICATOR
AR-209-8		OH	3	RATE INDICATOR
AR-2E-825-30000-302		NE	1	CONNECTOR
AS21-15		AR	1	CARGO HOOK
AS2264		SV	1	DOUBLE CARGO HOOK FIX PROV
AS22-64		NE	1	DOUBLE CARGO HOOK FIXED PROV.
AS22-83		NE	1	DUAL CONTROLS CARGO HOOK
AS2284		NE	1	DOUBLE CARGO HOOK FIX
AS-2890/APR-39(V)	5985-01-026-3927	SV	2	ANTENNA, BLADE
AS3100-(31N)-09		NE	1	COMM. CONTROL (NVG)
AS3209-146		NE	4	ORING
AS5174D0606		NE	2	FITTING
ASH671-1	ASNA0	OH	2	STATIC INVERTER
ASNA0045-120BCL		NS	1	NUT
ASU-ADI-A119-1		NE	1	NVG FILTER
ASU-BK-155165-1		NE	1	NVG FILTER KX165 LEFT SIDE
ASU-BK-155165-2		NE	1	NVG FILTER KX165 RIGHT SIDE
ASU-IND-3		NE	1	NVG FILTER
AT-206-2		OH	1	FUEL QTY IND
AT-209-NL		OH	1	TOTALZR IND-
AT-209-NL-05		OH	4	TOTALZR IND-
AT-884/APX-44		SV	2	ANTENNA
AT-884/APX-44		AR	2	ANTENNA
AV16E1293	222-366-680-101	OH	1	FUEL SHUTOFF VALVE
AV17125-1		SV	1	SUPPLY VALVE
AVR8220		AR	1	DVR W PLAYBACK
AVS420-ZX-28-OCU	AVS420-ZX-28-CH	SV	1	AERIAL VIEW SYSTEMS
AW001FB1S03		NE	18	STUD ASSY
AW-5544-3		SV	1	TACHOMETER GENERATOR
B-00368-5		AR	1	ALTERNATOR CONTROL
B03C0Z		NE	1	MOD KIT
B183M2010101		SV	1	CONTROL UNIT Z
B183M2010102		NE	8	CONTROL UNIT

B18-945.22.28.4.AZ
B18-945-32-28-1AJ
B19030NA02
B19030NA04
B19030NA04
B19030NA05
B212M2049101
B212M20C1013
B212M20C1015
B234M1020881
B24000
B246K3002-109
B281K2753-051
B281K2757-051
B284K3751-051
B284M30C1002
B290P0007201
B311M3010101
B311M3038101
B31521-10-008
B327M2001102
B327M5007102
B327M5008102
B334M3006104
B344M3809102
B34610-00-002
B3550-7-307
B4515210005
B45531-10-002
B45531-10-004
B45531-10-104
B4B-D
B521M3067101
B551M0005101
B620M0001103
B621M1002053
B622M1004201
B622M1005201
B633M2008201
B671M1002101
B671M5001104
B671M5801102
B672M1805102
B711M3530101

B3550
B4553

NE 1 CLOCK(NVG)
SV 1 CLOCK
SV 1 VEMD NVG
SV 1 VEMD V2003 NVG
NE 1 VEMD V2003 NVG
SV 1 VEMD BK 117 NVG
SV 5 VENTILATION BLOWER ASSY
NE 1 BLOWER ASSY
NE 1 BLOWER ASSY
NE 1 RETROFIT SWITCH GEAR
SV 2 FUEL DUMP VALVE
NE 1 WIRED ASSY - DISTRIB BOX 1
NE 1 SUPPLY TANK
SV 2 AFT MAIN TANK
NE 4 TRANSMIT FUEL QTY SUPPLY TANK
NE 1 FUEL SENSOR SUPPLY TANK
NE 2 HOUSING
NE 1 MAIN SWITCH PANEL
NE 1 TERMINAL JUNCTION
SV 1 INDICATOR,TR.TACH.NF-NR
NE 1 SNOW SKIDS PREASSY LH-S
NE 1 SETTL.PROTEC.EFS ASSY LH-S
NE 2 SETTL.PROTEC.EFS ASSY RH-S
SV 1 ELT-UNIT L/S-LIGHT ASSY
NE 1 SUPPORT VERTICAL ASSY RDR1600
SV 2 TUBE, PITOT ELEC HEATED
NS 1 DOME LIGHT
OH 1 Encoding Altimeter
SV 2 ALTIMETER (IN/HG WITH ENC.)
SV 1 ALTIMETER (IN/HG W/O ENC)
OH 1 ALTIMETER
SV 1 INDICATOR, BANK & TURN
NE 1 ARM WELDED LH-S
NE 1 END PLATE ASSY LH
NE 1 ROTOR SYSTEM
SV 2 BLADE ARM 2
SV 1 QUADRUPLE NUT UPPER
SV 1 QUADRUPLE NUT LOWER
NE 3 HEXAGON BOLT
NE 1 SHORTING PLUG
SV 1 COLLECTIVE LEVER RH
NE 1 COLLECTIVE LEVER LH
NE 1 BELL CRANK
NE 12 COVER XMSN COWLING RH

B711M4121101		NE	1	FRONT HINGE LH
B716M1024101		NE	1	FLANGE
B7-213-001-00		SV	1	CLOCK
B851M10X2001		NE	1	LOAD ROPE AFT
B851M2012052		NE	2	INST GRAB RING F HOOK EH
B851M2085101		NE	1	GRAB RING ASSY
B851M2105101		NE	3	HOLDER CONTROL PEND.EH COMPL.
B9845-1-305	BAC08	NS	1	DOME LIGHT
BAC086-33B		SV	1	COCKPIT WINDOW
BAC086-B		SV	1	COCKPIT WINDOW
BC1-0002-022		SV	1	COMPT LIGHT
BC1-0002-023		NE	1	EXIT SIGN
BC1-0002-024		NE	1	EXIT SIGN
BC1-0002-025		NE	1	EXIT SIGN
BC147-252	BD755	NS	1	BUTTON
BD755-212	BDW-A	SV	1	RADOME
BE369	BH185	SV	2	T-I-T- INDICATOR
BH185R4B	BHL-S	SV	2	T-I-T- INDICATOR
BHL-STD1036-331	BJ197	SV	1	STAND OFF
BLSABX-SWS32CS	BP-13	NS	1	LINER BALL BEARING
BN846-03		NE	1	TE450
BP-134-3616		OH	1	AUDIO CONTROL
BP230-6		OH	1	LH FUEL PUMP
BP-600C-01		SV	1	PWR/COMM UNIT
BR398		SV	2	ANGLE POSITION IND
BR5000-517		SV	1	OUTLET PLUG
BTI-600-2A		SV	1	BATT TEMP
BTI-600-3A		SV	2	BATT TEMP IND
BWS01		NE	1	BALANCE WEIGHT SYSTEM
C0001-81103		OH	1	ALTIMETER, PRESSURE
C-10109/USC-14V	774-1320-002	AR	1	CONTROL
C1-22306	67-523-412-21	SV	3	MICRO SWITCH
C12847BB		SV	2	AVIONIC RACK
C12847BB		NE	2	AVIONIC RACK
C12847CB		NE	1	AVIONIC RACK
C12847CB		SV	3	AVIONIC RACK
C13077AA		SV	2	RACK 4 SLOTS
C145-6034-1		SV	1	AFT EVAPORATOR
C1611D-AIC		OH	3	ICS PANEL
C16287CA	704A47612135	SV	1	SIMPLE INDICATOR NR
C17591-105		NE	1	VALVE ASSY
C175F3C		SV	1	VENT BLOWER
C19209VF11		SV	1	SMD 45 H
C19243AB02		SV	1	CAD

C19243AB07		SV	1	CAD 2002
C19243AB08		NE	1	CAD V2003 DISPLAY
C19243AB08		NE	1	EC135 CAD V2003 DISPLAY
C19243AB09		SV	1	CAD SW V2005 NVG DISPLAY
C19243AB09		SV	1	CAD SW V2005 NVG DISPLAY
C19243EA02		SV	1	CAD NVG
C19243EA04		SV	4	CAUTION ADVISORY DISPLAY
C19243EB04		SV	3	CAD V2003 NVG
C19243EB05	B316M30S1001	SV	1	CAD BK117 NVG
C19252FB06		NE	1	FLIGHT CONT. DISPLAY MODULE
C19252FC07		NE	1	FCDM
C19252FC07		SV	5	FLIGHT CONTROL DISPLAY MODULE
C19252JC07		SV	4	FCDM FBL3 SHS
C19252LC07		NE	1	FCDM
C19253AA		SV	4	INSTRUMENT CONTROL PANEL
C19254AA		NE	3	RCU
C19254AA		SV	2	RCU
C19267NG10		SV	3	SMART MULTIFUNCTION DISPLAY
C19267SG10		SV	3	SMART MULTIFUNCTION DISPLAY
C19267VF11		AR	3	SMD NVG
C-2106/AIC-18	5831-809-3180	OH	1	CONTROL, INTERCOMM SET
C-2106A/AIC-18	5831-809-3180	OH	1	CONTROL, INTERCOMM SET
C-2106A/AIC-18	5831-809-3180	AR	3	CONTROL, INTERCOMM SET
C215A1930103		SV	1	BOX CONTROL, EQUIP COWLING
C-2323A/AIC	5831-00-539-1471	SV	1	PANEL, MONITOR
C24160045-2		SV	1	PUMP, HYDRAULIC, LH
C3495100045		SV	1	OVERSPEED WARNING SWITCH
C-3835/ARC-54		SV	1	CONTROL, RADIO SET
C3BE4825A01		SV	1	PANEL, WARNING
C4FP4613A05		NS	2	FALCON 50 OVERLAY PANEL
C5175Y		NS	1	INDICATOR, EMER-FUEL VALVE
C594502-0102		AR	1	FLASHER
C598501-0202	14-50-01	OH	1	ANTENNA
C622010-0101	156-0019R	SV	1	NAV STROBE POWER SUPPLY
C622010-0102	156-0019G	SV	1	NAV STROBE POWER SUPPLY
C622010-0104		AR	1	NAV STROBE POWER SUPPLY
C-6287/ARC-51BX	C632A	SV	1	CONTROL
C631A1101101		SV	1	COUPLING ASSY, FLARED
C642A0201104		SV	1	PLATE ASSY, CONTROL
C661035-0101		SV	1	VSI
C661035-0101		SV	1	VSI
C661053-0103		OH	1	DIRECTIONAL GYRO
C661056-0202	5000F10	OH	1	GYRO
C668511-0102		SV	1	ALTIMETER

C67TS/1		OH	1	IGNITION UNIT
C6SC10373		OH	1	PROP TACH IND
C-79-2KAI		NE	1	PUSH LATCH
C826A-AIC10	CA-10	SV	1	CONTROL
CA-101A		SV	4	DISPLAY UNIT
CA3100E24-28PF80		NS	4	CONNECTOR
CA3106F32-1P-F80	CA-41	NS	1	CONNECTOR
CA-412-98-94		NE	1	KIT
CA-52-1A	7000T	OH	1	VSI
CB-2100-T4	AN5766-T4	SV	1	COMPASS, MAGNETIC PILOTS
CB2100T6D	CB301	SV	2	COMPASS
CBC43W2F00JVL0		NS	5	CONNECTOR
CCU-01-001	CCU-01	SV	1	COOLING CONTROL UNIT
CDM-630		SV	1	VIDEO CONVERTER
CDP250C		SV	1	DISPLAY UNIT,ISAT
CDS-728FK	CDX-W	SV	1	VCR
CDX-757MX		SV	1	CD CHANGER
CDX-W404	CE-00	SV	15	10 DISK CD CHANGER
CE394/U	CE413	NS	1	SWITCH BOX
CE413490073		SV	1	EGPWS RELAY UNIT
CE443490003-01		SV	1	EGPWS RELAY UNIT
CES3000-2	SES-83-1018-12	SV	1	SAS CTL AND IDLE CII TEST SET
CGS962U050V4C		NS	3	CAPACITOR
CH150-14-00		SV	1	CONTROL HEAD, RADIO TETRA
CHA-S634		SV	1	CD AUTO CHANGER
CI-105-7		NS	1	DME/TRANS ANT
CI-105-9		AR	1	ANTENNA
CI-120-1		SV	1	ANTENNA
CI-121		NE	3	ANTENNA
CI-125		SV	1	VHF COMM ANT
CI-222		SV	1	AM/FM ANTENNA
CI-292-1		NE	1	ANTENNA
CI-2RR		SV	1	JENSEN MODULE
CI401-420		SV	1	ANTENNA
CI-5000-1-L	CI5000	SV	1	TRANS/RADIO TELE ANT
CI-818A	3500-137-1D	SV	1	PC BOARD
CI-884		SV	1	PC CARD
CI-9051		SV	1	PC CARD
CIA-100		SV	1	RGB AMP INTERFACE
CIX94K6-74	CL-33	NS	1	SWITCH CABLE ASSY
CL-33	209-375-096-103	SV	2	CURRENT LIMITER
CM3558-4-10G		NE	10	SCREW
CN-405/ASN		SV	1	COMPENSATOR
CNS022		NS	1	PLUG

CP-1285A		SV	6	TEAM AUDIO CONTROL
CP-1285D		SV	1	TEAM AUDIO CONTROL
CP2618DB01		SV	1	SWITCH SELECTOR,ICS45
CP-5129/AYQ-507V3	C20709-1	OH	1	DATA ACQUISITION UNIT
CPW-ELW35		NS	2	MOUNTING CLIP
CR2795B105A1		SV	1	REGULATOR
CR2795E100A1	CTA33	SV	1	VOLT REG
CR3523-5-11		NE	100	RIVET CHERRY MAX
CRN6-83-1	704A45354002	SV	1	UNIT,SWITCHING
CSIBF14501-MANT		NE	1	IBF KIT 145
CTA339B1	D091-	SV	1	DME INDICATOR TEST ADAPTOR
CTJ120E03D513		NS	2	MODULE,TERMINAL
CTJ-3D-05		NE	1	RACK,ELECTRONIC JUNCTION
CTJ420E044D513		NS	1	MODULE,TERMINAL
CTJ420E128-513		NS	1	MODULE,TERMINAL
CW0622-1010		NE	3	SHROUD A119 MD41 HTAWS
D00282-0005		NE	1	LAST SENSOR
D091-1		SV	1	REGULATOR,VOLTAGE
D0C20-06		SV	1	ANTENNA COUPLER
D107318E		NE	4	FUEL PUMP ASSY
D107318E		SV	1	FUEL PUMP ASSY
D107318E		NE	4	FUEL PUMP ASSY
D107319		SV	1	FUEL PUMP
D107611E		SV	1	SERVO MOTOR
D107611E		NE	4	SERVO MOTOR
D120-P2-T	5120-P1	SV	2	ALTITUDE DIGITIZER
D134-1463		NE	1	CARD
D134-994		NE	1	WIRING HARNESS 38VB
D136-1010		NE	1	COPILOT SEAT
D136-1013.03		NE	1	STRENGTHENING
D136-1013.04		NE	1	BAR SPLINED
D136-1014		NE	1	SEAT RAIL RH
D163-1013		NE	2	SEAT RAIL LH
D19-035	704A46211023	SV	1	VOLTAGE REGULATOR
D20516-L		SV	1	NAV ANTENNA
D20516-R		SV	1	NAV ANTENNA
D205-523-011		SV	2	HELI-RAPPEL KIT LH
D240845	D24AB	SV	1	PUMP
D240845	D240845F	NE	3	PUMP
D24AB1042	D2979	OH	1	RELAY, BREAKING CURCUIT
D3040E		SV	1	LANDING LIGHT GRIMES
D30-45		OH	1	PROPELLER
D34160-101	D5150	SV	1	FLOAT ASSY FWD LH
D350-578-017		NE	3	AS350/AS355 BEARPAWS FLAT TOP R

D38999/26WJ-20PA		NS	1	CONNECTOR,RCPT,ELECTRICAL
D4703-041		NE	2	LOCKOUT PIN
D50020-111W		NE	3	CEILING PANEL ASSY
D50020-111W		NE	3	CEILING PANEL ASSY
D50020-112W		NE	1	CEILING PANEL ASSY
D50022-121W		NE	1	ROOF SIDE PANEL RH
D50023-111W		NE	2	CEILING SIDE PANEL ASSY LH
D50026-2W		NE	1	WINDOW TRIM ASSY RH
D50026-2W		NE	1	WINDOW TRIM ASSY RH
D50027-1W		NE	1	SIDE POST COVER ASSY RH
D50042-121W		NE	1	PANEL ASSY UPPER LH
D50042-131W		NE	1	PANEL ASSY SIDE
D50043-111W		NE	1	PANEL ASSY
D50043-112W		NE	2	PANEL ASSY RH
D50043-1W		NE	1	PANEL ASSY
D50043-2W		NE	1	PANEL ASSY
D50055-111W		NE	1	JOINER PANEL UPPER CARGO
D51506	900/D51506	SV	1	CVFDR,VOICE/DATA RECORDER
D51546-011	D5161	OH	2	CVFDR
D60268MK11112	D6026	SV	2	AIR DATA SENSOR
D60268MK21121	D6026	SV	2	AIR DATA SENSOR
D60268MK21123		SV	1	AIR DATA SENSOR
D-9961-3		NS	3	COVER (RED)
D9J13-00980	80008030	SV	1	ARINC RACK
DA-24658-31		NE	4	BACKSHELL SUB-D
DAAB0786CH061	CP-1828/ARN-148	OH	1	COMPUTER, AIRSPEED
DAPSHDMI-1		SV	1	HDMI SPLITTER
DAS2100-2		NE	16	RING BACK UP
DB438	438	SV	1	AMP
DB600		SV	1	TONE GENERATOR
DBA5W5SA197F0		NS	4	CONNECTOR
DBD-01-001		SV	6	DUAL BAND DETECTOR
DBMAM25S		NS	1	CONN KIT
DC7ZX+071W		AR	1	MOTOROLA RADIO
DCR-1A-06		NE	4	CONNECTOR RAIL
DCR-1A-10		NE	1	CONNECTOR RAIL
DD44F10JVLO		NS	2	CONNECTOR
DDL-OC119A	76450-01076-105	OH	1	T5 INDICATOR
DE-24652	DF-88	NS	2	BACKSHELL
DF-88A		OH	2	DIR FINDER IND
DH7BC		SV	1	RELAY
DHS433-141-05		NS	10	NUT
DK041-1		NE	1	OIL PRESSURE PICK-OFF 14 NT
DL016-3		SV	1	RPM TRANSMITTER

DL016-3		NE	1	RPM TRANSMITTER
DL404-38		SV	1	TRIPLE RPM INDICATOR
DL404-39		SV	1	TACHOMETR
DL404-40		SV	1	TRIPLE RPM INDICATOR
DL404-40		SV	1	TACHOMETR
DL404-53	105-957201	OH	1	TRIPLE RPM INDICATOR
DL412-39		OH	1	SINGLE RPM INDICATOR
DL412-39	105-90845	NE	2	SINGLE INDICATOR
DL412-40		OH	1	SINGLE RPM INDICATOR
DL412-40	105-90845	OH	1	RPM INDICATOR
DL436-38		OH	1	TRIPLE RPM INDICATOR
DL457-021	L771M40C1005	SV	1	TRIPLE INDICATOR RRM
DLA900-85-M-SB76		NE	1	CRYSTAL FILTER UNIT
DMC63-2		SV	1	ANTENNA
DMC63-4/A	DMC70	SV	1	ANTENNA
DMC70-1A	DMELT	NE	1	ANTENNA VHF
DM-C70-1A		SV	1	ANTENNA
DMH21-1		NE	1	VOR/LOC ANTENNA COUPLER
DMH21-1		SV	2	VOR/LOC ANTENNA COUPLER
DMH24-1		SV	1	COUPLER, GLIDE ANTENNA
DMN4-17-1/N		SV	3	VOR/LOC/GS ANTENNA
DMNI-24		SV	1	ANTENNA DME TRANS
DMNI50-10-2		NS	1	ANTENNA
DMNI50-6-2		SV	10	ANTENNA
DMNI50-9		SV	1	ANTENNA
DMNI50-9		SV	1	ANTENNA
DPP4FS464	MS27644-1	NE	10	BEARING
DPX2MA-A106P-A106P-33B-0001		NS	1	CONNECTOR
DPX2MA-A106P-A106P-33B-0001		NS	1	CONNECTOR
DPXBMA57-33S-0001		NS	4	CONNECTOR
DRA45C-26		SV	4	OVERSPEED WARNING SWITCH
DSR59176-1014		NE	30	SPRING DISC
DSRM-10		NE	1	REMOTE CONTROL UNIT
DST1017-5	850568-1	SV	1	ITT IND
DT410-2	412-075-008-113	OH	1	DUAL TORQUE IND
DT501-2		SV	1	DOUBLE TORQUE INDICATOR
DT501-9		NE	1	TORQUE INDICATOR
DT-A8GA		SV	8	SPEAKER
DT-AX2		SV	14	DT SYSTEMS SPEAKER ASSY
DTE12-001		SV	1	NAT DTFM PAD
DV00514-0291-0002-03	0514AD3	SV	1	ELECTRONIC JUCTION BOX
DVD-023-01-1		SV	1	AUDIO INTERNATIONAL
DVD-024-03-1		SV	1	DVD PLAYER
DVD1270E-H01A	DVD1270E	SV	1	MULTIFORMAT DVD WRITER

DV-EL320-240	DB586	SV	1	DYNAFLIGHT SEISBAG
DVI250A		SV	1	ISAT100 CONTROL HEAD
DVI-250C		SV	1	ISAT100 CONTROL PANEL
DVP-S5301	DW5FS	SV	1	DVD/CD PLAYER
DZP_04-800W		FN	1	DZMx DZUS with Sat,4G,Wifi,BT
E00101E00010100		NE	1	TRIPLE RPM INDICATOR
E07391-10-057		OH	1	AIRSPEED IND (KNOTS)
EA124AN-124		SV	1	FUEL QTY IND
EAD01		NE	3	FIXED EXTERNAL ABSEIL DEVICE
EB2BW		SV	1	FLOATING ELT
EC135-1004-14		NE	1	FWD SLIDE RH WINDOW
ECD-AMG-11	CD402B-NVG	SV	3	CONTROL DISPLAY UNIT
ECD-AMG-17	CD671C-NVG	NE	1	CONTROL DISPLAY UNIT
ECJ504-8		NE	1	CONNECTOR
ECU76A		AR	1	CONTROL UNIT
EE4-1450		NE	1	CONE GUIDE
EMSE377-2	ES400	SV	1	POWER SUPPLY
EMU-A-010-2		SV	1	PROCESSOR ADAS
EMU-A-010-3		SV	1	PROCESSOR ADAS
EPT941		SV	1	B LINE ELT LOCATOR
ES40020-4	ES721	NS	2	NUT
ES61104-1		NE	4	MOTOR
ESB-36C/3		SV	1	AIRBORNE COMM
ESB76A/3		SV	1	CONTROL
F15-0141-1	F2MA6	NS	2	BASE RAIL
F2MA600232110B2	600232	SV	1	ELT CONTROL PANEL
F32827.5		NE	4	NEEDLE BEARING
F32828-5		NE	4	NEEDLE BEARING
F36C2S28LEAE		NS	1	FLEX LIGHT
F50-11202-501	F50-1	SV	10	PC BOARD
F50-11203-501A	F50-11510A	SV	1	PC BOARD
F50-11205-501B	F50-1	SV	8	PC BOARD
F50-11891-505-701		SV	1	P- ANNUNC- FRAME ASSY
F50-11891-505-703		SV	1	P- ANNUNC- FRAME ASSY
F50-11891-505-704		SV	1	P- ANNUNC- FRAME ASSY
F50-11894-501		SV	1	JUNCTION BOX
FD104ARM		FN	1	Display 10,4" with arm
FD104ARM-VERSION_180		NE	2	Display 10,4" 180 deg version
FD151DMT		FN	1	15" Cabin Display Mount
FD70ARM		FN	1	FD70CV-V Display w/FD70DMT
FDS81-1029		FN	7	MAU - MODULAR ACQUISITION UNIT
FE463		AR	1	PC CARD
FE897	704A47131019	SV	1	UNIT,INDICATING
FERN0-SRFW-12-2		NE	1	FERN0-TYP LITTER

FGFB600232	
FLX2645	
FLYM23800-2	
FM10-12	
FM10-12G	
FM20-66	
FM2510	
FM504	
FM504-49	
FMB10-272-1	
FN-100	
FT-25242	L281M20C1010
FV-0910	
G-1684	
G-2139	
G2581-03	
G300103	704A47720100
G-3703E	
G3849A	
G4345	
G-4433A	
G-4434	
G-4434A	
G-4436A	
G-4483-14	
G-4483B	
G-4484D	
G4501A	
G-4518	
G456	
G4649	
G-4688	
G-4710A	4710A
G-4710A	4710A
G-4745A	
G-4876A	
G-4876C	
G-5325A	
G-5515	
G-5565	
G5922-13	
G5934	
G6119A	G6136
G6136B	G6240

SV	1	ELT CONTROL PANEL
SV	1	ANTENNA
SV	1	MOTOR DIRECT MAGNET
SV	1	FLUGH MARKER BEACON
SV	1	ANTENNA, MARKER BEACON
NE	2	HYBRID COUPLER
SV	1	FURUNO FM TRANSCEIVER
OH	1	AIR SPEED INDICATOR
AR	1	AIR SPEED
SV	1	ANTENNA MARKER BEACON
NE	1	AVIONICS FAN, 11-32 VOLTS
NE	1	FUEL TANK
SV	1	CAMERA CONTROL UNIT
SV	1	ATC CONTROL PANEL
SV	1	CONTROL
SV	1	SELCAL PANEL
SV	1	ROTOR RPM WARNING
AR	1	AUDIO CONTROL PANEL
SV	2	TACAN CONTROL
AR	2	AUDIO PANEL
SV	1	ADF CONTROL
SV	1	VHF CONTROLLER
SV	1	VHF CONTROLLER
SV	1	TRANSPONDER CONTROL
SV	1	COMM CTL
OH	1	COMM CTL
SV	1	ATC CONTROL PANEL
SV	1	CONTROL
SV	1	CONTROL
SV	1	VACUUM PUMP
SV	1	COMM ATC CONTROL
SV	1	AUDIO PANEL
AR	1	LANDING LIGHT
SV	1	LANDING LIGHT
SV	1	ATC CONTROL
SV	1	ATC/NAV CONTROL
SV	1	ATC/NAV CONTROL
SV	1	COMM 1-2, NAV 1-2 CONTROL
SV	1	COCKPIT SPEAKER
SV	1	MKR / ATC CONTROL
SV	1	CONTROL
SV	1	VHF/NAV CONTROL
SV	1	ADF CONTROL
SV	1	CONTROL RACK

G6240-4		OH	1	SEARCH LIGHT
G-6250		OH	1	SEARCH LIGHT
G-6325		SV	1	AUDIO MONITOR
G-6345		OH	1	AUDIO CONTROL
G6478-001-40		SV	1	CONTROL, COMPUTER
G6644-01		SV	1	ATC CONTROL
G6644C		SV	1	CONTROL
G6861-01		SV	1	CONTROL
G6930-03		SV	1	CONTROLLER
G6944-01		SV	1	ATC CONTROL
G6969-04		SV	1	TCAS CONTROL
G6969-05		SV	1	TCAS CONTROL
G7008-64		SV	1	CONTROL
G-708-1		AR	1	INTERPHONE AMP
G7275-04		FN	2	Cursor Control Device (CCD)
G7632-108		SV	3	NAV, VHF, CTL, CTL-32G
G7740A19-24	G8385	SV	1	LOWER ROTATING BEACON
G8385-7		NE	2	LANDING LIGHT
G8385-7		OH	1	LANDING LIGHT
G993-01-1A		OH	1	RATE OF CLIMB INDICATOR
G993-01-1B		OH	1	RATE OF CLIMB INDICATOR
G9950-1		OH	1	BEACON ASSY, UPPER
GA223280002-257		SV	1	PANEL
GA341200009-01		SV	3	PANEL
GA341200009-13		SV	5	FSU 1 FSU 2 PANEL
GA341200009-23		SV	5	FSU 1 FSU 2 PANEL
GA341200010-01		SV	3	PANEL
GA343700002-67		SV	1	FMS CONTROL PANEL
GC13422-4-1		SV	1	PRINTED CIRCUIT BOARD
GC1346142		SV	1	PRINTED CIRCUIT BOARD
GC514280073-01	4280073-01	AR	1	LAN SWITCHING UNIT
GC514280075-01	4280075-01	SV	2	WIRELESS ACCESS POINT
GC514740002		SV	1	BATTERY
GC543350007-7	720-7719D	SV	5	GULFSTREAM CONTROL WHEEL
GG301ED-A2	3001EDK	OH	1	GYRO, VERTICAL
GM11953		NE	6	LINEAR TRANSDUCER
GN565-26-160SW		NE	1	HANDLE
GNS430W	010-00412-01	NE	5	GNS430W WITH INSTALL KITS
GPX428001013-301		NE	1	BRACKET ASSY
GS-15-25-GG-K50146-400N		NE	1	GAS SPRING 400N
GT-900R7441000-TD		SV	1	TOOL
GV-620-16	GV-620-16-87	SV	1	PANEL
GV-620-17	GV-620-17-87	NE	1	PANEL
H140ABM1		OH	1	HORIZON GYRO

H140ABM2		OH	1	HORIZON GYRO
H140ACM1		OH	2	HORIZON GYRO
H140ACM2		OH	2	HORIZON GYRO
H140ADM1		OH	1	HORIZON GYRO
H140ADM2		OH	1	HORIZON GYRO
H140ALM1		OH	1	HORIZON GYRO
H140AMM1		OH	1	HORIZON GYRO
H140AMM2		OH	1	HORIZON GYRO
H140ARM2		OH	1	HORIZON GYRO
H140ASM1		OH	1	HORIZON GYRO
H140ASM2		OH	1	HORIZON GYRO
H140ATM1		OH	1	HORIZON GYRO
H140ATM2		OH	1	HORIZON GYRO
H140AUM1		OH	1	HORIZON GYRO
H140AUM2		OH	1	HORIZON GYRO
H140BHM		OH	2	HORIZONT
H140BHM1		OH	2	HORIZONT
H140BHM2		NE	4	HORIZON GYRO
H140BHM2		OH	2	HORIZONT
H140BLM		OH	1	HORIZON GYRO
H140CAM		OH	2	HORIZON GYRO
H140CAM1		OH	2	HORIZON GYRO
H140CJM		OH	2	HORIZON GYRO
H140CJM1		OH	2	HORIZON GYRO
H140CLM1		OH	2	HORIZON GYRO
H140CPM		OH	1	HORIZON GYRO
H140CPM1		OH	1	HORIZON GYRO
H140CSM1		OH	1	HORIZON GYRO
H140CWM		OH	2	HORIZON GYRO
H140JAM1		OH	1	HORIZON GYRO
H140JKM1		OH	1	HORIZON GYRO
H2301-9		NE	1	LATCH
H321ABM1		OH	1	ATTITUDE INDICATOR
H321AKM1		OH	1	ATTITUDE INDICATOR
H321ALM1		OH	1	GYRO
H321ASM1		OH	1	HORIZON GYRO
H321BHM1		OH	1	HORIZON GYRO
H321CMM		OH	1	HORIZON GYRO
H321CZM	704A47150120	OH	3	HORIZON GYRO
H321EGM		OH	2	HORIZON GYRO
H600S160A434		NE	1	LOCKING MECHANISM
H930-6		SV	1	INDICATOR
HAF118	704A35333053	NE	1	MOBILE ANTENNA
HAI-222-070-150		SV	1	INDICATOR

HAI-222-070-160		SV	1	INDICATOR
HAI-222-070-170	AES-0007-SCSH	SV	1	AES
HAS902-00028-02		SV	1	TRIM ACTUATOR
HCA3		OH	1	ELECTRIC MOTOR
HD135-75-3000-1		NE	1	POCKET
HD365-15-6008-01		NS	1	BEARING
HD365-15-6053-01		NS	2	HANDLE
HD412-05-6004-01	HD412	NS	3	BRACKET
HD412-15-6039-03	HD412	NS	1	BRACKET
HD412-75-6018-10	HD900	NS	2	DOUBLER
HD900-62-3003-02	HDATD	NS	1	SUPPORT
HDATD-15-6096-21	HDS92	NS	4	BUSHING
HDSTD-04-6004-02	HDSTD	NS	1	AMP
HDSTD-15-6096-09	HDSTD	NS	2	PIN
HDSTD-15-6096-09		NE	2	PIN
HDSTD-15-6101-03		NS	2	TELESCOPING TUBE
HDSTD-98-6004-02	HDSTD	NS	2	SPRING
HDSTD-98-6004-2		NS	2	SPRING
HDSTD98-6011-02	HE641	NS	5	GRAPHITE HINGE
HE64100	HG202	SV	1	CONTROLLER
HG2021GB01	HG709	SV	1	SENSOR UNIT
HG7095A1		SV	1	RAD ALT RCVR
HGA-48		SV	2	ANTENNA
HI-400		SV	1	COMPASS
HL19PB5-7	HN4H4	NS	35	HI LOC
HLN6912B	XTL5000	SV	1	CONTROL HEAD
HMF-BG-135-115		NE	2	TW-SPRUEHSCHLAUCH GARDENA
HMF-BG-135-600		NE	1	DOWING BAR
HN4H41-1	HR-DR	NS	10	BUSHING
HR-DR-28	HS565	SV	1	STOBE LIGHT
HS5659ME6PN	HS583	NS	4	CONNECTOR
HS5835-15	HSAA0	NS	13	DECAL
HSAA04549-001	HSAS0	FN	19	LIFE VEST KIT
HSAS00328-011	HSAS0	NE	1	CB SEGMENT, VHF-FM 5A
HSAS04534-001	HTE20	NE	1	PLACARD "MOBIL AERO HF" LARGE
HTE200016	HTE20	OH	1	ACTUATOR BALL VALVE
HTE200016	HTE90	AR	1	ACTUATOR BALL VALVE
HTE9061	HTE90	OH	1	VALVE ASSY
HTE9061	HUCAB	AR	1	VALVE ASSY
HTE920018		NE	3	ACTUATED BALL VALVE
HTE9482		SV	1	FIRE SHUTOFF VALVE
HUCAB2BP		SV	1	CONTROL-BRIEFER
HUCG-1-BPE		SV	1	CHECKLIST
HZ0000102770-R		NE	1	EXTERNAL HANDLE

HZ0000139480		NE	1	INTERIOR HANDLE
I-81-A		OH	1	INDICATOR
IC3100-(2)-01		SV	1	IC-AMPLIFIER
IC3100-2		SV	1	IC-AMPLIFIER
ICM11		SV	1	VHF TRANSCEIVER
ID-1103/ARN	5826-00-952-3709	OH	1	ID-1103/ARN INDICATOR
ID-1351B/A		OH	1	INDICATOR HEADING
ID-310A/ARN	5826-00-691-4893	OH	1	INDICATOR, RANGE
IN223A		SV	1	CONVERTER IND VOR/ILS
IN224A		SV	1	CONVERTER IND VOR/ILS
IPT20RT1-1000-80G		SV	1	PRESS- TRANSMITTER
IPT70RT1-1000-250G		SV	1	PRESS- TRANSDUCER
ISAT-100		AR	1	SATCOM TRANSCEIVER
JB37-405		NE	7	JUNCTION BOX, 5 STATION
JBS223-1		SV	1	COMPRESSOR ASSY
JBS880-3		NE	4	MIXING VALVE
JBS880-3		SV	3	MIXING VALVE
JBS880-3		AR	1	MIXING VALVE
J-D4N-300M		NS	1	LEACH RELAY
JE2-1978-0NG		SV	1	ELT
JG206D4	ID-1345/ARN-171(V)	SV	1	INDICATOR, ALTITUDE RADAR
JG873B1		SV	1	INDICATOR
J-J2A		NE	1	RELAY
JR28259		OH	1	AIR FLOW CONTROL
J-W4N-005		NS	1	LEACH RELAY
K00-00074-00		NE	1	ANTENNA KIT
K11695		NE	1	DAEMPFER HD18
K12054		NE	2	TAWS CONFIG KIT
K38490	K60AB	SV	2	CO2 CYLINDER
K402AC		NE	1	CHIP DETECTOR
K60ABM		SV	1	ACT POSITION DISPLAY
K9323030A000		FN	1	12" Display Unit (DU)
KDL569R		SV	1	TEST BOX
KHF950	KHF950SYSTEM	SV	3	HF SYSTEM
KHF990	KHF990SYSTEM	SV	3	HF SYSTEM
KIT:117-902051	117-902051	NE	1	RPM BOX
KIT:B793M5004051	B793M5004051	NE	1	FUZZ BURNER COMMON KIT
KIT:L332M3802051	L332M3802051	NE	1	BELT AND NO SMOKING SIGNS, INST.
KIT:L334M6860101	L334M6860101	NE	1	SX-16 HAND CONTROL
KIT:L642M1806051		NE	3	FEN.GEARBOX COVER
KIT:L642M1806051	L642M1806051	NE	1	FEN. GEARBOX COVER
KS-502A		SV	1	POWER SUPPLY
KS5216H2	L108A	FN	1	CLAMP
KS5216H2		NE	1	CLAMP

L108AAM		SV	2	ARTIFICIAL FEEL UNIT
L110M1806288		NE	1	PLACARD ROTORBRAKE
L132M0009101		NE	1	SHORT
L133M6205205		NE	1	SUPPORTING SLEEVE
L133M6205205		NE	1	SUPPORTING SLEEVE
L133M6205206		NE	1	SUPPORTING SLEEVE
L133M6205206		NE	2	SUPPORTING SLEEVE
L133M6205207		NE	2	THRUST PIECE
L20420-13	L209C	NS	2	LAMP ASSY
L209CCM2	L281M	SV	1	FEEL AND TRIM ACTUATOR
L210M1820114		NE	1	EVAPORATOR COCKPIT ASSY
L210M1831105		NE	1	COND MODULE ASSY
L2-117-93		NE	2	CONTROL BOX ASSY
L212M40X1001		NE	1	MIXING VALVE
L214M1038102		NE	1	BRACKET ASSY
L219M28X3001		NE	1	SLIM BLOWER
L221M75X3101		NE	1	TRIMACTUATOR
L251M2011205		NE	1	SEAT TRACK FENDER SERIES
L251M4002101		NE	1	MAP CASE RH ASSY
L258M2079101		NE	1	CARGO COMP.PANEL LH
L258M2839101		NE	1	CARGO COMPT WALL LH ASSY
L281M2008101		SV	3	FUEL SENSOR MAIN TANK
L281M2009101		NE	2	FUEL SENSOR MAIN TANK
L281M2011101		SV	3	FUEL PROBES SUPPLY TANK
L281M2011101		SV	1	FUEL SENSOR SUPPLY TANK
L281M2012101		SV	5	FUEL PROBES MAIN TANK
L281M2012101		SV	10	FUEL SENSOR MAIN
L281M20C1006		NE	1	FUEL MAIN TANK
L281M20C1006		SV	5	MAIN TANK
L281M20C1007		NE	1	SPLIT SUPPLY TANK
L281M20C1007		SV	1	SPLIT SUPPLY TANK
L281M20C1008	FT25084	SV	1	TANK
L281M20C1008	FT25084	NE	3	TANK
L281M20C1010		NE	1	TANK
L281M20C1026		SV	1	EC135 MAIN FUEL TANK
L282M20X1006		NE	1	HOSE DN08
L284M30C1001		SV	5	FUEL SENSOR MAIN TANK
L284M30C1002		SV	3	FUEL SENSOR SUPPLY TANK
L284M30C1002		SV	4	SUPPLY FUEL PROBE
L311M1009102		SV	4	SWI-PNL-20VE SMALL-NVG
L311M1009103		SV	5	SWI-UNIT-20VE SMALL-NVG
L311M1009150	L311M1009150D	SV	1	SWITCH UNIT 20VE SMALL-NVG
L311M1009881		NE	1	SWITCH UNIT
L311M1034101		SV	2	SWITCH UNIT 20VE

L311M1034101-001		SV	3	SWITCH UNIT 20VE/EMS
L311M1034102		SV	1	SWITCH UNIT 20VE
L311M1075101		NE	1	SWITCH UNIT 20VE SMALL NE
L311M1075102		NE	1	SWITCH UNIT 20VE 217
L311M1075102		SV	2	SWITCH UNIT 20VE 217
L311M1075155		SV	1	SWITCH UNIT 20VE 217
L311M1075155		NE	1	SWITCH UNIT 20VE 217
L311M1085103		NE	2	SWITCH PANEL
L311M1085103		SV	1	SWITCH PANEL 20VE TM ADAC
L311M1085106		SV	1	SWITCH UNIT
L311M1610168	L311M1610168A001	SV	45	MOUNTING PLATE
L311M1907210		NE	1	BLOCK
L315M5001881		SV	1	WARNING UNIT
L315M5001881	L315M5001881A002	NE	1	WARNING UNIT
L315M5001881		SV	1	WARNING UNIT
L315M5001881A001		SV	1	WARNING UNIT
L315M5002051		NE	1	WARNING UNIT ASSY (STAND. -97%)
L315M5003101		SV	2	WARNING UNIT ASSY NVG
L315M50C1001	6300-00-00	SV	1	WARNING UNIT
L315M50C1011		SV	1	WARNING UNIT
L316M20C1001		SV	2	ENG/XMSN OIL T/P INDICATOR
L316M20C1002		SV	1	ENG/XMSN OIL T/P INDICATOR
L316M20C1002		NE	1	ENG/XMSN OIL T/P INDICAT
L316M20C1003	KM455-5	NE	2	ENG/XMSN OIL INDICAT
L316M20C1005		SV	1	ENG/XMSN OIL T/P INDICATOR
L316M20C1005	KM455-4	SV	1	ENG/XMSN OIL INDICAT
L321M1001205		NE	1	SKID SHOE ASSY
L321M1001250		NE	4	BOLT
L321M1001251		NE	5	BEARING SLEEVE
L321M1021230		SV	1	BRACKET FWD LOWER
L321M1021231		SV	1	BRACKET FWD UPPER
L321M1021236		SV	1	BRACKET REAR UPPER
L321M1025101		SV	1	HIGH SKID SHOE ASSY
L321M5823101		SV	1	BRACKET PRESS. TUBE COMPL.
L321M5827205		SV	1	BRACKET FWD
L321M5827206		SV	1	BRACKET FWD
L321M5827207		SV	1	BRACKET AFT
L321M5827208		SV	1	BRACKET AFT
L321P1011101		NE	4	YOKE ASSY
L331M4602101		NE	1	MODULE NVG LAMP
L331M5861101		NE	1	CHARTHOLDER NVG LH DET PART
L331M5862102		NE	1	CHARTHOLDER NVG RH DET PART
L331M5862103		NE	1	CHARTHOLDER NVG RH DET PART
L334C6002003		NE	1	SX-16 DETACH PART

L334C6802002		NE	1	SX-16 ADAPT KA
L334M3843101		NE	1	LANDING LIGHT
L341M10C1001	8000L-B709	OH	2	AIRSPEED
L341M10C1001	8000L	OH	2	AIRSPEED
L341M20C1001		NE	1	ALTIMETER
L341M20C1001		SV	2	ALTIMETER
L341M30C1001		SV	1	VSI
L344M3817101		NE	1	BRACKET ASSY RDR 1600
L521M1031105		NE	1	COVER PILOT DOOR LH
L521M1034105		NE	1	COVER PILOT DOOR RH
L521M3034101		NE	1	COVER
L521M3104101		NE	1	LOCK RH
L535A3501131		NE	1	INSERT, TUNNEL
L535A3501131		NE	1	INSERT, TUNNEL
L535A4201102		NE	1	STATOR ASSY
L535M2002051		NE	1	INST.FENESTRON-SHAFT MGB
L563M20X2003		NE	1	SLID.DO.PANE LH W.SLD.WDO
L563M20X3967		NE	2	SLIDING WINDOW LARGE LH
L621M1010056	EC135	AR	1	ROTOR BLADE ASSY
L623M2005103		NE	1	SWASHPLATE
L634M20C1001		NE	1	PRESS TRANSDUCER
L635M1021001		NE	1	CALIPER UNIT
L635M1025230		NE	1	ADAPTER
L635M1025230		NE	1	ADAPTER
L635M1025231		SV	1	MGB-FLANGE REWORKED
L652A2008201		NE	1	OUTPUT CASE
L652A2011202		SV	1	CONTROL BOX
L662C1024101		SV	1	HUBCAP STANDARD
L671M1003104		NE	1	CYCLIC STICK RH
L671M1809102		SV	1	CYCLIC STICK LH
L671M20V1005		NE	1	ROD END ASSY
L671M3011205		SV	1	LEVER
L671M5029101		NE	1	BELLOWS
L671M50C1004		NE	2	SWITCH UNIT
L671M50C1008		NE	2	SWITCH UNIT COLLECTIVE PIL
L671M50C1013		NE	1	SWITCH UNIT COLLECTIVE
L671M50C1026	G2-0055	NE	3	SWITCH UNIT COLLECTIVE PIL
L671M50C1030		NE	6	SWITCH UNIT COLL PIL
L671M50C2026		NE	2	SWITCH UNIT COLL PIL
L673M20A1012	S4-3000561	AR	1	MHA - COLLECTIV
L711M1065101		NE	1	ENG.COWLING LH
L713M1052101		SV	1	ENGINE FIX FIREWALLS TM RH
L713M2048101		SV	1	SHEET LOWER RH ASSY
L713M2048102		SV	1	SHEET LOWER RH ASSY

L713M2053101		SV	1	EJECTOR ASSY (P&W)
L713M2054102		SV	1	EJECTOR COMPL-PW RH
L713M2055102		SV	1	EJECTOR COMPL-TM LH
L713M2056102		SV	1	EJECTOR COMPL-TM RH
L713M2067102		NE	4	FIREWALL FRONT LH
L713M2068102		SV	1	FIREWALL FRONT RH
L713M2071101		SV	1	INLET CHANNEL LH
L713M2071101		NE	1	INLET CHANNEL LH
L713M2072101		SV	1	INLET CHANNEL RH
L713M2072104		SV	2	INLET CHANNEL RH
L713M2072105		SV	1	INLET CHANNEL RH
L771M10C1002		SV	1	N1-TACHO INDICATOR
L771M10C1003	DL458-121	NE	2	N1 TACHO INDICATOR
L771M20C1001	DT413-120-120	SV	1	DUAL TORQUE INDICATOR
L771M20C1003	DT413-121	SV	3	DUAL TORQUE INDICATOR
L771M20C1005	DT413-021	SV	1	DUAL TORQUE INDICATOR
L771M40C1004	DL457-300	NE	1	TRIPLE INDICATOR RRM (NVG)
L771M40C1004		SV	1	TRIPLE RPM INDICATOR
L771M40C1005		SV	1	TRIPLE TACHO INDICATOR
L771M40C1006		NE	2	TRIPLE INDICATOR RPM(NVG)
L771M40C1007	DL457-310	SV	1	TRIPLE TACHO INDICATOR
L771M40C1010	DL457-600	NE	1	TRIPLE RPM INDICATOR
L771M40C1012		SV	1	TRIPLE INDICATOR RRM
L771M40C1026		NE	1	TRIPLE INDICATOR RPM (NVIS)
L771M40C1028		NE	5	TRIPLE INDICATOR
L772M10C1002		NE	1	DUAL TOT INDICATOR
L772M10C1003	TM477-122	NE	1	DT INDICATOR
L792M3004235		NE	3	SHAFT WITH SPLINE
L853C1002103		NE	1	WIRE HARNESS
L853M2044101		NE	1	COVER CONN.BRACKET ASSY
L853M2932881	DSR-20P	NE	1	VCR DSR-20P MOD
L854M4807210		NE	1	RELAISHALTER SERIE M500
L882M1010106		NE	1	WIRE HARNESS 10VB
L882M1036101		NE	1	WIRING HARNESS
L882M1828115		NE	1	WIRE HARNESS
LC41-103011-01	103011-01	SV	1	SATCOM ADAPTER
LC41-306001-01	306001-01	SV	1	PHONE CONTROL UNIT
LC41496002-01		SV	1	BATTERY UNIT
LC42216045-23		SV	1	PANEL
LD12-002		SV	2	LAMP DIMMER
LD8016		SV	1	DME TEST PANEL
LDM-171		SV	1	LEADER DISTORTION METER
LDS50-50-20-55	LE-50	NS	24	VARISTOR
LED-40-15-HE-34387		NS	1	SWITCH ASSY

LED-40-17-HE-31351		NS	1	SWITCH ASSY
LED-40-18-BB-33599		NS	1	SWITCH ASSY
LED-40-18-BB-34384		NS	1	SWITCH ASSY
LED41-14BG32272		NE	2	2Y4, HF 3G4 FM
LG14C11		OH	1	TRANSDUCER PRESSURE RATIO
LH1PGFO0001		NE	1	LIFE HAMMER
LN29930-08X26	LN299	NS	1	SCREW
LN29952-0815M	LN943	NS	7	WASHER
LN9038-04024		NE	50	SCREW
LN9438M5X32	LN943	NS	30	SCREW
LN9439M5X32	LR600	NS	2	SCREW
LPG111		SV	1	LP GOVERNOR
LPG126		SV	1	LP GOVERNOR
LR6003		SV	1	CTL TEST PANEL
LS03-05001		AR	1	DC CONVERTER
LT-100		SV	1	LIGHT DIMMER SUPPLY
LT-25F		SV	3	AC TO DC POWER SUPPLY
LT-48B	222-375-012-101	SV	4	LIGHT DIMMER SUPPLY
LT48D		SV	1	LIGHT DIMMER PWR SUPPLY
LT48D		SV	1	LIGHT DIMMER SUPPLY
LT-52A		SV	1	LIGHT DIMMER SUPPLY
LT-70		NE	1	LIGHT DIMMER SUPPLY
LT-71		SV	1	DC TO DC CONVERTER
LT-71A		SV	1	DC TO DC CONVERTER
LT-71G		SV	1	DC TO DC CONVERTER
LV2024		SV	4	MKR/GS TEST PANEL
LZ30		NE	1	GUARD
M025277-300-08	3045802-01	OH	1	FUEL PUMP
M031-01S021-046		NE	1	SKID SHOE RH AFT
M1035E-3A		SV	1	SPARE UNIT
M1045-F356-HMD3		SV	2	AUDIO CONTROL SYSTEM
M1045-J762-ESC3	990-3342-028	SV	2	AUDIO CONTROL SYSTEM
M1045J762GNK3		SV	4	CABIN AUDIO
M1050-B324-01	990-1254-051	SV	4	AUDIO SYSTEM
M1050B-7F		SV	1	AUDIO AMP
M1050-C447-01		SV	1	AUDIO SYSTEM
M1050-G448-01	990-1254-008	SV	1	AUDIO SYSTEM
M1050-L358-02	L358-02	SV	1	AUDIO AMP
M1050S-1G		SV	1	AUDIO AMP
M1052		SV	1	AUDIO SYSTEM
M105-23301-2		NE	2	WINDOW ASSY RH
M1060-01501-07		SV	1	AUDIO SYSTEM
M1080B		SV	1	AUDIO AMP
M1082B		SV	1	AUDIO AMP

M1082D		SV	2	AUDIO AMP
M12883/40-01		NS	1	SOCKET,RELAY
M12883/44-01		NS	1	SOCKET,RELAY
M12883/53-001		NS	1	CONNECTOR,RCPT,ELECTRICAL
M2050K	M2620	SV	1	AMPLIFIER
M24251/6-1		NE	3	SHIELD
M24251/6-2		NE	3	SHIELD
M24308/2-2F		NS	1	CONNECTOR,RCPT,ELECTRICAL
M24308/2-3F		NS	1	CONNECTOR,RCPT,ELECTRICAL
M24308/2-4F		NS	1	CONNECTOR,RCPT,ELECTRICAL
M24308/4-1F		NS	1	CONNECTOR
M24308-2-1F		NS	1	CONNECTOR
M2620BJ		SV	1	MOTOR
M3088-11		SV	2	PANEL
M33GMC09C2AA	M3901	SV	1	RADIO VHF FM GM300
M39012-20-0504	M3902	NE	100	CONNECTOR
M39029/29-12-12	M4630	NS	188	INSERT
M463080/M503540		SV	2	RACK
M6241		SV	1	ANTI-ICE VALVE
M655		OH	1	OAT GUAGE
M7950-11	990-1769-005	SV	1	PAGING AMP
M81714/2-AB1		NS	2	TERMINAL JUNCTION BLOCK
M81714/2-DB1		NS	9	TERMINAL JUNCTION BLOCK
M81714/67-02		NS	1	TERMINAL JUNCTION BLOCK
M83536-2-024M		NE	4	RELAY
M83723/82K1212N		NS	2	CONNECTOR
M83723/86R1212N	X9234-115	NS	10	CONNECTOR W/ PINS AND EXT TOOL
M83723/95R0803N		NS	1	CONNECTOR
M85049/49-2-12W		NS	2	CLAMP
M85049-52-1-20W		NS	1	STRAIN RELIEF
M85049-52-1-22N		NS	1	STRAIN RELIEF
M850-5V-G	1159SCAV409-2	SV	2	DIGITAL CLOCK
M-BK117-243021-4		NE	1	ASSY, CARGO DOOR WINDOW
MC235MH089		NE	3	INDICATOR
MC4741CP		NS	25	IC
MC700-4NVG		SV	5	MAGNETIC COMPASS
MC7014-1-00		SV	1	PRESSURE SWITCH LP
MD25-300		OH	1	STANDBY AIRSPEED INDICATOR
MD41-1308	MD41-13085V	AR	1	ANNUNCIATOR
MD41-1308		AR	1	TAWS ANNUNCIATION CTL
MD41-1448	MD41	AR	1	ANNUNCIATOR
MD41-1628	MD41-1628(5V)	SV	1	GPS ANNICIATION CTL UNIT
MD41-628	MD41	SV	1	ANNUNCIATOR
MFFA370-1		NS	2	FLITER ELEMENT

MI-585002	AVI-202	SV	1	RMI/CONVERTER
MI-585031	AVN-220	SV	1	VHF NAV SYSTEM
MI-585067	AVN-204	OH	1	AUTO VOR CONVERTER
MI-585072-3	MI-58	SV	2	NAV ILS40CH MKR RX
MI-585074-7	AVC-110A	SV	1	VHF COMM
MI-585084	FP-900	SV	1	ANTENNA RADAR
MI585297-3		SV	1	DATA NAV PANEL
MI-585297-3		SV	1	DATA NAV III CONTROL PANEL
MI-585300-4		SV	1	RADAR R/T
MI-585302		SV	2	RADAR ANTENNA
MI-585396-4	DNC-1001	SV	1	DATA NAV
MI-585397-5	DNC-1002	SV	1	DATA NAV
MI-585398-2	DNCP-1001	SV	1	DATA NAV CONTROL
MI-585399-1		SV	1	DATA NAV
MI-585399-2		SV	1	DATA NAV
MIL-G-6036B	AW-17/8-27-E5	SV	1	GAGE - HIGH PRESSURE OXYGEN
MJ10023	5961-01-176-5661	NE	1	TRANSISTOR
ML335	MP498	NS	10	LAMP
MP498-103	MP498	SV	1	YAW MAG-BRAKE
MP498-105	204-001-376-105	SV	1	YAW MAG-BRAKE
MPRD9639	MS166	SV	2	BARCO DISPLAY
MS16627-1125		NS	1	RINGS
MS17983-4	CB2125-28A	OH	1	COMPASS
MS17985C411	MS208	NS	10	PIN
MS1801		SV	1	MODULE
MS1803-3		SV	2	MICROTOUCH INTERFACE MODULE
MS1804		SV	1	MODULE
MS1805		SV	1	MODULE
MS1817		SV	1	MODULE
MS1826		SV	1	MODULE
MS1829-B		SV	1	MICTROTOUCH INTERFACE MODULE
MS1833		SV	1	MODULE
MS1858		SV	1	MODULE
MS1863		SV	1	MODULE
MS2012		AR	1	MICTROTOUCH INTERFACE MODULE
MS20825-8	MS210	NS	2	TEE FITTING
MS21048-3K	MS210	NS	36	NUTPLATE
MS21074-3K	MS220	NS	50	NUTPLATE
MS21075-3N		NE	100	NUTPLATE STEEL
MS21225-6		NE	3	NUT
MS22034-4	MS245	NS	1	JAW FITTING STUD
MS22073-10	7274-11-10	NS	1	CIRCUIT BREAKER
MS22073-15	7274-11-15	NS	1	CIRCUIT BREAKER
MS22073-2	7274-11-2	NS	3	CIRCUIT BREAKER

MS22073-3	7274-11-3	NS	7	CIRCUIT BREAKER
MS24183D1	24183D1	SV	1	RELAY SOLENOID
MS24390630BC4		SV	1	HYDRAULIC MOTOR
MS24576-2	18-1701	OH	1	OIL PRESSURE INDICATOR
MS24693BB52		NE	189	SCREW
MS24694C99		NE	39	SCREW
MS24694-S64		NE	150	SCREW
MS25056-1B		NE	1	SLEEVE ANTENNA WIRE
MS25056-1B	MS252	NS	1	SLEEVE/ANTENNA WIRE
MS25069-1495		NE	10	LAMP
MS26574-1	7274-70-1	NS	3	CIRCUIT BREAKER
MS27472T24B-2S	MS274	NS	1	CONNECTOR
MS27472T24B61P	MS277	NS	4	CONNECTOR
MS27473T14B18S		NE	2	CONNECTOR
MS27782-2F	MS280	NS	1	SWITCH
MS28041-2A	MS280	OH	1	TURN AND SLIP
MS28043-T2	273-7TN112	OH	1	GAGE UNIT - ENGINE
MS28075-1	RCS-60-1L	OH	1	IND, RATE OF CLIMB
MS28773-03		NE	20	RETAINER PACKING
MS28774-016		NE	50	RETAINER RING
MS28774-138	MS310	NS	7	RETAINER
MS28774-138		NE	7	RETAINER
MS28778-5		NE	400	PACKING
MS28778-8		NE	100	PACKING
MS3101A10SL-4P		NS	11	CONNECTOR
MS3106A18-11S		NS	1	CONNECTOR
MS3106A24-11P		NS	1	CONNECTOR
MS3106E14S-2S	MS310	NS	1	CONNECTOR
MS3106E28-16P	MS310	NS	2	CONNECTOR
MS3106F24-A24S		NS	3	CONNECTOR
MS3108F24-58P	MS347	NS	2	CONNECTOR
MS3116F10-6S		NE	1	CONNECTOR
MS3126F-16-23P		NS	10	CONNECTOR
MS3416-8EN		NS	31	BACKSHELL
MS3470L12-10P		NS	1	CONN KIT
MS3470L20-39PY		NS	4	CONNECTOR
MS3470L24-61PY		NS	1	CONNECTOR
MS3470W20-41SW	MS347	NS	1	CONNECTOR
MS3474W12-8P		NS	4	CONNECTOR
MS3476W20-39S		NS	5	CONNECTOR
MS35489-120	MS357	NS	8	GROMMET
MS35489-69		NE	25	GROMMET SYNTHETIC RUBBER
MS35769-20	MS361	NS	2	GASKET
MS3614-8EN	MS910	NS	36	BACKSHELL

MS9105-55	N000-	NS	2	PIN
MS91528-2N2B6		NE	1	KNOB
MS9575-09		NE	5	BOLT
MT1-1079-102		SV	1	ATC MOUNTING TRAY
N001-0001		SV	1	CONTROL DISPLAY UNIT
N200-151		NE	1	EMERGENCY ENG CONTROL
N300-005		SV	2	AUDIO CONTROL PANEL
N300-006		NE	1	CABIN CREW AUDIO PANEL
N303-10167-53-A	5985-01-297-5162	NE	5	RADIO FREQ SWITCH
N335-023		NE	2	AUDIO CONTROL PANEL
N3844-20		SV	1	ARRA ATTENUATOR
N48-1-2		SV	2	ANTENNA
NA135	NAS11	SV	1	AUDIO FREQ DECODER
NAS1149C0532B		NE	50	WASHER
NAS1330H08K161		NE	70	NUT PLAIN RIVET BLIND
NAS1333A3C10D		NE	3	QUICK RELEASE PIN
NAS1376A08SD018		NE	1	DUCT
NAS1738M5-6		SV	10	RIVIT
NAS1836-06-08		NE	1	INSERT
NAS1922-0400-1H		NE	6	CLAMPS
NAS557-8B	NAT35	NS	40	GROMMET
NAS561C4-9		NE	99	PIN SPRING
NAS6604D58		NE	5	BOLT
NAS77-4-012		NE	10	BUSHING
NAS8603-3		NE	31	BOLT
NAT352-001	NAT380-005	OH	2	AUDIO PANEL
NDN8595-03	704A47152004	OH	1	VERTICAL GYRO
NDN9768-03	NDN9768	SV	1	FLT PATH CTL COMPUTER
NT-30B-000W/R	NT30B-000	SV	1	FM TRANSCEIVER
NT450	CH250-020	OH	1	FM TRANSCEIVER
NT450	CH250-ONE	OH	1	FM TRANSCEIVER
NY-6MO-3	NY-6M0-3	NE	1	FITTING
O33203	BC407/332	OH	1	AMETEK ROTRON INVERTER
O50084	1250435	OH	1	BLOWER
O50084	1250435	AR	1	BLOWER
OB1303-003		SV	1	DZUS CONT (HORIZONTAL NON-NVG)
OBS-85A		OH	1	OMNIBEARING SELECTOR
P057634	P1208	SV	1	PRINTED CIRCUIT
P058312	704A46610010	SV	1	PRINTED CIRCUIT,Z200
P100-205A		NS	4	SCREW
P-10A		SV	1	INVERTER
P12064		NS	1	CONN KIT
P12083		AR	5	CABIN COMM ROUTER
P12248-002	AIRCELL	SV	1	AIRCELL HANDSET

P12339		SV	1	AIRCELL AXCESS II
P12347		SV	2	AIRCELL MODULE
P12861-001	P12861-003	NE	1	ASSY, TOP BASE STATION
P155-15A-E1A		SV	2	ADAS TRANSDUCER ASSY
P200100AFCAU	704A47134186	SV	3	BOX CONTROL
P356-5000		SV	1	ADAS TRANSDUCER ASSY
P600-14A	P6021	NS	1	CURRENT PROBE
P8304-1		SV	1	INVERTER
P94C16-601		AR	1	FUEL PUMP
PAI700		SV	1	COMPASS, BACKUP
PANL-2016-05-01		NE	2	SKYQUEST VCR REMOTE CONT
PC06E8-4S-SR		NS	11	CONNECTOR PLUG,ELECTRICAL
PC-125-123C		OH	2	STATIC INVERTER
PC12A		NE	1	CONVERTER 28/12 VDC
PC-12A		SV	1	STATIC INVERTER
PC-12A	PC-12	SV	1	CONVERTER
PC-12VR		OH	1	DC TO DC CONVERTER
PC16-3	PC-16-3	SV	1	STATIC INVERTER
PC17A	PC17A	SV	3	STATIC INVERTER
PC251		AR	1	STATIC INVERTER
PC-251-123E		SV	1	STATIC INVERTER
PC-251-123K	76550-23800-102	SV	1	STATIC INVERTER
PC-50		SV	2	STATIC INVERTER
PC820-101A		SV	2	SIGNAL CONDITIONING UNIT
PC900-1A0600PH1		SV	1	FUEL FLOW INDICATOR
PC900-1A0600PH1-1		SV	1	FUEL FLOW INDICATOR
PC-900-ECAP-0001		SV	1	INDICATOR CONDITIONER UNIT
PCC-15V	PF10-	NS	1	CURTAIN RACK
PF10-167		SV	1	ANTENNA
PH502-BKC		NE	1	PITOT TUBE
PO58312	704A46610010	SV	1	PRINTED CIRCUIT
PR-10		SV	1	CURRENT PROBE AMPLIFIER
PS1230		AR	1	BATTERY PACK
PS18125-1		SV	1	POWER SUPPLY, USB
PS7016006-202	PT06A	NS	2	O RING
PT00SE14-19S		NS	2	CONNECTOR,RCPT,ELECTRICAL
PT06A84SSR	PW206	NS	1	CONNECTOR
PT06CE8-2P(SR)		NS	16	CONNECTOR
PT06SE22-55PX		NS	1	CONNECTOR
PW-28D-13FL-4	222-375-065-101	SV	1	POWER SUPPLY
PW-28S-40CC-2		SV	11	POWER SUPPLY
PW727MVBUE7		OH	1	EGI INDICATOR
PYLB50487-1	R1467	OH	3	V/V ANTI-ICE/EAPS
R-1123A/ARC73		SV	1	RECEIVER, RADIO

R1467M20	214-001-347-101	OH	1	ACTUATOR
R-252220-00		AR	1	CAMERA UNIT, DOWN ZOOM
R460M15-11	204-001-376-3	OH	1	MAG BRAKE
R460M44-105	204-001-376-105	OH	2	MAGNETIC BRAKE HELICOPTER
R460M44-107	204-001-376-107	OH	2	MAGNETIC BRAKE HELICOPTER
R50U-15-N		NS	1	CONVERTER
RBE12-03	LMP027	SV	1	RPM WARNING SYS
RC-30-V-10-1	100-384054-1	SV	1	IVSI 0-3000 FPM
RC-30-VIL	212-070-239-001	OH	3	VSI
RC-60-10DE2	RC-60-10	OH	1	IVSI
RCA15B3		OH	1	INDICATOR GYRO DIR
RCA15BL1		OH	1	INDICATOR, DIR GYRO
RCA26BK-2	102-0054-03	OH	2	INDICATOR, GYRO ATT
RCA28W2D2S		OH	1	INDICATOR
RCA82A-2		OH	1	TURN COORDINATOR
RCD-021-402		SV	1	AI CD PLAYER
RCLD14-5-B2/28		SV	1	DISPLAY
RCLD14-7/28		SV	1	DISPLAY
RCM-10-3		OH	1	RATE OF CLIMB INDICATOR
RCM60ACL		OH	1	RATE OF CLIMB INDICATOR
RD25FJVL0		NS	1	CONNECTOR
RD29M00000		NS	3	CONNECTOR
RD29M10JV30		NS	1	29 PIN M DSUB KIT
RD50M10JVL0		NS	1	CONNECTOR
RD8180K	4440-00-780-1039	OH	1	DEHYDRATOR UNIT
RD9F10JVL0		NS	2	CONN KIT
RD9M10JV30		NS	1	CONN KIT
RD9S10GVL0		NE	1	CONNECTOR
RD-AV7052-1		SV	7	LCD MONITOR
RDR1400SYSTEM	RDR1400	SV	1	WEATHER RADAR SYSTEM
RECT1-B12-1A998000		SV	1	POTENTIOMETER
RG-15980-E		OH	1	FUEL PUMP
RG40		SV	1	DC TO DC CONVERTER
RGD-9-D-PS-R		SV	5	SHARP/ROSEN DISPLAY
RGD-9-R	6M-40U	NS	5	SHARP/ROSEN DISPLAY
RIA01-01-00		NE	1	RETRACTABLE INTERFACE ADAPTER SET
RISR-28-12-6		SV	6	PWR CONV
RL5026		NE	18	READING LIGHT
RLB-35	2744	SV	1	ACR ELT
RLCD14-5-B2/28		SV	1	ROSEN DISPLAY
RM300CA-9W		SV	1	DIODE ASSY
RN-222AE		SV	1	NAV RCVR
RNVAP-2LL		NS	1	ROSEN CONNECTOR
RNVAP-5ULL-L-WO/28		SV	1	VIDEO MONITOR

RR54220	70307-23908-101	OH	1	PUMP DUMP FUEL SYSTEM
RS08-001		AR	4	AUDIO BOX
RS08-500		SV	1	AUDIO BOX
RS16-001		SV	1	RELAY UNIT
RS8031	RSLM-	SV	1	VOLTAGE CONVERTER
RSLM-5SB/28		SV	2	MONITOR BASE
RSLM-5SLA-L/28		SV	3	MONITOR DISPLAY
RT100M1E		SV	2	MEM- CARD READ/WRITE U-
RT100-PC-M1		AR	1	CARD READER
RT-1115C/APN209V	HG7209AB01	SV	2	RECEIVER TRANSMITTER
RT651/N-A	SRT651	NE	1	V/UHF TRANSCEIVER
RT8	XANTECH	SV	1	ADDRESSABLE INFRARED ROUTER
S15-005	706A31213061	SV	1	ECLAIRAGE PANNEAU CARB 3Q
S1609.1.118A		NE	3	LOAD HOOK
S1609.6		OH	1	SLING CARGO HOOK
S1820513-11		AR	1	ELT SWITCH
S1840501-01		AR	1	ELT
S212-850		SV	1	AC CURRENT LEVEL SENSOR
S4000-4		SV	1	PASSENGER BRIEFING SYSTEM
S4-3402250		NE	1	MAGNET VENTIL
S6130-63049-000	S65-5	OH	1	DEFUEL/REFUEL VALVE
S65-5366-10L		SV	1	L-BAND ANTENNA DME/XPDR
S65-5366-850L		SV	1	ANTENNA RADIO PHONE
S65-8282-25		SV	1	ANTENNA
S65K-L7-30	S67-1	OH	1	AIRSPEED MAX ALLOW IND
S67-1575-20		SV	4	ACTIVE GPS ANTENNA
S67-1575-232		SV	10	ACTIVE GPS ANTENNA
S67-1575-39		SV	8	ANTENNA
S67-2002-14		AR	1	ANTENNA
S72-1750-32L		AR	1	ANTENNA
SA106509	SA106	SV	1	TAPE CARTRIDGE ASSY
SA106572	SA-40	SV	1	HARVARD BI-PHASE CARD
SA40-1	8000T-B12	SV	1	AIRSPEED IND
SA-40-1	8000T-B12	OH	1	AIRSPEED 0- 200 MPH
SA-40-1RB	8000T	OH	1	AIRSPEED 0- 200 MPH
SAT-550		NS	1	GLOBALSTAR SATELLITE PHONE
SB093-1		NE	1	KIT F. AIR CONDIT.
SB-117-90-119-3.1		NE	1	RETROF CIP DET TAILR INTERM GEARBO
SB120		SV	1	POWER STATIC INVERTER
SB-135-33-004-2C1		NE	1	LED POS LIGHT
SB-135-34-034-2C1		NE	1	RET STBY HORIZON
SB-135-52-006-2C1		NE	1	JETTISON COCPIT DOOR
SB-135-53A-018-2C1		NE	1	CHANGE OF DRAIN HOSE
SB-135-85-030-2C1		NE	1	CONVERSION HELLAS

SC41-37002-01	SC41-	SV	1	PANEL
SC41-471001-01		SV	2	TELCOM TRANSFER UNIT
SC41-471002-01	471002-01	SV	1	SATCOM INTERFACE COMPUTER
SC41-472001-01		SV	1	HANDSET TRANS UNIT
SC44104048-537	59734/SC44104048-537	SV	1	PANEL
SC44104058-51		SV	1	PANEL
SC44453002-27		SV	1	PANEL
SC44468035-37		NS	1	EXT LTS/MASTER ETC PANEL
SD15F10JVL0		NS	1	CONNECTOR
SD167A		NE	1	CONTACTOR
SE13626	704A42713044	SV	2	HEATING MAT POWER UNIT
SE13651	704A42713045	SV	1	MPA POWER UNIT
SE-3130-D-73-71-905		OH	4	SERVO COMMANDE TYPE 4300
SEL0C19EL		OH	1	T5 INDICATOR
SEL-OC19AM	76450-01076-106	OH	1	TURB TEMP IND
SEL-OC19AP	76450-01076-107	OH	1	TURB TEMP IND
SEL-OC19EL		OH	1	T-5 INDIC
SEL-OC19EL1	SEL-OC19EL1	OH	2	T5 INDICATOR
SEL-OC29CB	76450-00903-101	OH	2	TRIPLE TACH
SEL-OC29F	76450-01076-101	OH	2	GAS GEN TACH IND
SETL-OC329A	76450-01076-103	OH	2	TRIPLE INDICATOR, TACH
SG1525AJ		NE	10	MICROCIRCUIT
SK106L106-581,4		NE	2	ROD TUBE
SK355-078-01	SKCP2	SV	2	WHEEL ASSY
SKCP2456-3	SL204	SV	1	DRIVE SHAFT
SKCP2456-3		NE	1	DRIVE SHAFT
SKCP2456-3		SV	1	DRIVE SHAFT
SL2049-1	SLZ76	NS	4	NUT
SLZ7600		OH	1	TRANSMITTER, STAT-429
SLZ9125A	6610-903-0714	OH	1	INDICATOR, VERTICAL VELOCITY
SLZ9157	D6HL	OH	1	IVSI
SLZ9157-3	D6HL	SV	1	IVSI
SLZ9644		OH	1	TRANSMITTER, ANGLE OF ATTACK
SM15CXD20		SV	1	RELAY 60 AMP 1PDT
SM20ACD200A21		SV	2	CONTACTOR
SM20ACD300A21		SV	2	CONTACTOR
SM20CCD200B21		SV	2	CONTACTOR
SM600BA50A1		NS	1	CIRCUIT BREAKER
SM600BA75N1		NE	1	CIRCUIT BREAKER
SM-D-374989	5821-00-089-9207	NE	2	A1500 RF TUNER
SN3500-010N	SN3500	SV	1	EHSI NVS
SO-1055-8690		NS	1	RELAY SOCKET
SOC108		OH	1	HP FUEL COCK
SP401		SV	1	TELPAR PRINTER

SP67-9		SV	1	SMARTPACK
SPC-10(H)		NE	1	INVERTER
SPC-30B	SPC-6	SV	1	INVERTER
SPC-60A	SPH-1	SV	1	INVERTER
SPH-1006	SPH-1	SV	1	STATIC FREQ CHANGER
SPH-1606B-3	SPS-1	OH	1	STATIC FREQ CHANGER
SPR87378		NE	1	JACK 7T MODIFIED
SPR87378		NE	2	JACK 7T MODIFIED
SPS-1-1-331	SPS-1	NS	1	SWITCH
SPS-1607	SPS-1	OH	1	STATIC INVERTER
SPS-306B-3		SV	1	STATIC INVERTER
SRM8.TA		NS	2	BEARING
SS9013-2409	SSP23	NS	1	IDENT PLATE
SSD120-30A		SV	1	ATTITUDE ENCODER
SSP23-004B		NS	1	LABEL, MAR, VHF
SSP23-022-3		NS	1	INTERCOMM HARNESS RADIO
SSPD-113-39		NS	1	ANTENNA POWER DIVIDER
ST10107		NE	2	MOTOR-TACHOMETER GENERATOR
ST3400H-001		FN	10	TAWS-A & RMI
SX-16		OH	1	SEARCH LIGHT
SX7EJ3		SV	1	BATTERY CONTACTOR
SYLC52086-2	230-360-701-101	OH	1	ACTUATOR ELECTROMECHANICAL
SYLC-9548-1		SV	2	LINEAR ACTUATOR
SZ65-001-1		SV	1	MOTOR COMPRESSOR COND UNIT
T1B90A6C		AR	1	METAL PART
TA3F-94V0		NS	1	CONNECTOR
TBM150365	TE-17	SV	1	VIDEO POWER SUPPLY
TDH7050-2000		NE	2	RELAY
TE450		AR	1	LS AMPLIFIER
TE450BN846		AR	1	TRANSISTOR
TH250-2NN	TLNB-	SV	1	FM CONTROL
TJG120403		NS	1	TERMINAL JUNCTION
TK-7180		SV	1	VHF FM TRANSCEIVER
TLH451L115		NE	1	SLIDING PIECE
TLNB-10		NE	1	TERK DUAL LNB
TM105-2		SV	1	TEMP. SWITCH
TM105-2		NE	1	TEMP SWITCH
TM-105PSN	TM410	SV	1	TV
TM410-39		SV	1	TRIPLE OIL TEMP. INDICATOR
TM410-40		SV	1	TRIPLE OIL TEMP INDICATOR
TM410-53		SV	1	TRIPLE OIL TEMP- INDICATOR
TM410-54		OH	1	TRIPLE OIL TEMP- INDICATOR
TM427-39		SV	3	EXHAUST TEMP. INDICATOR
TM427-40		SV	3	TEMP INDICATOR

TM427-45		NE	2	TEMPERATURE INDICATOR
TM427-45		SV	1	TEMPERATURE INDICATOR
TM477-020-020		SV	1	DUAL TOT INDICATOR
TNC3844-20	N3844-20	SV	1	ADAPTER
TRAWID9-25		NE	1	BREAK OUT BOX
TRDU24A2	TSG42	SV	1	TIME DELAY RELAY
TS-642/U	AN/UPM-56	SV	2	TEST SET, RADAR
TS-807/ARM-10		SV	1	TEST SET, RADIO
TSG420-103	TWN-1	SV	1	STATIC INVERTER
TWN-12	UC-28	NS	2	TWIN PILLOW BLOCK
TWN-12-ADJ		NE	2	TWIN PILLOW BLOCK
TYE3007-3-18		NE	1	INSERT
TYP8124K		SV	1	AVIONICS FAN
UC-28-14	UCB16	SV	4	DC TO DC CONVERTER
UCB16530-02	UCB16530	SV	1	CONTROL UNIT
UNC529		NE	1	GRIP
UT12-000		NE	1	TONE ENCODER
V084C-CA		AR	5	MONITOR
V5000-172	V694-	SV	2	SOLENOID VALVE
V6-328		NE	1	BELLOWS
V63A010-00-001-001	V63A010	SV	2	MULTI-FUNCTION DISPLAY
V694-6-1	V694-	SV	1	VOICE GENERATOR
V694-7-5	V8500	SV	1	VOICE GENERATOR
V694-7-7		SV	1	VOICE GENERATOR
VA 3660		NE	1	AXIAL FAN
VA 3660		SV	3	AXIAL FAN
VA1A300		SV	1	INDICATOR, DC VOLT AMP METER
VA400		SV	1	VIDEO SWITCH
VA-400-1	VCT15	SV	1	AIRSHOW VIDEO AMP
VCL16501-02		SV	1	TRIM ACTUATOR
VCP-014-01-2		SV	1	VIDEO PLAYER
VCP-015-01-1	30500056	SV	1	VIDEO PLAYER
VCT1518C	9560156790	AR	2	BLOWER
VCT1518C	9560156790	OH	1	BLOWER
VFS10-90-1		SV	2	ANTENNA, VHF
VFS10-90-2		AR	7	ANTENNA, VHF
VG204AB	76600-02113-103	OH	1	REMOTE GYRO
VG204V	76600-02113-102	OH	1	REMOTE GYRO
VLTL12-CV	VM-20	SV	1	DC TO DC CONVERTER
VM-202RRT	VM202	SV	1	PHASE ANGLE VOLTMETER
VP4805		SV	1	RF MOUSE
VR2011	VR300	SV	1	VOLTAGE REGULATOR
VR2011		SV	1	VOLTAGE REGULATOR
VR300-14-50		NS	1	VOLTAGE REGULATOR

VR-L11-0023.100		NE 1 COLD BONDING TOOL SET EC135
VT044		NE 20 ROD TUBE
VT426-39		NE 2 FUEL INDICATOR
VT426-40		SV 1 FUEL PRESSURE INDICATOR
VT426-41		SV 1 FUEL QTY IND (US GALS)
VT443-1		SV 1 FUEL QTY IND (US GALS)
VXAP-135		NE 1 VXP APPLICATION KIT T&B EC135
VXAP-135DS		NE 1 VXP APPLICATION KIT EC135 DRI
W0314		NE 2 LAP BELT
W21ADCQX-5	W33-7	NS 1 RELAY
W21ADCQX-5		NS 1 RELAY
W33-7510-10	98429-W33-7510-10	OH 1 CLOCK
W33-7510-10A		OH 1 CLOCK
W671M50C1001		NE 1 SWITCH UNIT COLLECTIVE
WA1967		NE 1 SAFETY DISK
WA2014		NE 1 STELLMOTOR
WA4337		NE 1 GEAR ASSY
WA4339		NE 1 GEAR ASSY
WA4346		NE 1 RECORDING RING
WB4365		NE 1 PISTON
WB4366		NE 1 DRIVE CAM DISK
WE-3821-4		SV 1 HOIST ASSEMBLY
WEMACPP3510-10		SV 10 READING LIGHT
WGE-0090-00		SV 1 DIPLEXER
WL/519CUF/1	WL/519CLF/1	SV 1 ALTITUDE ALERTING UNIT
X00042-413		SV 1 STALL PROTECTION COMPUTER
X98545		SV 1 EMERGENCY VHF TRON AIR
XD4N		NS 2 LEACH RELAY
XE-90MKII		SV 2 STEREO GRAPHIC EQUALIZER
XL1327		SV 1 ANTENNA PLATE
XMC100-01		NS 1 XM RADIO CONTROLLER
XMD076-01	RS232	SV 1 XM DATA RCVR
XMR100-01		NS 1 XM RCVR UNIT
XW21160-M1		NE 3 MOTOR
XW23513-1	222-325-001-25	SV 1 MOTOR CONVERTER
Y1242-31-1		AR 1 MOTOR
Y-E4N-024		NS 1 LEACH RELAY
ZC-B3N		SV 1 RELAY
ZE3-276		SV 3 GUIDE ASSY
ZRB263-00		NE 3 PRESS TRANSDUCER

der

IR

TER

DFILTER)

SY

T

SSY

LER

