



Prime Seating Application Chart for Truck make and models

Freightliner	International	Kenworth	Mack	Peterbilt	Sterling	Volvo	Western Star
Century	4000 Series	C500	CH	320	Acterra	VHD	3800
Classic	5000 Series	T470	CX	325	AeroMax	VN	4800
Cascadia	7000 Series	T600	GRANITE	330	A-Series	VNL	4900
Classic XL	8000 Series	T660	GU	337	Louisville	VNM	5900
Columbia	9000 Series	T700	PINNACLE	348	L-Series	VT	6900
Coronado	DuraStar	T800	TITAN	365		WAH	LowMax
Coronado SD	LoneStar	T900	TD	367		WCA	StratoSphere
FLD	PayStar	T2000	VISION	379		WG	
FLD SD	ProStar	W900		382		WIA	
	TerraStar			384			
	TranStar			385			
	WorkStar			386			
				387			
	International Adapter			388		Volvo Adaptor	
	Prime-P0104			389		Prime-P0101	
	ProStar			587		VHD Since 2000	
	LoneStar					VN Since 2000	
	TranStar Since 2002					VNL Since 2000	
	WorkStar Since 2002					VNM Since 2000	
	DuraStar Since 2001					VT Since 2000	
	TerraStar			579 567			
	8000 Series Since 2002						
	7000 Series Since 2002						
	4000 Series Since 2001						
					Kenworth Peterbilt Adapter		
					P2209		
					T680 T880		