


Lumiere™ Glass Essential Oil Diffuser INSTRUCTIONS

PARTS



FEATURES

Ultrasonic vibrations transform your essential oil and water into fragrant humidification.

1. Water Capacity: 120 mL (4.06 fl oz)
2. Coverage Area: Up to 200 sq ft
3. Continuous Operation: Up to 4 hours
Intermittent Operation: Up to 8 hours at 20-second intervals
4. Light Mode: Warm white
5. Automatic safety shut-off
6. Power: AC adapter included, c UL us approved

CARE & MAINTENANCE

Only use the power cord supplied with the unit. Always disconnect the power cord before cleaning. Essential oil should not come in contact with the exterior surface of the unit.

TO CLEAN:

* SpaRoom® KLENZOR™ tablets may be used to renew diffuser to like-new condition.

Remove Outer Cover and Water Tank Lid. Empty water from the Water Tank away from the Air Outlet.




The Ceramic Disc should not come in contact with any hard or sharp objects.

To remove possible buildup, gently use a cotton swab dipped in white vinegar to wipe out the inside. Dry with a soft cloth to avoid mineral buildup. Do not use strong cleaning agents.

INSTRUCTIONS FOR USE

Place diffuser on a flat, water-resistant surface when operating.

1. Remove Outer Cover and Water Tank Lid from the Base.
2. Insert the Adapter's DC connector into the DC Socket located on the bottom of the diffuser. Plug the AC end of the Adapter into an electrical wall outlet.
3. Pour tap water into the Water Tank up to the Max Fill Line. Add 2-3 drops of essential oil (not included) directly into the Water Tank.
4. Replace the Water Tank Lid and Outer Cover onto the Base.
5. **Power Button Functions:**
 - 1st Push = Continuous mist and warm white light
 - 2nd Push = Intermittent mist and warm white light
 - 3rd Push = Turns unit off completely



NOTES:

- The unit will automatically shut off completely when water level becomes too low.
- Disconnect Adapter from electrical outlet when not in use.