

supersolano EVO

HAIR DRYER INSTRUCTIONS & WARRANTY



Congratulations! Your new Solano® dryer represents the international standard of quality, technology and artistry for the hair care professional. Proper care and operation will ensure that your dryer will give you superior results for many years to come. Please read this booklet carefully before use.



MADE IN ITALY

1

ENGLISH

protective switch will interrupt the heating

element and stop heating. The dryer must be unplugged from the power supply and the filter screen cleaned. After the dryer has cooled, it can be turned back on.

- The front air outlet grill can become very hot. Do not touch this grill and make sure that the power cord does not come in contact with this area.

ALCI POWER PLUG

Leakage Circuit Interrupter (ALCI), a safety feature that renders it inoperable under some abnormal conditions, such as immersion in water. To make sure the ALCI is functioning properly and the exclusive water sensing system (ALCI) is working, perform the following test.

Plug in hairdryer and press test button on plug.

Hairdryer will stop working. There will be an audible click and reset button will pop out.

To reset ALCI with a reset button: Unit should be unplugged. Then push reset button in, and reinsert plug into outlet.

Be sure to repeat test every time you use hair dryer to confirm ALCI is operational. If ALCI is not functioning properly, return hairdryer to service center.

3

OPERATING INSTRUCTIONS

- This dryer can only be used with 110-125 volt power systems. Before using your new hair dryer check that the power supply voltage corresponds with that shown on the dryer. DO NOT USE with 220-240 volt power systems! Dryer electronics and motor will suffer damage. Warranty will be void if there is evidence of such damage.
- Reference the switch settings for optimum dryer performance.
- The styling nozzle serves to concentrate the airflow and work smaller sections of hair.
- Your dryer will have a removable filter system. The filter ring and screen allows you to keep your appliance free from entrapped hairs and dust. A quarter turn to the left disconnects the removable filter ring and screen from the dryer. Remove the filter screen and clean it with a brush. Replace the filter ring and screen by turning to the right. Remember to clean your filter regularly.
- For your safety, your hair dryer is equipped with a thermal-protective switch, which prevents damage by overheating. In the event of overheating the thermal-

2


ENGLISH

It is important that if immersion occurs, this unit be brought to a service center.

Do not try to reset. Should the hairdryer go off and the reset button pop out during use, this could

indicate a malfunction in the hair dryer. Remove plug from outlet and allow the dryer to cool.

Reset the ALCI. Reinsert plug into outlet. Hairdryer should function normally. If not, return to service center for examination and repair.




■... TEST BUTTON
■..... RESET BUTTON

4

INSTRUCTION FOR USE

1. ON / Lock / OFF switch

I = ON -  = Lock - O = OFF



2. Cold-shot button

3. Temperature control switch

- = low temperature
- = medium temperature
- = high temperature

4. Airflow control switch

- = low airflow
- = medium airflow
- = strong airflow

5

MEMORY FUNCTION

Dryer will recall the last setting for Temperature and Airflow after shutting down

SAFETY INFORMATION


For your own protection from injuries and electric shocks, the following information must be observed when using electrical equipment:

Read all the instructions before using the appliance!

- Do not immerse the appliance in water and AVOID contact with water or other liquids.
When switched either on or off, keep the appliance AWAY FROM bathtubs, showers, areas of high humidity and water-filled containers. Always disconnect from the power supply after use, since proximity to water can be hazardous, even when the appliance is switched off. Store the appliance in a protect place, possibly away from children and in dried places.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice

7

LOCK FUNCTION

It is possible to lock the chosen air/temperature combination, slide the switch (1) to the lock position . When you desire to change setting, slide switch (1) to the [I] position and adjust the setting.
Note: with the lock function engaged, the cold-shot button (2) remains functional

SELF-CLEANING SYSTEM

To activate the self-cleaning system (auto reverse):

1. Remove the rear filter paying attention to leave the openings free and away from objects.
2. Turn on and off the hairdryer sliding the switch (1) to the position [I] and then to the position [O]
3. Immediately press simultaneously the switch (3) and switch (4) for 5 seconds.
4. The auto reverse system will activate, the hairdryer will turn off automatically after few working seconds.
5. Reinstall Sponge Filter (wash & dry before use) + Filter Ring on position the rear filter.

Self-cleaning should be performed regularly. We recommend using the self-cleaning function every 3 days for professional use in a salon or every 10 days if the hair dryer is being used at home.

6



WARNING: Do not use this appliance near bathtubs, shower, basins or other vessels containing water.

- Only use the appliance to dry hair.
- Only operate the hair dryer with an AC power supply and with the voltage stated on the rating-plate.
- Never touch electrical equipment that has fallen into the water. Disconnect from the power supply immediately.
- When the appliance is new, sparking may occur at the collector of the motor inside the appliance. This phenomenon disappears after a brief operating period and does not indicate that there is any impairment of the appliance's operational safety.
- Never use the appliance without the rear filter.
- Disconnect from the power supply before cleaning or servicing the appliance.
- Keep the packaging away from children as this is potentially dangerous.
- Never touch the appliance with wet hands or feet.
- Never use the appliance when barefoot.
- Only use the appliance for the proper use as described in the operating instructions. Only use accessories recommended by the manufacturer.
- Do not use the appliance if it is defective, if it has fallen onto the floor or if the mains cable is damaged. Switch off the appliance if it is defective and/or if there is a malfunction. Repairs may only be performed at an authorized Service Center using original parts.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not pull the power cable or the appliance itself to take the plug away from the socket.

8

- When disconnecting the appliance from power supply, never pull on the mains cable as a handle.
- Do not wind the mains cable around the appliance.
- Keep the mains cable away from hot surfaces.
- Make sure that the mains cable is not twisted or kinked when stored.
- When using the diffuser, never set the hairdryer to a high temperature as this could result in the overheating of the diffuser or hair dryer.
- Never insert or allow objects to fall into the openings of the appliance.
- Never use the appliance where aerosol (spray) products are being used or where oxygen is released.
- The appliance is safety insulated and radio screened. It meets the requirements of EU Directive 2014/30/EU regarding electromagnetic compatibility and Machinery Directive 2006/42/EC.
- The hair dryer is fitted with an over-heating protection facility. Should the appliance over-heat, the heating process is interrupted and only cold air flows out. After the appliance has cooled down, the heating element will switch on again automatically.
- Do not take the back filter away, use original accessories only, do not cover the back filter or the front grill and do not damage the power cord or the plug. All these precautions avoid electro shocks, breakage of internal components and different damages to the appliance as well as overheating.
- Clean the back filter every two days and check if all the outside parts of the appliance are intact.
- Do not leave the hairdryer switched on the floor and on carpets. This can damage these surfaces.
- We are not liable for damage caused as a result of improper use or failure to observe these operating instructions.

WARRANTY

1. The 24-month warranty period begins with the purchase of the appliance and must be proven by presentation of a purchase slip such as sales check, invoice, delivery note or the like.
2. Defects which occur in the warranty period, and which are reported to us in writing within three weeks of their occurrence will be corrected by us free of charge subject to restrictions listed at point 3. Repairs must be made in our factory or at a point of sales authorized by us. The customer has no further reaching rights from this warranty.
3. Defects caused by excessive use, improper handling and maintenance and by non-compliance with operating instructions are not covered by the warranty. The same applies to defects which occur as a result of the normal wear and tear of expendable components (e.g. drive components).
4. The warranty period will not be extended by the effecting of any warranty performances.
5. Parts exchanged within the scope of warranty repair work become our property.
6. In the event of unjustified of our customer service, the costs incurred will be charged to the customer.
7. This does not affect your statutory rights.

• THIS APPLIANCE HAS BEEN DESIGNED & ENGINEERED TO BE USED FOR COMMERCIAL USE

- **THE NOISE LEVEL OF THIS APPLIANCE IS LESS THAN 70 dB(A)**
- The socket used must be clearly visible and easily accessible



Disposal in EU countries

Do not dispose of the hairdryer with the domestic refuse. As part of the EU Directive governing the disposal of electric and electronic devices, the device is accepted free of charge by local waste collection points or recycling centres. Correct disposal will ensure environment protection and prevent potential harmful impact on people and the environment.

Disposal in non-EU countries

At the end of its service life, please dispose of the appliance in an environmentally friendly manner in line with local legislation.

CARE + REPAIR PROGRAM

FOR WARRANTY REPAIR

For repair of products that are under Warranty and have been properly registered within 30 days of purchase date, a warranty claim should be initiated. See solanopower.com for details or call 800-733-7902. Please be prepared to share a description and have a copy of the original proof of purchase available. Prior to initiating a warranty claim, please be sure to review the terms of our 2-year limited warranty and confirm that the issue you are reporting is valid and indeed covered.

Products covered under our 2-Year limited warranty will be repaired, refurbished, reconditioned by a certified Solano Technician within 7 days of receipt and *return shipped at no additional cost (when selecting our discounted shipping option with your warranty claim order), otherwise, you will be responsible for paying for return shipping. *valid for shipments in continental U.S. Only, otherwise additional shipping costs will apply.

NON-WARRANTY REPAIR

If you do not qualify for Warranty repair, you still may obtain repair service for your Solano

product. Please visit solanopower.com for details on our dryer repair service. Once a

repair order is initiated, the dryer will be inspected, repaired, refurbished, and reconditioned and return shipped at no additional cost. If your dryer is not under warranty and repair is not possible, you will be contacted by a Solano customer service representative to discuss service options.

EXTENDED 2-YEAR WARRANTY

If you qualified for and obtained the 2-Year Limited Warranty, you may purchase (for a nominal fee) an additional 2-Year Limited Warranty by visiting solanopower.com or call 800-733-7902. You must do so prior to the expiration of the initial 2-Year Warranty. All 2 - Year Limited Warranty terms will apply for this additional term.

THANK YOU!

register your solano®



solano® is a family-owned company.
solano® and supersolano® are
registered trademarks of KOSSOF
BEAUTY, LLC.

281 waukegan road | northfield, il
60093 | 800.733.7902

solanopower.com